产品说明书 尺寸:50x75mm 材质:80g书写纸 双面印刷 风琴折

htc

头戴式无线蓝牙耳机13

快速入门指南
使用前请阅读使用说明书
HTC HP13

产品规格

型号:HTC HP13

蓝牙
范围:≈10m
版本:6.0

喇叭
直径:40mm
阻抗:32Ω

功率
输入:5V⎓1000mA
电池容量:1000mAh
使用时间:≈35小时
充电时间:≈3小时

物品清单



如何正确佩戴耳机

连接到蓝牙设备

在您的设备上,打开蓝牙
并选择连接到"HTC HP13"。

图标介绍

ᛒ	状态
灰色	耳机未连接到手机
白色	耳机已连接到手机
APP	状态
灰色	APP未连接
绿色	APP已连接

充电



将您的充电器连接到USB-C端口

基本操作



初始激活
注:首次使用需要初始激活。
执行以下任一操作:
• 通过USB Type-C接口给耳机充电激活。
• 按住电源键三秒钟。

打开显示屏
执行以下任一操作:
• 双击显示区域(须打开触控唤醒功能)
• 单击电源键

关闭显示屏
自动息屏:设置自动息屏时间,自动息屏。
手动熄屏:单击电源键,显示屏熄灭。

多功能按键功能

状态	操作	功能
音乐 ♫	单击	播放/暂停/接听/挂断
	双击	下一曲
	三击	上一曲
	长按	语音助手/拒接来电
	顺时针转	音量加
	逆时针转	音量减
菜单	顺时针转	向下滑
	逆时针转	向上滑

电源按键功能
• 单击:亮屏/灭屏
• 长按3秒:关机
• 长按10秒:重启

导航操作
• 向左/右滑动:查看更多功能
• 向下滑动:查看屏幕设置
• 向上滑动:音乐播放界面



显示屏功能介绍

主界面
亮屏解锁屏幕,解锁屏幕后,向左/右滑动即可浏览这些功能
音乐背景:长按切换音乐背景壁纸

功能菜单
上下滑动查看菜单项,点击进入对应选项

音乐播放 ♫
上一曲 播放/暂停 下一曲
− 音量减 + 音量加

场景音效
点击任意模式以使用它

模式选择
点击切换音乐模式和游戏模式

计时器
根据自定义时间倒计时,时间结束,耳机会发出滴滴报警声。

天气
点击查看天气信息(需连APP)



海拔与气压
点击查看海拔与气压信息(需连APP)

步数
点击查看今日步数(需连APP)

使用指南
扫描二维码以查看使用指南

APP下载
扫描二维码以下载APP;
连接APP后,可使用对应功能

系统设置
向上滚动并轻点某一选项,以访问其选项

系统菜单
点击执行关于设备,恢复出厂,重启,关机对应功能设置。

亮度调节
亮度调节:上下滑动提高或降低屏幕亮度

息屏时间
点击设置息屏时间

背景壁纸
选择背景图片

语言设置
切换不同国家/地区的语言

触摸唤醒
打开时可以触屏点亮屏幕
关闭时无法触屏点亮屏幕
默认为打开

屏幕设置
点击设置对应选项

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○:表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。
表单标记"X"的部件,皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件:包括印刷电路板及其零部件,电子元器件等,根据产品型号不同,您所购买的产品可能不会含有以上所有部件。

重要安全说明

在使用本产品之前,请仔细阅读本说明书中的所有安全说明。

• 小心使用本产品,并将其存放在没有极端温度、高温高压和潮湿的清洁环境中。确保产品存放在不易弯曲或挤压的地方。
• 维修和更换只能由授权的售后服务人员进行。请勿自行拆卸或更换产品的任何部件,以防受伤或损坏设备。对产品的任何未经授权的修改都将使保修无效。
• 仅在允许蓝牙传输的环境中使用本产品。

• 如果产品有明显缺陷或出现膨胀或温度过高等异常,请勿使用。
• 执行需要全神贯注的高风险任务时,请勿使用本产品。
• 为了保护您的听力,请勿长时间高音量收听。
• 请将产品及其包装放在儿童和宠物接触不到的地方,以防发生吞咽和窒息等事故。

该产品内置可充电电池,请阅读以下说明,确保安全使用和处置。
• 请勿将产品长时间暴露在热源中,如明火或阳光直射。
• 仅将产品存放在环境温度为 0°C 至 35°C (32°F 至 95°F) 的环境中。
• 请勿在易产生灰尘、烟雾、高温、高压或高湿度的环境中使用或存放本产品。
• 保持产品干燥,远离液体或湿气。
• 只能使用经 FCC 或 CCC 认证、输出电压为DC 5V/1A的充电器。
• 充电时不要使用产品。
• 产品充电时间不要超过8小时。
• 按照当地的废物管理规定负责任地处理产品。

售后服务电话:4009933981

法律声明
商标和许可:
HTC和HTC标志为HTC公司的商标,
授权给深圳市卜兰沃德科技有限公司使用。
2026版权©归深圳市卜兰沃德科技有限公司。
本文件仅供参考,不构成任何形式的保证,本公司保留所有权利。

htc

---

htc

Wireless Headphones 13

Quick Start Guide
HTC HP13

Product Specifications

Model: HTC HP13

Bluetooth
Range: ≈10 m
Version: 6.0

Speaker
Diameter: 40 mm
Impedance: 32 Ω

Power
Input: 5 V⎓1000 mA
Battery capacity: 1000 mAh
Battery life: ≈ 35 hrs
Charging time: ≈ 3 hrs

What's in the box

How to put on the headphones

Connect to Bluetooth device



On your device, turn on Bluetooth and choose to connect to "HTC HP13".

Status icons

ᛒ	Status
Solid grey	Headphones are disconnected from your phone
Solid white	Headphones are connected to the your phone
APP	Status
Solid grey	APP not connected
Solid green	APP connected

Charging



Connect your charger to the USB-C port.

Basic operations



Initialization
If you're using the display for the first time, make sure that the headphones is charged then press and hold the power button for three seconds.

Turn on the display
Do any of the following:
• Tap the display twice. ("Tap to wake"must be on.)
• Press the power button once.

Turn off the display
The display shuts off automatically after the set idle duration.
To manually turn it off, press the power button once.

Multifunction button

Status	Operation	Function
Music	Single press	Play/Pause/Answer/End Call
	Second press	Next
	Triple Tap	Previous
	Long Press	Voice Assistant/Reject Call
	Rotate clockwise	Volume up
	Rotate counterclockwise	Volume down
Menu	Rotate clockwise	Next item
	Rotate counterclockwise	Previous item

Power button
• Press once: Turn the screen on/off
• Press and hold for three seconds: Power off
• Press and hold for ten seconds: Restart

Navigation
• Swipe left/right: View the more options
• Swipe down: View screen settings
• Slide up: Music playback interface

Display feature overview

Home screen
Swipe to view the items.
Music wallpaper: Long press to switch music wallpaper.

Menu
Swipe up or down to view the items and tap to access its options.

Music
Previous Play/Pause Next
− Volume down + Volume up

Scene sound effects
Tap any of the mode to use it.

Mode selection
Tap to switch between music mode and game mode.

Timer
After the customized countdown time expires, the headset will emit a beeping alarm sound.

Weather
Tap to view weather info (APP connection required).



Altitude and air pressure
Tap to view altitude and barometric pressure info (APP connection required).

Steps
Tap to view today's steps (APP connection required).

User guide
Scan the QR code to view the user guide.

App download
Scan the QR code to download the APP.
Connect to the APP to access corresponding functions.

System settings
Configure your charging case settings.

System menu
Check your device details, perform a factory reset, restart, or power off your device.

Brightness
Adjust the screen brightness by swiping up or down.

Screen timeout
Tap to set screen timeout duration.

Background wallpaper
Choose a background image.

Language
Choose the language to use for the display.

Tap to wake up
Enable this so you can turn on the display by tapping it.

Display settings
Click to set corresponding options.

Important Safety Instructions

Carefully read all the safety instructions in this document before using the product.

General safety instructions
• Use the product with care and store it in a clean environment that is free from extreme temperature, pressure, and humidity. Make sure that the product is stored in a location where it cannot be bent or squeezed.
• Repairs and replacements should only be performed by authorized after-sales service staff. Do not attempt to disassemble or replace any part of the product yourself to prevent injuries or damage to the device. Any unauthorized modification to the product voids the warranty.
• Only use the product in environments where Bluetooth transmission is permitted.

Personal safety instructions
• Do not use the product if it is obviously defective or exhibits abnormalities such as bulging or excessive heating.
• Do not use the product when performing high-risk tasks that require your full attention.
• For your hearing protection, do not listen at high volume for long periods.
• Keep the product and its packaging out of reach of children and pets to prevent accidents such as swallowing and choking.

Battery safety instructions
The product has a built-in rechargeable battery. Read the following instructions to ensure safe use and disposal.
• Keep the product away from prolonged exposure to heat sources such as open fires or direct sunlight.
• Only store the product in environments with ambient temperatures of 0°C to 35°C (32°F to 95°F).
• Do not use or store the product in dust-prone, smoke-prone, high-temperature, high-pressure, or highly humid environments.
• Keep the product dry and away from liquids or moisture.
• Only use an FCC or CCC-certified charger with an output voltage of 5 V/1 A DC.
• Do not use the product while charging.
• Do not leave the product charging for longer than eight hours.
• Dispose of the product responsibly according to your local waste management guidelines.

FCC ID: 2BHJR-HP13

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.
*RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

US REP
Company Name: LOBOS IOWA INC
FRN: 0036413961
Contact Name: Harley Li
Address: 4623 Bittercreek Dr Colorado Springs CO 80922 US
Phone: +1 8188180538
Email: info@lobos-iowa.com

Customer Service Email: service@yhemi.net

Legal notice
Trademarks and permissions:
HTC and the HTC logo are trademarks of HTC Corporation and used under license by Shenzhen Brands World Technology Co., Ltd.
Copyright © 2026 Shenzhen Brands World Technology Co., Ltd.
All rights reserved.
THIS DOCUMENT IS FOR INFORMATION PURPOSES ONLY AND DOES NOT CONSTITUTE ANY KIND OF WARRANTY.

htc