FUEL INJECTOR User Manual

Sharing valuable products to those who need them

TECHNICAL SUPPORT SERVICE TEAM

Supporting Contact us Immediately After Purchasing to Get

"2-year Factory Warranty"

"2-year Free Replacement"

"2-year Technical Support"

"Repeat Purchase Welfare Plan"

"Recommend a friend Welfare Plan"

If you don't understand what it means, please contact us immediately.

E-mail: s-upport-aut6@outlook.com

Contents

1.Product Specifications

2.Installation Guide

3.After-Sales Service

PRODUCT SPECIFICATIONS

Brand:	SZKAIDAG
Product:	Fuel Injectors
Manufacturer:	Yazhidianf
Terminal Type:	Blade
Lifespan:	5 Year
Driving Kilometers:	40000-60000
System Type:	Top Feed
New or Reman:	New

4.User instructions :

① Please purchase the product through official channels , otherwise we won't provide atter-sales service .

② As the product has small sharp parts , please keep it away from children .

③ After receiving the product , please carefully check whether it is damaged orany part is missing . If there is any problem , please contact Customer Service

④ After receiving the product , please carefully check whether it is damaged orany part is missing . If there is any problem , please contact Customer Service

INSTALLATION INSTRUCTIONS

1.Ensure the engine is turned off and the key is removed from the ignition.

2.Wear appropriate safety gear, including gloves and eye protection.

3.Locate the existing fuel injector on your engine and disconnect the electrical connector.

4.Carefully remove the old injector and any associated O-rings.

5.Install the New Injector

1 . Remove Connector

2 : Remove Fuel Rail

3 : Lift Up On Rail

4 : Remove Old Fuel Injector

5 : Fuel Injector O Ring

6 . Install Fuel Injector

7 : Push Down On Rail

8 : Reinstall Bolts

9 : Reconnect Electrical