正面

Smartwatch

TGW02

User Manual

Please use a 5V1A adapter for charging.

To make full use of the features of this smartwatch, please read this manual (including the warranty certificate) carefully until the end.

Safety Precautions

Before Use

This product is not a medical device. The watch and its app cannot be used for the diagnosis, treatment, or prevention of diseases or symptoms.

⚠ Caution

1.The watch has waterproof, sweatproof, and rainproof features, allowing for direct use in daily environments such as exposure to rain, sweat, and hand washing.
2.Do not use it in baths, saunas, hot springs, or other hot and steamy environments.

⚠ Usage Precautions

1.The language of the smartwatch synchronizes with the smartphone settings.
2.Monitoring data for various features will sync with the product. To obtain information, wearing the product is necessary.
3.Available features include: multiple watch faces, step counting, calorie tracking, various sports modes, smart reminders (calls/SMS/sedentary reminders, etc.), stopwatch, brightness adjustment, find my phone,power on/off, and more.
4.Some features like drink water reminders, call notifications, SMS notifications, and menstrual calendar are off by default. You need to enable them in the app under "Device Settings."

Wearing/Installation

Wearing | Band Replacement

Wear the device approximately one finger's width away from the wrist bone.
Adjust the strap to a comfortable position.
Press the switch on either the right or left side to remove the strap.
Do not wear it too tight, a slight looseness allowing the index finger to pass through is optimal.

App Download and Pairing

1.App Download:

Download and install the "VeryFit" app from the App Store or Google Play by scanning the QR code below.

iOS: Requires iOS 9.0 or later.

Android: Requires Android 6.0 or later.

Features and Operations

1. Main Interface Introduction

Notifications
Swipe up to access message notifications.

Main screen
- Do Not Disturb Mode
- Screen Brightness Adjustment
- Raise to Wake
- Flashlight
- Drain Water Function
- Settings
- Alarm Settings
- Power Saving Mode
- Find My Phone

Basic Settings
Swipe down to switch to the basic settings screen.

Data and Records:
Swipe left to switch screens. Alexa, weather, and music display can be added in the app:
"VeryFit App" → "Device" → "Other Settings" → "Shortcuts."

3. AI Voice Assistant

Use voice commands to control built-in assistants like Siri or Google Assistant on your smartphone.

4. Sports Mode

The watch supports up to 12 types of exercises.
The app offers 100 sports modes, which can be added or removed from the smartwatch.
A maximum of 12 sports modes can be displayed on the smartwatch at a time.

7. Notification Function

a. Message Notifications

When the smartwatch is paired with the dedicated app, notifications from Instagram, Facebook, LINE, SMS, Twitter, incoming calls, and messages can be set in the app to notify you via vibration, ensuring you never miss any important contacts.

Click on the app → Device → Tap Notifications → Sync phone notifications

Notifications
Sms
Call
Wechat
Qq
Facebook
Twitter
Whatsapp
Line
Instagram
Linkedin
Skype
Messenger
Viber
Snapchat
Gmail
Outlook
Yahoo
Google+
Hangouts
Tencent Mobile Manager
Tencent Mobile Manager
Tencent Mobile Manager