BR01

ACTIVO

INSTRUCTION BOOK

각 부의 명칭



1	🔇	음소거	7	☼	화면 ON/OFF
2	◀◀	(짧게) 이전 곡 (길게) 뒤로 감기	8	⌂	홈 이동
3		볼륨 제어	9	<	뒤로가기
4	▶▶	(짧게) 다음 곡 (길게) 앞으로 감기	10	B	블루투스 연결
5	▶I	재생/정지	11	⏻	전원 ON/OFF
6		LED	12		충전단자

페어링

전원 켜기 / 끄기

1. 리모컨 우측에 있는 ⏻ 버튼을 위로 올려주세요.
2. 사용이 끝나면 ⏻ 버튼을 아래로 내려 전원을 꺼 주세요.

처음 연결하는 방법(페어링)



1. 전원을 켠 상태에서 B 버튼을 3초 이상 길게 눌러 주세요.



2. 하얀색 LED가 깜빡이며 페어링 모드로 진입합니다.

3. 연결하려는 기기의 블루투스 설정에서 [ACTIVO BR01]을 선택하면 페어링이 완료됩니다.

LED 동작 사양

전원 켬	하얀색 3초 점등	**충전중**	주황색 점등
페어링 모드	하얀색 깜빡임	**충전 완료**	초록색 점등
페어링 완료	하얀색 10초 점등	**배터리 부족**	주황색 깜빡임

멀티 페어링 방법

여러 기기와 연결하기



1. 전원을 켜고 ☼ 버튼을 3초 이상 길게 눌러주세요. 이때 하얀색 LED가 '한 번' 깜빡입니다.
2. **B** 버튼을 3초 이상 길게 눌러 하얀색 LED가 반복적으로 깜빡이면, 기기 무선 설정에서 1번 기기를 등록합니다.
3. ⌂버튼을 3초 이상 길게 눌러 하얀색 LED가 '두 번' 깜빡이면, **B**버튼을 길게 눌러 2번 기기를 등록합니다.
4. < 버튼을 3초 이상 길게 눌러 하얀색 LED가 '세 번' 깜빡이면, **B**버튼을 길게 눌러 3번 기기를 등록합니다.
5. 모든 기기 등록이 완료되면 ☼/⌂/< 버튼을 길게 눌러 각각 연결하여 사용하시면 됩니다.

문제 해결

1. 리모컨이 연결되지 않아요.

- 리모컨과 연결 기기의 블루투스 설정을 껐다 켠 후 다시 시도해 주세요.
- 연결된 기기의 블루투스 설정 목록에서 [ACTIVO BR01]를 삭제한 후 다시 연결해 주세요.

2. 사용 중에 블루투스 연결이 끊어져요.

- 블루투스가 연결된 상태에서 30분 동안 아무런 동작을 하지 않으면 슬립모드로 진입합니다.
- 리모컨이 슬립모드로 진입하여 연결이 끊어졌을 경우 임의의 버튼을 누르면 자동으로 다시 연결됩니다.
- 자동으로 연결이 되지 않을 경우 리모컨을 껐다 켜면 다시 연결됩니다.

참고 사항

1. ACTIVO BR01은 Astell&Kern, ACTIVO 제품에 최적화 되어있으며, 다른 기기와 연결할 경우 호환되지 않거나 일부 기능에 제약이 있을 수 있습니다. 호환성 문제는 제품의 교환 또는 수리 사유에 포함되지 않습니다.

2. 스트리밍 앱에 따라 뒤로 감기, 앞으로 감기 기능이 동작되지 않을 수 있으며, 이는 제품의 문제가 아닌 앱 사양입니다.

Part Names



1	🔇	Mute	7	☼	Screen ON/OFF
2	◀◀	(Short Press) Previous Track (Long Press) Rewind	8	⌂	Home
3		Volume Control	9	<	Back
4	▶▶	(Short Press) Next Track (Long Press) Fast-Forward	10	B	Bluetooth Pairing
5	▶I	Play/Pause	11	⏻	Power ON/OFF
6		LED	12		Charging Port

Pairing

Power ON / OFF

1. Slide the power button up on the right side.
2. Slide it down to power off the device.

First-time Connection (Pairing)



1. Press and hold the Bluetooth Pairing button "B" for at least 3 seconds.



2. The white LED will blink, indicating pairing mode.



3. On your device, go to Bluetooth settings and select 'ACTIVO BR01' to complete pairing.

LED Status Indicator

Power ON	White LED remains on for 3 seconds
Pairing Mode	White LED blinks
Pairing Complete	White LED remains on for 10 seconds
Charging	Orange LED remains on
Fully Charged	Green LED remains on
Low Battery	Orange LED blinks

Multi-pairing Guide

Connecting to Multiple Devices



1. Turn on the power and press and hold the ☼ button for at least 3 seconds. The white LED will blink once.
2. Press and hold the **B** button for at least 3 seconds. When the white LED blinks repeatedly, pair Device 1 in your device's wireless settings.
3. Press and hold the ⌂ button for at least 3 seconds. When the white LED blinks twice, press and hold the B button to pair Device 2.
4. Press and hold the < button for at least 3 seconds. When the white LED blinks 3 times, press and hold the B button to pair Device 3.
5. Once all devices are paired, press and hold the ☼ / ⌂ / < button to connect and use each device.

Troubleshooting

1. The remote control does not connect.

- Turn Bluetooth off and back on for both your device and the remote, then try pairing again.
- Forget 'ACTIVO BR01' from your device's Bluetooth list and try pairing again.

2. The Bluetooth connection drops during use.

- The remote automatically enters sleep mode after 30 minutes of inactivity while connected.
- If disconnected due to sleep mode, press any button to automatically reconnect.
- If it does not reconnect automatically, turn the remote off and on again.

Notes

1. ACTIVO BR01 is optimized for Astell&Kern and ACTIVO products.
   Compatibility issues or limited functionality may occur with other devices.
   Compatibility issues are not covered under the product warranty.

2. Rewind and fast-forward functions may not work depending on the streaming app.
   This is an app limitation, not a product defect.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

各部の名称と機能



1	🔇	消音	7	☼	画面 ON / OFF
2	◀◀	短押し : 前の曲 長押し: 早戻し	8	⌂	ホーム移動
3		音量調節	9	<	戻る
4	▶▶	短押し : 次の曲 長押し : 早送り	10	B	Bluetooth 接続
5	▶I	再生 / 一時停止	11	⏻	電源 ON / OFF
6		LED	12		充電端子

ペアリング

電源 ON / OFF

1. リモコン右側の⏻ボタンを上にスライドします。
2. 使用後は⏻ボタンを下にスライドし電源を切ります。

初めて接続する方法(ペアリング)



1. 電源を入れた状態で、Bボタンを3秒以上長押ししてください。



2. 白色のLEDが点滅し、ペアリングモードに入ります。

3. 接続する機器のBluetooth設定から[ACTIVO BR01]を選択すると、ペアリングが完了します。

LED動作仕様

電源ON	白色 3秒間点灯
ペアリングモード	白色 点滅
ペアリング完了	白色 10秒間点灯
充電中	オレンジ色 点灯
充電完了	緑色 点灯
バッテリー残量少	オレンジ色 点滅

マルチペアリング方法

複数の機器と接続する



1.電源を入れ、☼ボタンを3秒以上長押ししてください。
この時、白色のLEDが1回点滅します。
2. **B** ボタンを3秒以上長押しし、白色のLEDが繰り返し点滅したら、接続機器のワイヤレス設定から1台目の機器を登録します。
3. ⌂ボタンを3秒以上長押しし、白色のLEDが2回点滅したら、**B** ボタンを長押しして2台目の機器を登録します。
4. < ボタンを3秒以上長押しし、白色のLEDが3回点滅したら、**B** ボタンを長押しして3台目の機器を登録します。
5.すべての機器の登録が完了したら、☼/⌂/< ボタンを長押ししてそれぞれ接続して使用してください。

トラブルシューティング

1. リモコンが接続できません。

- リモコンと接続機器のBluetoothを一度オフにし、再度オンにしてからお試しください。
- 接続機器のBluetooth設定から[ACTIVO BR01]を削除し、再接続してください。

2. 使用中にBluetooth接続が切れます。

- 接続した状態で30分間操作がない場合、スリープモードに入ります。
- スリープモードで接続が切れた場合は、いずれかのボタンを押すと自動的に再接続されます。
- 自動的に再接続されない場合は、リモコンの電源を入れ直してください。

注意事項

1. ACTIVO BR01はAstell&KernおよびACTIVO製品に最適化されています。
   他機器との接続時は、互換性の問題や一部機能が制限される場合があります。
   互換性による問題は、製品の交換や修理の対象外となります。

2. ストリーミングアプリによっては、早戻し・早送り機能が 動作しない場合があります。
   これはアプリの仕様であり、故障ではありません。

部件名称与功能



1	🔇	静音	7	☼	屏幕 开启 / 关闭
2	◀◀	(短按) 上一首 (长按) 快退	8	⌂	主页
3		音量控制	9	<	返回
4	▶▶	(短按) 下一首 (长按) 快进	10	B	蓝牙连接
5	▶I	播放 / 暂停	11	⏻	电源 开启 / 关闭
6		LED	12		充电接口

配对

电源 开启 / 关闭

1. 请将遥控器右侧的⏻键向上推。
2. 使用完毕后，请将⏻键向下推以关闭电源。

首次连接方法(配对)



1. 在电源开启的状态下，长按 B 键 3 秒以上。



2. 白色 LED 灯闪烁，进入配对模式。

3. 在待连接设备的蓝牙设置中选择 [ACTIVO BR01] 即可完成配对。

LED 指示灯状态

电源开启	白色 亮起 3 秒
配对模式	白色 闪烁
配对完成	白色 亮起 10 秒
充电中	橙色 亮起
充电完成	绿色 亮起
电量不足	橙色 闪烁

多台设备配对方法

连接多台设备



1.开启电源，长按☼ 键3秒以上。此时白色LED灯将闪烁1次。
2. **B** 长按B键3秒以上，当白色LED灯连续重复闪烁时，在设备的无线设置中添加注册 1 号设备。
3.长按 ⌂ 键3秒以上，当白色LED灯闪烁2次时，长按 **B** 键添加注册 2 号设备。
4.长按 < 键3秒以上，当白色LED灯闪烁3次时，长按 **B** 键添加注册 3 号设备。
5.所有设备注册完成后，长按 ☼ / ⌂ / < 键即可分别连接并使用。

故障排除

1. 遥控器无法连接。

- 请重启遥控器和待连接设备的蓝牙，然后重试。
- 请在设备的蓝牙列表中删除 [ACTIVO BR01]，并重新连接。

2. 使用中蓝牙连接断开。

- 蓝牙连接状态下，如 30 分钟无操作，设备将进入休眠模式。
- 因休眠模式断开连接时按任意键即可自动重新连接。
- 如无法自动连接，请重启遥控器电源再次尝试。

注意事项

1. ACTIVO BR01 已针对 Astell&Kern 和 ACTIVO 产品进行优化。
   连接其他设备时，可能会出现不兼容或部分功能受限的情况。
   因兼容性问题产生的不良，不属于产品换货或保修范围。

2. 根据流媒体应用的不同，快退、快进功能可能无法正常工作。
   此为应用自身的限制，并非产品故障。

产品规格

设备名称	蓝牙设备
设备型号	DEE31
材质	铝合金，PC, ABS
蓝牙版本	5.3
电池容量	210毫安
充电时间	2小时
充电接口	USB Type-C
尺寸	36.7*102.7*17.9mm
重量	44.5g

CMIIT ID : 26J99VW7U404
制造商：MITER Inc
产地：中国

Specifications

Product Name	ACTIVO BR01
Model	DEE31
Material	Polycarbonate , Aluminum (Wheel) ABS (Body)
Bluetooth Version	5.3
Battery	210mAh
Charging Time	Approx. 2 hours
Charging Type	USB Type-C
Dimensions	1.44"(36.7mm)[W] x 4.04" (102.7mm)[H] x 0.7" (17.9mm)[D]
Weight	Approx. 1.56oz (44.5g)

Certifications

R-R-mIT-DEE31
MODEL: DEE31
5V⎓100mA
MADE IN CHINA

ⓡ 210-266924
CMIIT ID : 26J99VW7U404

FCC ID: 2BKCX-DEE31
This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.