UNIMAC | ACM-250

AIR COMPRESSOR



User Manual

[Revision 2.0]

READ THIS MANUAL CAREFULLY BEFORE USE – FAILURE TO DO SO MAY RESULT IN INJURY, PROPERTY DAMAGE AND MAY VOID WARRANTY. • KEEP THIS MANUAL FOR FUTURE REFERENCE. • Products covered by this manual may vary in appearance, assembly, inclusions, specifications, description, and packaging.

The product is NOT supplied with engine oil, although traces of oil from the manufacturing process may be present. It is essential to add adequate engine oil of the correct type to the engine before use. Failure to add engine oil will void the product warranty.

Safety

Safety messages are designed to alert you to possible dangers or hazards that could cause death, injury or equipment or property damage if not understood or followed. Safety messages have the following symbols:



You WILL be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You CAN be KILLED or SERIOUSLY INJURED if you do not follow instructions.



You CAN be INJURED if you do not follow instructions or equipment damage may occur.

It is vital that you read and understand this user manual before using the product, including safety warnings, and any assembly and operating instructions. Keep the manual for future reference.

Safety precautions and recommendations detailed here must be fully understood and followed to reduce the risk of injury, fire, explosion, electrical hazard, and/or property damage.

Safety information presented here is generic in nature – some advice may not be applicable to every product. The term "equipment" refers to the product, be it electrical mains powered, battery powered or combustion engine powered.

- **Before Use** - If you are not familiar with the safe operation/handling of the equipment or are in any way unsure of any aspect of suitability or correct use for your application, you should complete training conducted by a person or organization qualified in safe use and operation of this equipment, including fuel/electrical handling and safety.
- Do NOT operate the equipment in flammable or explosive environments, such as in the presence of flammable liquids, gases, or dust. The equipment may create sparks or heat that may ignite flammable substances.
- Keep clear of moving parts.
- Equipment may be a potential source of electric shock or injury if misused.
- Do NOT operate the equipment if it is damaged, malfunctioning or is in an excessively worn state.
- Do NOT allow others to use the equipment unless they have read this manual and are adequately trained.
- Keep packaging away from children - risk of suffocation! Operators must use the equipment correctly. When using the equipment, consider conditions and pay due care to persons and property.

General Work Area Safety

- Work areas should be clean and well it.
- Do not operate the equipment if bystanders, animals etc are within operating range of the equipment or the general work area.
- If devices are provided for connecting dust extraction / collection facilities, ensure these are connected and used properly. Dust collection can reduce dust-related hazards.

General Personal Safety

- Wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect from eye and ear injury, poisoning, burns, cutting and crush injuries. Protective equipment such as safety goggles, respirators, non-slip safety footwear, hard hat, hearing protection etc should be used for appropriate equipment / conditions. Other people nearby should also wear appropriate personal protective equipment. Do not wear loose clothing or jewellery, which can be caught in moving parts. Keep hair and clothing away from the equipment.
- Stay alert and use common sense when operating the equipment. Do not over-reach. Always maintain secure footing and balance.
- Do not use the equipment if tired or under the influence of drugs, alcohol, or medication.
- This equipment is not intended for use by persons with reduced physical, sensory, or mental capabilities.

General Fuel Safety

- Petrol/fuel/gasoline is extremely flammable – keep clear of naked flames or other ignition sources.
- Do not spill fuel. If you spill fuel, wipe it off the equipment immediately – if fuel gets on your clothing, change clothing.
- Do NOT smoke near fuel or when refuelling.
- Always shut off the engine before refuelling.
- Do NOT refuel a hot engine.
- Open the fuel cap carefully to allow any pressure build-up in the tank to release slowly.
- Always refuel in well-ventilated areas.
- Always check for fuel leakage. If fuel leakage is found, do not start, or run the engine until all leaks are fixed.

General Carbon-Monoxide Safety

- Using a combustion engine indoors **CAN KILL IN MINUTES**. Engine exhaust contains carbon-monoxide – a poison you cannot smell or see.
- Use combustion engines OUTSIDE only, and far away from windows, doors, and vents.

General Equipment Use and Care

- Keep packaging away from children and pets, potential risk of suffocation or choking.
- The equipment is designed for domestic use only.
- Handle the equipment safely and carefully.
- Before use, inspect the equipment for misalignment or binding of moving parts, loose components, damage, or any other condition that may affect its operation. If damaged, have the equipment repaired by an authorised service centre or technician before use.
- Prevent unintentional starting of the equipment - ensure equipment and power switches are in the OFF position before connecting or moving equipment. Do not carry equipment with hands or fingers touching any controls. Remove any tools or other items that are not a part of the equipment from it before starting or switching on.
- Do not force the equipment. Use the correct equipment for your application. Equipment will perform better and be safer when used within its design and usage parameters.
- Use the equipment and accessories etc. in accordance with these instructions, considering working conditions and the work to be performed. Using the equipment for operations different from those intended could result in hazardous situations.
- Always keep equipment components (engines, hoses, handles, controls, frames, housings, guards etc) and accessories (cutting tools, nozzles, bits etc) properly maintained. Keep the equipment clean and, where applicable, properly lubricated.
- Store the equipment out of reach of children or untrained persons. To avoid burns or fire hazards, let the equipment cool completely before transporting or storing. Never place or store the equipment near flammable materials, combustible gases, or liquids etc.
- The equipment is not weather-proof, and should not be stored in direct sunlight, at high ambient temperatures or locations that are damp or humid.
- Do not clean equipment with solvents, flammable liquids, or harsh abrasives.
- For specific equipment safety use and care, see Equipment Safety.

© Unimac

General Electrical Safety

- Inspect electrical equipment, extension cords, power bars, and electrical fittings for damage or wear before each use. Repair or replace damaged equipment immediately.
- Ensure all power sources conform to equipment voltage requirements and are disconnected before connecting or disconnecting equipment.
- When wiring electrically powered equipment, follow all electrical and safety codes.
- Always use a Residual Current Device (RCD) (GFCI) / Earth Leakage Circuit Breaker / Safety Switch when operating this item (electrical items only).
- High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.

General Electrical Safety

- Electrically grounded equipment must have an approved cord and plug and be connected to a grounded electrical outlet.
- Do NOT bypass the ON/OFF switch and operate equipment by connecting and disconnecting the electrical cord.
- Do NOT use equipment that has exposed wiring, damaged switches, covers or guards.
- Do NOT use electrical equipment in wet conditions or in damp locations.
- Do NOT use electrical cords to lift, move or carry equipment.
- Do NOT coil or knot electrical cords, and ensure electrical cords are not trip hazards.

General Service Information

- The equipment must be serviced or repaired at authorised service centres by qualified personnel only.
- Replacement parts must be original equipment manufacturer (OEM) to ensure equipment safety is maintained.
- Do NOT attempt any maintenance or repair work not described in this manual.
- After use, the equipment and components may still be hot – allow the equipment to cool and disconnect spark plugs and/or electrical power sources and/or batteries from it before adjusting, changing accessories, or performing repair or maintenance.
- Do NOT adjust while the equipment is running.
- Perform service-related activities in suitable conditions, such as a workshop.
- Replace worn, damaged or missing warning/safety labels immediately.

Child Choking Hazard!



- **WARNING: CHOKING HAZARD - CHILDREN UNDER 8 YRS. CAN CHOKE OR SUFFOCATE ON SMALL PARTS. ADULT SUPERVISION REQUIRED.**
- Carefully inspect anything a baby or child could gain access to, including this product & packaging.
- Dangers include anything of a size that could become stuck or lodged in a baby or child's airway.
- Dangers include things like raw, hard fruit and vegetable pieces, large pieces of meat, bones or sausage skins, popcorn, nuts, hard lollies and corn chips, small magnets and batteries, coins, beads, marbles and small uninflated balloons, broken toys and smaller toys, buttons, keys, and coins. But there are also many more.
- Pay particular attention to accessories, nuts, bolts, screws, washers, caps, covers, loose parts, parts that could be removed or break off, pieces of packaging, staples, tape etc.
- In the case of any doubt, secure the item of concern in an appropriate manner, or completely remove the possibility of access by a baby or child.

Air Compressor Safety

- **BEFORE OPERATING THIS AIR COMPRESSOR, READ AND UNDERSTAND THIS MANUAL TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, AND PERSONAL INJURY. THESE PRECAUTIONS ENSURE YOUR SAFETY AND EXTEND THE SERVICE LIFE OF YOUR MACHINE.**

General Safety Precautions

- Read the Manual: Understand the tool's applications, limitations, and potential hazards.
- Work Area: Keep workbenches tidy and floors clean. Slippery surfaces (e.g., due to sawdust or wax) increase the risk of accidents.
- Lighting: Ensure the work area is well lit.
- Flammable Materials: Do not use the compressor near combustible materials, flammable liquids (e.g., paint, varnish, petrol), or explosive gases or dust.
- Moisture: Do not expose the compressor to rain or use it in damp or wet conditions.
- Children and Pets: Keep them away from the work area.

Personal Safety

- Appropriate Tool Use: Use the correct tool for the job. Do not force small tools to do the work of heavy-duty equipment.
- Clothing and Accessories: Avoid loose clothing, jewellery, or anything that may get caught in moving parts.
- Hair: Tie back long hair or cover it securely.
- Eye Protection: Always wear safety goggles or glasses.
- Ear Protection: Wear ear protection during prolonged use.
- Footwear: Use non-slip, safety footwear where there's a risk of slipping or heavy objects falling.
- Securing the Workpiece: Use clamps or a vice instead of your hands to hold workpieces.
- Balance: Maintain stable footing and avoid overreaching.

Tool Maintenance

- Care and Cleaning: Keep tools sharp, clean, and well-lubricated.
- Cords: Regularly inspect the power cord and replace it if damaged. Keep it clean and away from oil, heat, solvents, and sharp edges.
- Ventilation: Ensure air vents are clean and free from dust to prevent overheating.
- Alertness: Stay alert. Do not operate the compressor if you are tired, under the influence of alcohol, drugs, or medication causing drowsiness.

COMPRESSOR WARNINGS

- **DO NOT MODIFY THE COMPRESSOR.**
- **USE ONLY ACCESSORIES DESIGNED FOR COMPRESSED AIR.**
- **ADJUST OUTPUT PRESSURE TO MATCH THE TOOL OR ACCESSORY'S RATED PRESSURE.**
- **NEVER EXCEED THE MAXIMUM PRESSURE OF ANY CONNECTED TOOL OR ACCESSORY.**
- **REPAIRS MUST BE CARRIED OUT BY QUALIFIED TECHNICIANS USING GENUINE SPARE PARTS.**

Important Notices

- Breathable Air Warning: This unit is not suitable for supplying air for human consumption.
- Overload Protection: A thermal device will cut power if the motor overheats. It will reset automatically once cooled.
- Extension Leads: Avoid using extension leads. Use a longer air hose instead. If unavoidable, use a 15-amp rated cord for lengths up to 5 metres. Using an extension cord may cause voltage drop, motor damage, and void the warranty.
- Power Cord Handling: Never yank the cord to unplug the compressor or use it to carry or drag the unit.
- Inspection: Before each use, check for misalignment, binding, broken or missing parts. Have any faults repaired at an authorised service centre.

Operation Guidelines

- Disconnecting: Unplug the compressor and empty the tank when not in use, during maintenance, or when changing accessories.
- Prevent Unintentional Start-Up: Ensure the switch is in the OFF position before connecting to power.
- Switch Operation: Use the red knob on the pressure switch to turn the compressor ON or OFF:
  - ON: Pull the knob up.
  - OFF: Push the knob down.
- Note: Do not use the mains switch to turn the unit on and off. Doing so may damage the motor and void the warranty. The pressure switch also releases air from the delivery pipe when the motor stops, reducing restart load.

⚠ DANGER ⚠

Using an engine or wood/charcoal/gas fuelled appliance indoors CAN KILL YOU IN MINUTES. Engine exhaust and wood/charcoal/gas fumes contain carbon monoxide. This is a poison you cannot see or smell.



NEVER use inside a building, home, garage, boat, caravan or tent EVEN IF doors and windows are open.



Only use OUTSIDE and far away from windows, doors, and vents.

Avoid other hazards - READ MANUAL BEFORE USE.

GENERAL:
- Do not operate in a hazardous location. Such areas include where there is a risk of explosion of petrol fumes, leaking gas or explosive dusts.
- Do not operate in a confined area where exhaust gases or wood/charcoal/gas fumes could reach dangerous concentrations.

PRODUCTS FEATURING AN ENGINE
- Follow all warnings in the section titled "GENERAL".
- Explosion hazard - never smoke while refuelling.
- Take care not to spill fuel. When refuelling the engine, ensure that the engine has been allowed to cool. Prevent spilling of fuel as this may also ignite with a hot engine.
- Never refuel while engine is running.

GENERATORS
- Follow all warnings in the sections titled "GENERAL" and "PRODUCTS FEATURING AN ENGINE".
- The output of this generator is potentially lethal. The generator should not be connected to a fixed electrical installation except by an appropriately licensed person.
- Not weatherproof – protect your machine. This machine is not weatherproof and should not be exposed to direct sunlight, high ambient temperature, damp conditions, wet conditions or high humidity conditions.

Safety Symbols

The product may have safety warning labels attached to it, explained below. Understand the symbols on your product and their meanings. If any stickers become unreadable, unattached etc., replace them.



Flammable Material Hazard
Flammable liquids, gases, or substances etc may present. Avoid ignition sources and open flames. Danger of fire.



Read User Manual
Read and fully understand product safety warnings, operation, procedures etc before using the product.



Use Hand Protection
Wear appropriate hand protection and take due care as the product or use of the product may present hand hazards.



Carbon-Monoxide Hazard
Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.



Electrocution / Electrical Shock Hazard
High voltage or high current electricity may be present or required by the product. Take due care when handling electrical products, cables, plugs and leads. Electrical shock can be fatal.



Toxic Fumes / Dust Hazard
Using the product or by-products from use may produce fumes, smoke or particles that could be harmful if inhaled. Wear appropriate breathing protection and have adequate ventilation.



Explosive Material Hazard
Combustible liquids, gases, or substances etc may be present. Avoid ignition sources and open flames. Danger of explosion.



Cutting / Amputation Hazard
The product may have blades, edges or mechanical devices that can cause severe cut injury to fingers, limbs etc. Take due care when handling and using the product.



Crush Hazard
The product may have blades, edges or mechanical devices that can cause severe crush injury to fingers, limbs etc. Take due care when handling and using the product.



Single Operator Only
The product must be operated by a single person only. More than one person operating the product may introduce additional hazards.



Use Face Protection
Wear appropriate full-face protection and take due care as the product or use of the product may present face and eye hazards.



Use Foot Protection
Wear appropriate foot protection and take due care as the product or use of the product may present foot hazards.



Use Eye / Ear / Head Protection
Wear appropriate eye and / or ear and / or head protection and take due care as the product or use of the product may present eye, hearing, and head hazards.



Running Hazard
Do not run on or near the product as doing so may present a fall hazard.



Diving Hazard
Do not dive into the product as doing so may present a neck / head injury hazard.



Adult Supervision Required
Always supervise children and other users of a product to prevent drowning or injury.



Skin Penetration / Puncture Hazard
The product may produce pressure, emit liquids or objects that can cause severe injury to fingers, limbs, blood etc. Take due care when handling and using the product.



Hot Surface Hazard
Be aware that the product may produce high temperatures and hot surfaces that can cause burn injuries.



Flying Debris Hazard
Be aware that the product or use of the product may present hazards produced by flying debris. Wear appropriate clothing and protective devices.



Moving Parts Hazard
Be aware that the product contains or uses mechanical devices that move or rotate. Always wait for moving parts to stop fully before handling the product, adjusting, maintenance etc.

© Unimac



Carbon-Monoxide Hazard
Do not use the product in confined areas or without adequate ventilation. Carbon-monoxide poisoning can be fatal.



Pull Hazard
Be aware that the product contains or uses mechanical devices that can pull in objects and can cause severe injury to fingers, limbs etc. Take due care when handling and using the product.



Slope / Fall Injury Hazard
Be aware that using the product on sloping surfaces or in slippery conditions may present additional dangers from falls and contact with blades, moving parts, hot surfaces etc.



"Slam Dunk" Warning
Do NOT attempt "slam dunk" manoeuvres as this may result in severe injury due to falling, product breakage or collapse etc.



Electrocution / Electrical Shock Hazard - Outdoor
High voltage or high current electricity may be present or required by the product. Do NOT use in rain, damp, or wet conditions. Electrical shock can be fatal.



Electrocution / Electrical Shock Hazard - Disconnect
High voltage or high current electricity may be present or required by the product. Always disconnect the product from the electrical supply before handling the product, adjusting, maintenance etc.



Power Line Electrocution Hazard
High voltage / high current power lines may be present. Use extreme caution to avoid contact or interference with power lines. Electrical shock can be fatal.



"Kick-Back" Hazard
High level of "kick-back" hazard that can cause the machine to suddenly rotate towards operator. Kick-back injury can be fatal.



Winch Operator Position Hazard
Do NOT stand between winch and load. Do NOT use winch to move people.



Winch Lift Hazard
Do NOT LIFT load vertically. Use machine to PULL only.



Cable Hazard
Ensure that load bearing cable is not kinked or knotted.



Winch Cable Hazard
Ensure that there is a minimum number of cable coils on winching mechanism.



Winch Hook Hazard
Carry hook to load – do NOT throw or run.



Flash / Blinding Hazard
Wear appropriate eye protection for welding. Direct exposure to weld arcs may cause permanent eye injury.



Laser Hazard
Laser may be in use – do NOT look directly at laser or allow others to.



Choking Hazard
Children under 8 yrs. Can choke or suffocate on small parts. Adult supervision required.

© Unimac

Table of Contents

Safety **2**
Safety Symbols 5
Parts Identification **8**
Assembly **9**
Initial Start-Up **10**
Operation **11**
Maintenance **12**
Daily Checks 12
Weekly Maintenance 12
Monthly Maintenance 12
Every Three Months 12
Troubleshooting **13**
Specifications **14**

© Unimac

Parts Identification



No.	Name	No.	Name
1	Main compressor	7	Drain cock
2	Pressure switch	8	Wheel
3	Outlet valve	9	Discharge pipe
4	Pressure regulator	10	Air tank
5	Pressure gauge	11	Safety valve *(back of pressure switch)*
6	Non-return valve	12	Fan cover

Note: Fittings may differ from what are shown above.

Spare parts available for purchase, scan QR code below:

© Unimac

Assembly

This air compressor requires minor assembly before use. Locate the accessory pack, which should include:

- Wheel and axle set
- Rubber stopper
- Air filter
- Oil breather plug
- A bottle of oil

Assembly Steps:

1. Attach the wheels to the unit using the supplied axle kit. Insert the rubber stopper into the spigot at the base of the tank.





Note: A bottle of oil is included with the unit.

2. Check the oil level in the pump. Fill oil through the oil breather hole until the level reaches the top of the red circle in the sight glass.











Important: Change the oil after the first 10 hours of operation, then every 20 hours thereafter. To change the oil, use a shifter to remove the sight glass cover. Recommended oil: Use SAE 30 for temperatures above 10°C and SAE 10 for temperatures below 10°C.

© Unimac

Initial Start-Up

1. Ensure the unit is placed on a stable surface in a dry, well-ventilated location.
2. Make sure all air outlets and the drain valve are closed.
3. Connect the power lead to the mains supply.
4. Turn on the compressor by pulling up the red knob on the pressure switch.
5. Check for any air leaks.



Note: Output fittings may vary from those illustrated.

WARNING: Always use the red knob to switch the unit ON and OFF. Do not use the mains switch to control power. Doing so can damage the motor and void the warranty.

© Unimac

Operation

- The tank pressure is automatically controlled by the pressure switch located beneath the pressure switch cover.
- When the maximum set pressure is reached, the pressure switch activates and turns the motor off. As air is consumed, the pressure in the tank drops. When it reaches the minimum set pressure, the switch turns the motor back on.

Note: The motor may start and stop automatically while the compressor is in use. This is normal operation and occurs without warning as pressure rises or falls.

- The maximum and minimum pressure settings are factory-set and must not be adjusted.
- You can use the direct outlet, the regulated outlet, or both.
- To adjust the regulated outlet pressure, turn the control knob:
  - Clockwise to increase pressure
  - Anti-clockwise to decrease pressure



© Unimac

Maintenance

ATTENTION: Surface corrosion will occur on metal surfaces over time and the rate of oxidation depends on factors such as proximity to the ocean and humidity or condensation of water vapour on metal surfaces. To mitigate this, WD40 can be used to remove surface corrosion then, when applied periodically, it will prevent rust from forming.

WARNING: Before performing any maintenance, turn off the compressor, disconnect it from the mains supply, and discharge all air from the tank.

Daily Checks

- Check oil level before each use.
- Drain condensation from the air receiver.
- Inspect for air leaks.
- Hand-tighten cylinder head bolts to ensure they are secure.

Weekly Maintenance

- Remove the air filter element and clean or replace as needed.

Monthly Maintenance

- Inspect the non-return valve. Clean or replace if necessary.

  CAUTION: Ensure the tank is completely emptied before performing this task.

- Manually test the safety valve by pulling the ring to ensure it functions correctly.

Every Three Months

- Change the oil.
- Re-tighten cylinder head bolts.
- Clean and inspect the valve assembly. Replace gaskets or valves if worn or damaged.

Recommended compressor oil:

- Use SAE 30 for temperatures above 10°C
- Use SAE 10 for temperatures below 10°C

© Unimac

Troubleshooting

Issue	Possible causes	Recommended Action
Motor not running or running slowly	1. Faulty power supply or low voltage 2. Power cable is too thin or too long 3. Faulty pressure switch 4. Motor fault 5. Compressor is seized 6. Motor thermal overload has tripped	1. Check power supply 2. Replace with appropriate cable 3. Repair or replace switch 4. Repair or replace motor 5. Inspect and repair compressor 6. Turn off power, allow 10–15 minutes for motor to cool, then restart
Compressor sticking	1. Moving parts burnt due to insufficient oil 2. Moving parts damaged or obstructed by foreign object	Inspect crankshaft, bearing, connecting rod, piston, and piston rings; replace as necessary
Excessive vibration or abnormal noise	1. Loose fittings 2. Foreign object in compressor 3. Piston striking valve seat 4. Severely worn moving parts	1. Inspect and tighten connections 2. Clean out foreign objects 3. Replace with thicker paper gasket 4. Repair or replace worn parts
Insufficient pressure or reduced air output	1. Motor running too slowly 2. Blocked air filter 3. Leaking safety valve 4. Discharge pipe leak 5. Damaged sealing gasket 6. Valve plate worn, carbon build-up, or stuck 7. Worn or damaged piston ring or cylinder	1. Diagnose and correct motor speed 2. Clean or replace air filter 3. Check and adjust valve 4. Repair leak 5. Replace gasket 6. Clean or replace valve plate 7. Repair or replace worn components
Excessive oil consumption	1. Oil level too high 2. Blocked breather pipe 3. Worn piston ring or cylinder	1. Maintain oil at correct level 2. Clean breather pipe 3. Repair or replace components

Specifications

Power Type	Corded Electric
Power (HP)	2HP
Input Voltage	240V / 50Hz
Max. Air Flow	159L/min
Working Pressure	8 Bar, 116 PSI
Tank Capacity	24L
Flow Rate	159 L/min
Speed	2850 RPM
Outlet	1x 1/4" Ball Valve, 1 x Nitto Coupler

© Unimac

Some experts believe that the incorrect or prolonged use of almost any product may cause serious injury or death. To help reduce your risk of serious injury or death, refer to the information below. For more information, see www.datastreamserver.com/safety

- Consult all documentation, packaging, and product labelling before use. Note that some products feature documentation available online. It is recommended to print and retain the documentation.
- Before each use, check the product for loose/broken/damaged/missing parts, wear, or leaks (if applicable). Never use a product with loose/broken/damaged/missing parts, wear, or leaks.
- Products must be inspected and serviced (if applicable) by a qualified technician every 6 months. This is based on average residential use by persons of average size and strength, and on a property of average metropolitan size. Use beyond these recommendations may require more frequent inspections/servicing.
- Ensure that all users of the product have completed a suitable industry recognised training course before being allowed access to the product.
- The product has been supplied by a general merchandise retailer that may not be familiar with your specific application or description of application. Be sure to attain third-party approval from a qualified specialist for your application before use, regardless of any assurances from the retailer or its representatives.
- This product is not intended for use where fail-safe operation is required. As with any product (for example, automobile, computer, toaster), there is the possibility of technical issues that may require the repair or replacement of parts, or the product itself. If the possibility of such failure and the associated time it may take to rectify could in any way inconvenience the user, business, or employee, or financially affect the user, business, or employee, then the product is not suitable for your requirements. This product is not intended for use where incorrect operation or a failure of any kind, including but not limited to, a condition requiring product return, replacement, parts replacement, or service by a technician may cause financial loss, loss of employee time or an inconvenience requiring compensation.
- If this product has been purchased in error when considering the information presented here, contact the retailer directly for details of their returns policy, if required.

edisons.com.au

© Unimac. All rights reserved. No part of this document, including descriptive content, concepts, ideas, diagrams, or images may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, scanning, or recording, or any information storage and retrieval system, without express permission or consent from the publisher.