Electric Oil Filled Radiator

Instruction Manual

AH-QNQ1YT1



HJ-Customer-Service@outlook.com

6269443420 | 6267435564

EST 9:00AM--17:00PM

⚠ SAFETY INFORMATION

PLEASE SAVE THESE INSTRUCTIONS AND READ THIS MANUAL CAREFULLY BEFORE USE.

IMPORTANT SAFETY INSTRUCTIONS

When using this electric oil filled radiator, basic safety precautions should always be followed to reduce the risk of fire, electric shock, injury, and overheating, including the following:

⚠ WARNING

1. Read all instructions before using this appliance.
2. This radiator becomes hot during operation. To avoid burns， do not touch hot surfaces with bare skin. If equipped, use the handles when moving the radiator.
3. Keep combustible materials--such as furniture, pillows, bedding, paper, clothing, and curtains--at least 3 feet(0.9 m) away from the front of the radiator, and clear of the sides, top,and rear. Do not place towels or other objects on the radiator.
4. Use extreme caution when operating the radiator near children, individuals with disabilities, or when left unattended.
5. Always unplug the radiator before moving or cleaning, or whenever it is not in use.
6. Do not run the power cord under carpeting or cover it with rugs, runners, or similar coverings. Arrange the cord away from traffic areas and in a location where it will not cause tripping hazards.
7. To disconnect the radiator, turn the controls to OFF, then remove the plug from the outlet.
8. Do not insert or allow foreign objects to enter any ventilation or exhaust openings, as this may result in electric shock, fire, or damage to the radiator.
9. This appliance contains hot, arcing, or sparking components. Do not use in areas where gasoline, paint, or flammable/explosive liquids are used or stored. Keep the unit away from heated surfaces and open flames.
10. Use this radiator only as described in this manual and only for intended household purposes. Any other use not recommended by this manual may result in fire, electric shock, or injury.
11. Always plug the radiator directly into a wall outlet. Do not use with extension cords or relocatable power taps (such as power strips).
12. Hyperthermia can be fatal. Symptoms may include elevated body temperature, headache, nausea, vomiting, fatigue, dizziness, fainting, and rapid heartbeat. If you experience any of these symptoms, turn off the radiator immediately and seek medical attention.
13. To prevent excessive room temperatures that may lead to hyperthermia, do not leave the unit running unattended in confined spaces or near infants, or individuals with reduced physical, sensory, or cognitive abilities.
14. PLEASE SAVE THESE INSTRUCTIONS AND READ THIS MANUAL CAREFULLY BEFORE USE.

CAUTION

1. Before servicing the appliance, turn the main power switch to "OFF" and unplug it from the power outlet.
2.This heater draws 12.5 amps during operation. To prevent circuit overload, do not connect the heater to a power source shared with other appliances.
3. This radiator is designed for occasional or supplementary use. Do not operate it continuously or rely on it as the primary source of heat.
4. Do not hang or mount the product on a wall.
5. Place the product upright on a stable, level, and heat-resistant surface.
6.Do not operate the radiator if the power cord is damaged, or if the unit malfunctions, has been dropped, or otherwise damaged. Please contact our after-sales service for further assistance.
7. Do not use this radiator outdoors.
8. This radiator is not intended for use in bathrooms, laundry areas, or other similar indoor locations. Never place the radiator where it could fall into a bathtub or any other water container.
9.To reduce the risk of fire, do not block air intakes or exhaust openings. Do not use the radiator on soft surfaces, such as a bed, where openings may be obstructed.

TECHNICAL SPECIFICATIONS

Model	Rated Voltage/Frequency	Rated Current	Maximum Power
QNQ1YT1-26	120V ~ 60Hz	12.5 A	1500 W

⚠ WARNING

This radiator is designed for use with a 120 V power supply. The power cord has a polarized plug, with one blade wider than the other. To reduce the risk of electric shock, the plug is designed to fit into a polarized outlet in only one direction. If the plug does not fully fit into the outlet, reverse it. If it still does not fit, contact a qualified electrician to install a suitable outlet. Do not attempt to modify the plug or defeat this safety feature in any way. Never use this radiator with an extension cord or a relocatable power tap (such as a power strip).



PACKAGE CONTENTS



PART	NAME	QUANTITY
A	Radiator Body	1
B	Water Tank	1
C	Wing Nut	4
D	U-bolt	2
E	Castor Brackets	2
F	Castor Screws	4
G	Castor Wheels	4

PREPARATION

Before beginning assembly, ensure all parts are present. Compare the included components with the package contents above. If any parts are missing or damaged, do not attempt assembly. Contact our after-sales service for replacement parts.

ASSEMBLY INSTRUCTIONS

CAUTION: DO NOT OPERATE THIS RADIATOR WITHOUT CASTORS ATTACHED.
NOTE: Oil movement inside the radiator during transport is normal.



CASTOR ASSEMBLY:
1.Place the unit upside down on a flat, stable surface to prevent tipping.
2.Install 4 castors beneath the two castor brackets.
3.Attach the U-bolt around the two rear fins, then secure the castor bracket with wing nuts to the U-bolt.
NOTE:Do not over-tighten the wing nuts.
4.Put the unit on a flat surface and ensure that it can move freely and smoothly .
5.Set the unit upright and wait at least three minutes for the oil to settle before use.

How to use the water tank

1. Add an appropriate amount of tap water into the water tank.
2. Cover the water tank lid securely and place the tank on the radiator body.
3. During heating, water evaporates from the tank to humidify the air, which helps relieve dryness and makes the room more comfortable.

OPERATING INSTRUCTIONS

WARNING: Do not operate the product until fully assembled (including castors).
WARNING: Operate the product in an upright position only.
1.Place the product upright on a flat, level, stable,and heat-resistant surface.Completely unwind the power cord from the cord storage spool, plug the power cord into a wall outlet.
2.Turn the thermostat control knob clockwise to its maximum setting.
3.Power Selector: Use this knob to set the heat setting:
"LOW" – Low heat setting (600 W)
"MID" – Medium heat setting (900 W)
"HIGH" – High heat setting (1500 W)
4.When the desired ambient temperature is reached, slowly turn the thermostat knob back toward MIN until it clicks. The product will cycle on and off to maintain the setting.
NOTE: The product may emit an odor during first use, which is normal. Ensure adequate ventilation during this period.
5.Turn off the product by rotating the power selector.



CARE AND MAINTENANCE

Always unplug the radiator and allow it to cool down completely before cleaning.
1. Wipe the unit with a soft cloth dampened with a mild soap and water solution.
2. Do not use abrasive cleaners or flammable solvents to clean the unit.
3. After cleaning, ensure the unit is thoroughly dried with a clean cloth or towel.
4. Store the radiator in a cool, dry place. We recommend keeping the unit in its original packaging for protection.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION(S)
Radiator does not power on.	Thermal cut-off has been activated.	Unplug the unit and turn it off. Allow it to cool for at least 30 minutes. Ensure that no objects are placed on or near the radiator. After cooling, plug the unit back in to resume operation.
	The radiator is not plugged into a 120V polarized outlet.	Make sure the unit is in the OFF position. Plug it into a 120V polarized outlet and try turning it on again.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION(S)
Radiator does not power on.	Circuit breaker or fuse has been tripped.	1.Check your electrical panel to ensure the breaker has not tripped or the fuse has not blown. 2.This may occur if the outlet is shared with other high-power appliances. 3.Make sure the unit is in the OFF position, then plug it in and try turning it on again. 4.If the issue persists, try plugging the unit into a different outlet.
Power light is on, but no heat is emitted.	Room temperature has reached the thermostat setting.	Turn the thermostat control knob clockwise to a higher setting to increase the room temperature.
	The heating elements have not yet reached operating temperature.	Allow up to 20 minutes for the oil-filled fins to fully heat after the unit is turned on.
The radiator emits a burning smell.	Combustible materials may be located within 3 feet (0.9 m) of the radiator.	Remove all combustible items from the area surrounding the radiator.
	The castors or castor brackets may not be properly installed.	Refer to the assembly instructions and ensure both front and rear castor brackets (including castors) are securely attached.
The radiator emits a smell or crackling sound.	It is normal for the radiator to produce slight crackling sounds as the oil inside the fins heats up.	Let the radiator run for a while. The sounds should diminish after approximately 15 minutes of operation. This is not a malfunction.

WARRANTY INFORMATION

1. This product is covered by a **one (1) -year** limited warranty against defects in materials and workmanship, valid only for the original purchaser. The warranty period begins on the date of retail purchase and is non-transferable.
2. This warranty does not cover normal wear and tear, or any damage resulting from misuse, negligent use, use with improper voltage or current, failure to follow the operating instructions, or any disassembly, repair, or modification not authorized by our after-sales service.
3. Additionally, this warranty does not cover damages caused by Acts of God (such as fire, flood, hurricanes, or tornadoes) or force majeure events (such as arson, power outages, riots, or vandalism).
4. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state (or province to province). Some states (or provinces) do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.



Technical Support

6269443420 | 6267435564

Other Info

HJ-Customer-Service@outlook.com

Thank you for choosing this product. We strive to provide you with the best quality products and service in the industry. Should you have any issues, please don't hesitate to contact us.