MONSTER®



Monster Soundbase YS03

多功能蓝牙音箱
使用说明书

产品参数

- 产品名称 ---------- Monster Soundbase YS03
- 蓝牙版本 ---------- V5.4
- 传输距离 ---------- ≥10米
- 喇叭规格 ---------- 4Ω 10W (1PCS)
- 频响范围 ---------- 45HZ-20KHZ
- 输入 ---------- 5V⎓1A
- 信噪比 ---------- ≥80dB

包装清单

- 音箱 *1
- 使用说明书 *1
- Type-C充电线 *1

产品示意说明



1.电源开/关
2.下一曲/音量加
3.暂停/播放/接听/ 挂断
4.上一曲/音量减
5.麦克风
6.电量指示灯
7.蓝牙指示灯
8.AUX 接口
9.TF 卡槽
10.Type-C接口
11.USB接口

音箱功能按键说明

按键	功能以及操作
1.电源/关	双击进入TWS配对模式/连接立体声
2.下一曲/音量加	短按加音量;长按下一曲
3.暂停/播放/接听/挂断	短按暂停/播放/接听/挂断;长按来电时拒接
4.上一曲/音量减	短按减音量;长按上一曲
5.麦克风	语音通话功能
6.电量指示灯	显示电量
7.蓝牙指示灯	蓝牙连接成功常亮灯
8.AUX接口	可插入直径3.5mm立体头的音频线外接音源
9.TF卡槽	播放TF卡音乐/语音,最大支持32GB
10.Type-C接口	Type-C充电线充电
11.USB接口	播放U盘音乐/语音,最大支持32GB

接听/挂断/拒接电话

手机与音箱蓝牙连接,有电话进入时,短按"▷"按键,接听电话;在通话中,长按"▷"按键,挂断电话

AUX in / 声卡输入操作使用说明



1.将AUX 3.5mm音频线接入电脑端音频接口,音箱开机后,短按开/关机按键"⏻"切换至声卡模式,模式指示灯蓝灯常亮。3.5mm音频线为非标配配件。

2.将TF卡插入TF卡槽自动切换到读卡模式。

3.将U盘插入USB接口自动切换到USB模式。

注意:声卡模式下,音箱不支持音量同步功能,如需调节音量,可分别调节音箱端及电脑端的音量大小。

注意事项

重要安全说明

阅读并遵循所有说明。

1. 切勿将本产品暴露在液滴或溅洒环境下,也不要在产品、上面放置装有液体的物品(如花瓶);
2. 切勿将无遮盖的火源(如点燃的蜡烛)置于产品上;
3. 应让本产品远离阳光直射,明火或其它热源;
4. 请勿堵塞,拆装,涂改,避免长期置于高温,潮湿环境中使用;
5. 请使用适当音量来欣赏音乐,避免损伤您的听力系统;
6. 在任何音源模式下,必须使用USB音频线连接音箱,得到供电系统方可正常工作;
7. 产品长期不使用时,请断开所有供电电源;
8. 音箱内有电池,请勿自行拆解,以避免触电和意外损坏。

部件名称	有害物质									
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)	邻苯二甲酸二(2-乙基)己酯 (DEHP)	邻苯二甲酸丁基苄酯 (BBBP)	邻苯二甲酸二正丁酯 (DBP)	邻苯二甲酸二异丁酯 (DIBBP)
塑料外壳/组件	0	0	0	0	0	0	0	0	0	0
金属部件	X	0	0	0	0	0	0	0	0	0
麦克风	X	0	0	0	0	0	0	0	0	0
扬声器	X	0	0	0	0	0	0	0	0	0
包装	0	0	0	0	0	0	0	0	0	0

FCC 声明

根据FCC规则第15部分，本设备经过测试，符合B类数字设备的限制。这些限制旨在提供合理的住宅设施中的有害干扰防护。该设备产生使用并可辐射射频能量，如果未按照规定安装和使用说明书可能会对无线电通信造成有害干扰。然而，有不能保证在特定安装中不会发生干扰。如果这个设备有对无线电或电视接收造成有害干扰，可通过转动来确定设备关闭和打开时，鼓励用户尝试通过一个或多个以下更多措施：

--重新定向或重新定位接收天线。
--增加设备和接收器之间的间距。
--将设备连接到与接收器不同的电路上的插座已连接。
--请咨询经销商或经验丰富的无线电/电视技术人员以获得帮助。

此设备符合FCC规则的第15部分。操作受以下两个条件限制条件：

（1） 本装置不得引起有害干扰。
（2）本装置必须接受任何接收到的干扰，包括可能导致意外操作的干扰。未经合规责任方明确批准的变更或修改可能使用用户对设备的操作权限失效。

FCC ID：2ABPV-YS03

Environment Friendly Use Period (EFUP)
环保使用年限

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

这标志标识的期间（10年）是电子电气产品中有害物质在正常使用的条件下不会发生外泄或突变，电子电气产品用户使用此电子电气产品不会对环境造成严重污染或对人身，财产造成严重损害的期限。

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			
产品信息			
产品名称		产品型号	
产品条码/编号/批号			

销售商信息			
名　称			
地　址			
联系电话		邮政编码	
销售日期		发票号码	
备　注			

MONSTER®
合格证
产品编号
生产日期
检 验 员

MONSTER®



Monster Soundbase YS03

Multifunctional Bluetooth speaker
User Manual

Product Parameters

- Product Name ---------- Monster Soundbase YS03
- Bluetoothversion ---------- V5.4
- Wireless range ---------- ≥10m
- Specification ---------- 4Ω 10W (1PCS)
- Frequency Response ---------- 45HZ-20KHZ
- Input ---------- 5V⎓1A
- SNR ---------- ≥80dB

Packing List

- Speaker × 1
- User Manual × 1
- Type-C charging cable × 1

Product Instruction Diagram



1.Power On/Off
2.Next Track / Volume Up
3.Play/Pause/Answer/End Call
4.Previous Track / Volume Down
5.Microphone
6.Battery Indicator Light
7.Bluetooth Indicator Light
8.AUX Port
9.TF Card Slot
10.Type-C Port
11.USB Port

Speaker Function Button Explanation Translation in Chinese

Button	Function & Operation
1. Power	Double-click to enter TWS pairing/stereo mode
2. Next/Vol+	Short press: Volume up; Long press: Next track
3. Play/Pause	Short press: Pause/Play/Answer/Hang up; Long press: Reject calls
4. Prev/Vol-	Short press: Volume down; Long press: Previous track
5. Mic	Voice call
6. Battery Indicator	Battery level display
7. Bluetooth Indicator	Blue light on when connected
8. AUX Port	3.5mm audio input for external sources
9. TF Card Slot	Play TF card music/voice (max 32GB)
10. Type-C Port	Type-C charging
11. USB Port	Play USB music/voice (max 32GB)

Answer / Hang up / Reject a call

When connected to your phone via Bluetooth:
Short press"▷" Answer/End call
Long press"▷" Reject call

AUX In / Sound Card Input Operation Guide



Connect a 3.5mm AUX audio cable to your computer's audio port, power on the speaker, shortpress the power button to switch to sound card mode (blue indicator steady on). Note: 3.5mm audio cable is not included as standard.

2. Insert TF card for card reader mode.

3. Insert USB drive for USB mode.

In Sound Card Mode, the speaker does not supportvolume synchronization. To adjust volume, adjust thevolume levels on both the speaker and the computerseparately.

Precautions

Read and follow all instructions

1. Do not expose the product to dripping or splashing water, or place liquid-filled items (e.g. vases) on it.
2. Do not place unshielded heat sources (e.g., lit candles) on the product.
3. Keep the product away from direct sunlight, open flames, or other heat sources.
4. exposure to rain, water immersion, or use in extremely cold, hot, or humid environments.Avoid.
5. Use moderate volume to prevent hearing damage.
6. Use aUSB cable to connect the speaker to the power supply in all audio modes for normal operation.
7. Disconnect all power when the product is not in use for a long time.
8. Hazardous voltage inside the speaker. Do not disassemble it to avoid electric shock and warranty invalidation.

Name of the Parts	Hazardous Substances									
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)	(DEHP)	(BBBP)	(DBP)	(DIBBP)
Housing	0	0	0	0	0	0	0	0	0	0
Metal Comp	X	0	0	0	0	0	0	0	0	0
Microphone	X	0	0	0	0	0	0	0	0	0
Speaker	X	0	0	0	0	0	0	0	0	0
Packaging	0	0	0	0	0	0	0	0	0	0

FCC Statement

This Equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide Reasonable Protection against Harmful Interference in a residential Installation. This Equipment generates uses and can radiate radio Frequency Energy and, if not installed and used in Accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.
(2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID：2ABPV-YS03

Environment Friendly Use Period (EFUP)

This logo refers to the period (10 years) during which the hazardous substances in electronic and electrical products will not leak or mutate so that the use of these [substances] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User information			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

MONSTER®
Certificate of Approval
Product No:
Production Time:
QC: