80g书纸双面黑白印刷
成品尺寸73x73mm

MODEL: MD-25

Product parameters

The package contains: earphone x2, charging case x1, lanyard x1, Type-C charging cable x1

Earphone parameters
Wireless: V6.0
Transmission distance: ≥10m
Speaker type: Φ10mm 22Ω
Frequency response: 20Hz-20KHz
Battery capacity: 30mAh / 3.7V
Rated input: 5V⎓30mA
Charging time: ≈1 hours
Play music time: ≈4 hours

Charging case parameters
Battery capacity: 200mAh / 3.7V
Rated input: 5V⎓200mA
Standby time: ≈50 hours
(All technical information is subject to actual performance)

Product diagram



① Charging contacts
② Sound hole
③ Touch key
④ Microphone
⑤ Earphone indicator light
⑥ Type-C charging interface
⑦ lanyard hole

Product operation instructions

1. Power on
- Method 1: Open the top cover of the charging case, take out the earphones, and the earphones will automatically power on.
- Method 2: Long press the touch key of the left / right earphone for 3 seconds, and the earphones power on.

2. Power off
- Method 1: Place the earphones back into the charging case . The earphones will automatically power off and begin charging.
- Method 2: Press and hold the touch button on the left/right earphone for 5 seconds to turn off the earphones.

3. Pairing
- After the earphones are power on, the left and right earphones will automatically interconnect, then turn on the BT list of smart devices, search for " G52/G53 " and click connect. After the connection is successful, the voice prompt will sound.

4. Phone call
- Answering a call: When receiving an incoming call, tap the touch button on the left/right earphone.
- Ending a call during a call: Tap the touch button on the left/right earphone.
- Canceling a call: While dialing, tap the touch button on the left/right earphone.
- Rejecting an incoming call: Press and hold the touch button on the left/right earphone for 2 seconds when receiving a call.

5. Voice assistant (Smart device supports voice assistant)
- Activating the voice assistant: Press and hold the touch button on the left/right earphone for 2 seconds, then tap to cancel.

6. Music
- Playing/pausing music: Tap the touch button on the left/right earphone.
- Previous track: Triple-tap the touch button on the left earphone.
- Next track: Triple-tap the touch button on the right earphone.

7. Volume
- Increasing volume: Double-tap the touch button on the right earphone.
- Decreasing volume: Double-tap the touch button on the left earphone.

FCC Warming:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

MODEL: MD-25

产品参数

包装内含耳机x2、充电仓x1、挂绳x1、Type-C充电线x1

耳机参数
蓝牙版本: V6.0
工作距离: ≥10m
扬声器类型: Φ10mm 22 Ω
频率: 20Hz-20KHz
耳机电池: 30mAh / 3.7V
输入: 5V ⎓30mA
充电时间: ≈1小时
音乐播放时间: ≈4小时

充电参数
电池容量: 200mAh / 3.7V
输入: 5V ⎓200mA
待机时间: ≈50小时
(所有参数以实际为准)

产品图示



① 充电触点
② 声孔
③ 触摸键
④ 麦克风
⑤ 耳机指示灯
⑥ Type-C 充电接口
⑦ 挂绳孔

操作方法

1.开机
- 方法1:打开充电仓盖，取出耳机，耳机自动开启。
- 方法2:长按左/右耳机上的触摸键3秒钟，打开耳机。

2.关机
- 方法1：将耳机放回充电仓，耳机自动关机充电。
- 方法2：长按左/右耳机上的触摸键5秒钟，关闭耳机电源。

3.配对
- 当耳机接通电源时，左右耳机将自动连接。 之后，打开智能设备列表，找到G52/G53，然后单击"连接"。如果连接成功，将显示语音消息。

4.电话
- 接电话:收到来电时：单击左/右耳机的触摸按钮。
- 打电话的时候挂断电话： 单击左/右耳机的触摸按钮。
- 取消拨号：拨号时，单击左/右耳机的触摸键。
- 拒绝接电话：收到来电时长按左/右耳机的触摸键2秒钟。

5.语音助手(智能设备支持语音助手)。
- 打开语音助手：长按左/右耳机的触摸键2秒钟，单击取消。

6.音乐
- 播放/暂停音乐：单击左/右耳机上的触摸按钮。
- 上一首：三击左耳机的触摸键。
- 下一首：三击右耳机的触摸键。

7.音量
- 提高音量：双击右耳机的触摸键。
- 降低音量：双击左耳机的触摸键。

Producer:Shenzhen Medi Haley TechnologyCo.,Ltd
Address:Gonghe Industrial Zone,Xixiang Street,
Bao'an District,Shenzhen
Service Number:400-607-8699
Made in China