PANTONE®
285 C

AGBFPL36025918
onn Glasses Black 01
100% UV-protected polarized lenses

140 mm

QUICK START GUIDE

onn Smart Glasses



WL12

CONTENT & INFORMATION

CONTENT & INFORMATION 1
Features 1
DEVICE OVERVIEW 2
WHAT'S INCLUDED 4
CHARGING 5
SAFETY INSTRUCTIONS .. 7
REGULATORY NOTICES .. 8
OPERATION 9
Power On/Off 9
Pairing 10
Unpairing 11
Reset Pairing 11
Volume 12
Music 12
Calls 13
Voice Assistant 13
TROUBLESHOOTING 14
FCC COMPLIANCE 14

Features

1. 100% UV-protected polarized lenses.
2. Open-ear audio.
3. Hands-free calling.
4. Bluetooth® wireless connection.
5. Up to 6 hours of playtime.
6. USB-C magnetic charging.
7. On-frame button controls.
8. IPX4 water- and sweat-resistant.

DEVICE OVERVIEW

(Figures 1)



FRONT VIEW

(Figures 2)



BACK VIEW

(Figures 3)



USB-C TO DUAL MAGNETIC CHARGING CABLE

Figures 1-2:
Front, Right Temple, Left Temple.
A - Power/Multifunction Button.
RB - Right Functional Button.
LB - Left Functional Button.
1 - Microphones and LED Indicators.
2 - Magnetic Gold-plated Charging Contacts.
3 - Speakers.

WHAT'S INCLUDED

(Figures 4)



CHARGING

Before first use, fully **charge both temples**.

(Figures 5)



1. Attach one Magnetic Connector to the Gold-plated Charging Contacts on each temple.

2. Connect the USB-C plug to a compatible 5V/1A USB power adapter.

(Figures 6)



Auto power OFF during charging. Power ON **manually** after charging.

LED Indicators

(Figures 7)



Charging: **Red** light ON.

(Figures 8)



Fully charged: **Green** light ON.

SAFETY INSTRUCTIONS

⚠ Warning

- Do not repair or modify the product.
- Do not use if the product is damaged.
- Keep away from water, fire and excessive heat.
- Use only the supplied USB-C magnetic charging cable.
- Do not look directly at the sun.

Battery
Charge: 0°C to 50°C.
Operate: −15°C to 55°C.

Cleaning
Clean with a microfiber cloth. Keep charging contacts dry. Do not use alcohol, solvents, abrasives, or compressed air.

Privacy
Bluetooth audio only. No personal data is stored or uploaded.

Disposal
Dispose of according to local e-waste regulations.

REGULATORY NOTICES

⚠ Warning

This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to: **www.P65Warnings.ca.gov**

Impact Resistance: This product complies with the impact resistance requirements of **21 CFR 801.410.**

40 mm

360 mm

140 mm

For product assistance
WE CAN HELP
1-888-516-2630
7 DAYS/WEEK
7:00am-9:00pm CST

THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.

Please read and keep for future reference.

Find more at **Walmart.com**

Manufactured in China for: Walmart Inc.

OPERATION

Control Guide

(Table 1)

Control	Action	Control	Action
	Single press		Double press
	Press and hold		

Power On/Off

Power On

Press and hold **Button A** on **each** temple for 3 sec. Both temples will automatically pair.

(Figures 9)



Power Off

Press and hold **Button A** on **either** temple for 5 sec.

(Figures 10)



If the glasses are not connected to a device within 3 min, both temples will automatically Power OFF.

Pairing

(Figures 11)



1. Power ON both temples.
2. Enable Bluetooth on your smartphone.
3. Select the Bluetooth device name "**onn Glasses Black 01**".
4. A confirmation tone indicates successful pairing.

Unpairing

Remove the Bluetooth connection from your smartphone.

1. Open the Bluetooth settings on your smartphone.
2. Select the connected "**onn Glasses Black 01**" device.
3. Select "Forget This Device" or "Unpair".
4. Pairing mode starts automatically. Powers off after 3 minutes if not paired.

Reset Pairing

Use this if the glasses cannot connect or pairing problems occur.

1. Power ON both temples.
2. If connected, disconnect the glasses from Bluetooth.
3. Press **Button A** 5 times on either temple.
4. Pair the glasses again.

If only one temple resets, repeat Step 3 on the other temple.

Volume

Press once **Left Button / Right Button** for Volume - / +.

(Figures 12)



Music

Play / Pause

Press once **Button A** on **either** temple.

(Figures 13)



Previous / Next Track

Press and hold **Left Button / Right Button** for Previous / Next track.

(Figures 14)



Calls

Answer / End a Call

Press once **Button A** on **either** temple.

(Figures 15)



Reject

Press and Hold 1 sec **Button A** on **either** temple.

(Figures 16)



Voice Assistant

Siri / Google Assistant

Press 2 times **Button A** on **either** temple.

(Figures 17)



TROUBLE-SHOOTING

(Table 2)

Problem	Solution
Cannot power ON	Charge for 10-15 minutes, then press and hold Buttons A on both Left and Right Temples for 3 seconds.
Cannot pair	Enable Bluetooth, delete previous pairing, then reconnect.
Poor audio quality	Keep the phone within Bluetooth range and remove sources of interference.
Connection issues	Turn ON both temples, disconnect Bluetooth, then reset pairing and reconnect.
Charging does not start	Check that both magnetic connectors are attached correctly and the USB-C cable is connected.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement: This device complies with FCC RF exposure requirements for portable use.

⚠ Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate t his equipment.

FC

FCC ID: 2BUHE-WEILAN12

40 mm

360 mm

140 mm

Cut line
Fold line
Copy safe area
Outside bleed (3mm)

PANTONE®
285 C

AGBGBL36025918
onn Glasses Black 02
Filters up to 22% of high-energy blue light

140 mm

QUICK START GUIDE

onn Smart Glasses



WL12

CONTENT & INFORMATION

CONTENT & INFORMATION 1
Features 1
DEVICE OVERVIEW 2
WHAT'S INCLUDED 4
CHARGING 5
SAFETY INSTRUCTIONS ..7
REGULATORY NOTICES .. 8
OPERATION 9
Power On/Off..... 9
Pairing 10
Unpairing 11
Reset Pairing.....11
Volume.....12
Music.....12
Calls 13
Voice Assistant 13
TROUBLESHOOTING 14
FCC COMPLIANCE 14

Features

1. Filters up to 22% of high-energy blue light.
2. Open-ear audio.
3. Hands-free calling.
4. Bluetooth® wireless connection.
5. Up to 6 hours of playtime.
6. USB-C magnetic charging.
7. On-frame button controls.
8. IPX4 water- and sweat-resistant.

DEVICE OVERVIEW

(Figures 1)



FRONT VIEW

(Figures 2)



BACK VIEW

(Figures 3)



USB-C TO DUAL MAGNETIC CHARGING CABLE

Figures 1-2:
Front, Right Temple, Left Temple.
A - Power/Multifunction Button.
RB - Right Functional Button.
LB - Left Functional Button.
1 - Microphones and LED Indicators.
2 - Magnetic Gold-plated Charging Contacts.
3 - Speakers.

WHAT'S INCLUDED

(Figures 4)



CHARGING

Before first use, fully **charge both temples**.

(Figures 5)



1. Attach one Magnetic Connector to the Gold-plated Charging Contacts on each temple.

2. Connect the USB-C plug to a compatible 5V/1A USB power adapter.

(Figures 6)



Auto power OFF during charging. Power ON **manually** after charging.

LED Indicators

(Figures 7)



Charging: **Red** light ON.

(Figures 8)



Fully charged: **Green** light ON.

SAFETY INSTRUCTIONS

⚠ Warning

- Do not repair or modify the product.
- Do not use if the product is damaged.
- Keep away from water, fire and excessive heat.
- Use only the supplied USB-C magnetic charging cable.
- Do not look directly at the sun.

Battery
Charge: 0°C to 50°C.
Operate: −15°C to 55°C.

Cleaning
Clean with a microfiber cloth. Keep charging contacts dry. Do not use alcohol, solvents, abrasives, or compressed air.

Privacy
Bluetooth audio only. No personal data is stored or uploaded.

Disposal
Dispose of according to local e-waste regulations.

REGULATORY NOTICES

⚠ Warning

This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to: **www.P65Warnings.ca.gov**

Impact Resistance: This product complies with the impact resistance requirements of **21 CFR 801.410.**

40 mm

360 mm

140 mm

For product assistance
WE CAN HELP
1-888-516-2630
7 DAYS/WEEK
7:00am-9:00pm CST

THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.

Please read and keep for future reference.

Find more at **Walmart.com**

Manufactured in China for: Walmart Inc.

OPERATION

Control Guide

(Table 1)

Control	Action	Control	Action
	Single press		Double press
	Press and hold		

Power On/Off

Power On

Press and hold **Button A** on **each** temple for 3 sec. Both temples will automatically pair.

(Figures 9)



Power Off

Press and hold **Button A** on **either** temple for 5 sec.

(Figures 10)



If the glasses are not connected to a device within 3 min, both temples will automatically Power OFF.

Pairing

(Figures 11)



1. Power ON both temples.
2. Enable Bluetooth on your smartphone.
3. Select the Bluetooth device name "**onn Glasses Black 02**".
4. A confirmation tone indicates successful pairing.

Unpairing

Remove the Bluetooth connection from your smartphone.

1. Open the Bluetooth settings on your smartphone.
2. Select the connected "**onn Glasses Black 02**" device.
3. Select "Forget This Device" or "Unpair".
4. Pairing mode starts automatically. Powers off after 3 minutes if not paired.

Reset Pairing

Use this if the glasses cannot connect or pairing problems occur.

1. Power ON both temples.
2. If connected, disconnect the glasses from Bluetooth.
3. Press **Button A** 5 times on either temple.
4. Pair the glasses again.

If only one temple resets, repeat Step 3 on the other temple.

Volume

Press once **Left Button / Right Button** for Volume - / +.

(Figures 12)



Music

Play / Pause

Press once **Button A** on **either** temple.

(Figures 13)



Previous / Next Track

Press and hold **Left Button / Right Button** for Previous / Next track.

(Figures 14)



Calls

Answer / End a Call

Press once **Button A** on **either** temple.

(Figures 15)



Reject

Press and Hold 1 sec **Button A** on **either** temple.

(Figures 16)



Voice Assistant

Siri / Google Assistant

Press 2 times **Button A** on **either** temple.

(Figures 17)



TROUBLE-SHOOTING

(Table 2)

Problem	Solution
Cannot power ON	Charge for 10-15 minutes, then press and hold Buttons A on both Left and Right Temples for 3 seconds.
Cannot pair	Enable Bluetooth, delete previous pairing, then reconnect.
Poor audio quality	Keep the phone within Bluetooth range and remove sources of interference.
Connec-tion issues	Turn ON both temples, disconnect Bluetooth, then reset pairing and reconnect.
Charging does not start	Check that both magnetic connectors are attached correctly and the USB-C cable is connected.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement: This device complies with FCC RF exposure requirements for portable use.

⚠ Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate t his equipment.

FC

FCC ID: 2BUHE-WEILAN12

360 mm

Cut line
Fold line
Copy safe area
Outside bleed (3mm)

PANTONE®
285 C

AGBMPL36025918
onn Glasses Black 03
100% UV-protected polarized lenses

140 mm

40 mm

360 mm

QUICK START GUIDE

onn Smart Glasses



WL12

CONTENT & INFORMATION

CONTENT & INFORMATION 1
Features 1
DEVICE OVERVIEW 2
WHAT'S INCLUDED 4
CHARGING 5
SAFETY INSTRUCTIONS ..7
REGULATORY NOTICES .. 8
OPERATION 9
Power On/Off..... 9
Pairing 10
Unpairing 11
Reset Pairing.....11
Volume.....12
Music.....12
Calls 13
Voice Assistant 13
TROUBLESHOOTING 14
FCC COMPLIANCE 14

Features

1. 100% UV-protected polarized lenses.
2. Open-ear audio.
3. Hands-free calling.
4. Bluetooth® wireless connection.
5. Up to 6 hours of playtime.
6. USB-C magnetic charging.
7. On-frame button controls.
8. IPX4 water- and sweat-resistant.

DEVICE OVERVIEW

(Figures 1)



FRONT VIEW

(Figures 2)



BACK VIEW

(Figures 3)



USB-C TO DUAL MAGNETIC CHARGING CABLE

Figures 1-2:
Front, Right Temple, Left Temple.
A - Power/Multifunction Button.
RB - Right Functional Button.
LB - Left Functional Button.
1 - Microphones and LED Indicators.
2 - Magnetic Gold-plated Charging Contacts.
3 - Speakers.

WHAT'S INCLUDED

(Figures 4)



CHARGING

Before first use, fully **charge both temples**.

(Figures 5)



1. Attach one Magnetic Connector to the Gold-plated Charging Contacts on each temple.

2. Connect the USB-C plug to a compatible 5V/1A USB power adapter.

(Figures 6)



Auto power OFF during charging. Power ON **manually** after charging.

LED Indicators

(Figures 7)

Charging: **Red** light ON.

(Figures 8)



Fully charged: **Green** light ON.

SAFETY INSTRUCTIONS

⚠ Warning

- Do not repair or modify the product.
- Do not use if the product is damaged.
- Keep away from water, fire and excessive heat.
- Use only the supplied USB-C magnetic charging cable.
- Do not look directly at the sun.

Battery
Charge: 0°C to 50°C.
Operate: −15°C to 55°C.

Cleaning
Clean with a microfiber cloth. Keep charging contacts dry. Do not use alcohol, solvents, abrasives, or compressed air.

Privacy
Bluetooth audio only. No personal data is stored or uploaded.

Disposal
Dispose of according to local e-waste regulations.

REGULATORY NOTICES

⚠ Warning

This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to: **www.P65Warnings.ca.gov**

Impact Resistance: This product complies with the impact resistance requirements of **21 CFR 801.410.**

140 mm

For product assistance
WE CAN HELP
1-888-516-2630
7 DAYS/WEEK
7:00am-9:00pm CST

THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.

Please read and keep for future reference.

Find more at **Walmart.com**

Manufactured in China for: Walmart Inc.

OPERATION

Control Guide

(Table 1)

Control	Action	Control	Action
	Single press		Double press
	Press and hold		

Power On/Off

Power On

Press and hold **Button A** on **each** temple for 3 sec. Both temples will automatically pair.

(Figures 9)



Power Off

Press and hold **Button A** on **either** temple for 5 sec.

(Figures 10)



If the glasses are not connected to a device within 3 min, both temples will automatically Power OFF.

Pairing

(Figures 11)



1. Power ON both temples.
2. Enable Bluetooth on your smartphone.
3. Select the Bluetooth device name "**onn Glasses Black 03**".
4. A confirmation tone indicates successful pairing.

Unpairing

Remove the Bluetooth connection from your smartphone.

1. Open the Bluetooth settings on your smartphone.
2. Select the connected "**onn Glasses Black 03**" device.
3. Select "Forget This Device" or "Unpair".
4. Pairing mode starts automatically. Powers off after 3 minutes if not paired.

Reset Pairing

Use this if the glasses cannot connect or pairing problems occur.

1. Power ON both temples.
2. If connected, disconnect the glasses from Bluetooth.
3. Press **Button A** 5 times on either temple.
4. Pair the glasses again.

If only one temple resets, repeat Step 3 on the other temple.

Volume

Press once **Left Button / Right Button** for Volume - / +.

(Figures 12)



Music

Play / Pause

Press once **Button A** on **either** temple.

(Figures 13)



Previous / Next Track

Press and hold **Left Button / Right Button** for Previous / Next track.

(Figures 14)



Calls

Answer / End a Call

Press once **Button A** on **either** temple.

(Figures 15)



Reject

Press and Hold 1 sec **Button A** on **either** temple.

(Figures 16)



Voice Assistant

Siri / Google Assistant

Press 2 times **Button A** on **either** temple.

(Figures 17)



TROUBLE-SHOOTING

(Table 2)

Problem	Solution
Cannot power ON	Charge for 10-15 minutes, then press and hold Buttons A on both Left and Right Temples for 3 seconds.
Cannot pair	Enable Bluetooth, delete previous pairing, then reconnect.
Poor audio quality	Keep the phone within Bluetooth range and remove sources of interference.
Connec-tion issues	Turn ON both temples, disconnect Bluetooth, then reset pairing and reconnect.
Charging does not start	Check that both magnetic connectors are attached correctly and the USB-C cable is connected.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement: This device complies with FCC RF exposure requirements for portable use.

⚠ Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate t his equipment.

FC

FCC ID: 2BUHE-WEILAN12

140 mm

360 mm

Cut line
Fold line
Copy safe area
Outside bleed (3mm)

PANTONE®
285 C

AGTFPL36025918
onn Glasses Tortoise
Filters up to 22% of high-energy blue light

140 mm

40 mm

360 mm

onn

QUICK START GUIDE

onn Smart Glasses



WL12

CONTENT & INFORMATION

CONTENT & INFORMATION 1
Features 1
DEVICE OVERVIEW 2
WHAT'S INCLUDED 4
CHARGING 5
SAFETY INSTRUCTIONS ..7
REGULATORY NOTICES .. 8
OPERATION 9
Power On/Off..... 9
Pairing 10
Unpairing 11
Reset Pairing.....11
Volume.....12
Music.....12
Calls 13
Voice Assistant 13
TROUBLESHOOTING 14
FCC COMPLIANCE 14

Features

1. Filters up to 22% of high-energy blue light.
2. Open-ear audio.
3. Hands-free calling.
4. Bluetooth® wireless connection.
5. Up to 6 hours of playtime.
6. USB-C magnetic charging.
7. On-frame button controls.
8. IPX4 water- and sweat-resistant.

DEVICE OVERVIEW

(Figures 1)



FRONT VIEW

(Figures 2)



BACK VIEW

(Figures 3)



USB-C TO DUAL MAGNETIC CHARGING CABLE

Figures 1-2:
Front, Right Temple, Left Temple.
A - Power/Multifunction Button.
RB - Right Functional Button.
LB - Left Functional Button.
1 - Microphones and LED Indicators.
2 - Magnetic Gold-plated Charging Contacts.
3 - Speakers.

WHAT'S INCLUDED

(Figures 4)



CHARGING

Before first use, fully **charge both temples**.

(Figures 5)



1. Attach one Magnetic Connector to the Gold-plated Charging Contacts on each temple.

2. Connect the USB-C plug to a compatible 5V/1A USB power adapter.

(Figures 6)



Auto power OFF during charging. Power ON **manually** after charging.

LED Indicators

(Figures 7)



Charging: **Red** light ON.

(Figures 8)



Fully charged: **Green** light ON.

SAFETY INSTRUCTIONS

⚠ Warning

- Do not repair or modify the product.
- Do not use if the product is damaged.
- Keep away from water, fire and excessive heat.
- Use only the supplied USB-C magnetic charging cable.
- Do not look directly at the sun.

Battery
Charge: 0°C to 50°C.
Operate: −15°C to 55°C.

Cleaning
Clean with a microfiber cloth. Keep charging contacts dry. Do not use alcohol, solvents, abrasives, or compressed air.

Privacy
Bluetooth audio only. No personal data is stored or uploaded.

Disposal
Dispose of according to local e-waste regulations.

REGULATORY NOTICES

⚠ Warning

This product can expose you to chemicals including Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to: **www.P65Warnings.ca.gov**

Impact Resistance: This product complies with the impact resistance requirements of **21 CFR 801.410.**

OPERATION

Control Guide

(Table 1)

Control	Action	Control	Action
	Single press		Double press
	Press and hold		

Power On/Off

Power On

Press and hold **Button A** on **each** temple for 3 sec. Both temples will automatically pair.

(Figures 9)



Power Off

Press and hold **Button A** on **either** temple for 5 sec.

(Figures 10)



If the glasses are not connected to a device within 3 min, both temples will automatically Power OFF.

Pairing

(Figures 11)



1. Power ON both temples.
2. Enable Bluetooth on your smartphone.
3. Select the Bluetooth device name "**onn Glasses Tortoise**".
4. A confirmation tone indicates successful pairing.

Unpairing

Remove the Bluetooth connection from your smartphone.

1. Open the Bluetooth settings on your smartphone.
2. Select the connected "**onn Glasses Tortoise**" device.
3. Select "Forget This Device" or "Unpair".
4. Pairing mode starts automatically. Powers off after 3 minutes if not paired.

Reset Pairing

Use this if the glasses cannot connect or pairing problems occur.

1. Power ON both temples.
2. If connected, disconnect the glasses from Bluetooth.
3. Press **Button A** 5 times on either temple.
4. Pair the glasses again.

If only one temple resets, repeat Step 3 on the other temple.

Volume

Press once **Left Button / Right Button** for Volume - / +.

(Figures 12)



Music

Play / Pause

Press once **Button A** on **either** temple.

(Figures 13)



Previous / Next Track

Press and hold **Left Button / Right Button** for Previous / Next track.

(Figures 14)



Calls

Answer / End a Call

Press once **Button A** on **either** temple.

(Figures 15)



Reject

Press and Hold 1 sec **Button A** on **either** temple.

(Figures 16)



Voice Assistant

Siri / Google Assistant

Press 2 times **Button A** on **either** temple.

(Figures 17)



TROUBLE-SHOOTING

(Table 2)

Problem	Solution
Cannot power ON	Charge for 10-15 minutes, then press and hold Buttons A on both Left and Right Temples for 3 seconds.
Cannot pair	Enable Bluetooth, delete previous pairing, then reconnect.
Poor audio quality	Keep the phone within Bluetooth range and remove sources of interference.
Connec-tion issues	Turn ON both temples, disconnect Bluetooth, then reset pairing and reconnect.
Charging does not start	Check that both magnetic connectors are attached correctly and the USB-C cable is connected.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement: This device complies with FCC RF exposure requirements for portable use.

⚠ Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate t his equipment.

FC

FCC ID: 2BUHE-WEILAN12

For product assistance
WE CAN HELP
1-888-516-2630
7 DAYS/WEEK
7:00am-9:00pm CST

THIS GUIDE CONTAINS IMPORTANT SAFETY INFORMATION.

Please read and keep for future reference.

Find more at **Walmart.com**

Manufactured in China for: Walmart Inc.

Cut line
Fold line
Copy safe area
Outside bleed (3mm)