Aircillin

DESKTOP AIR PURIFIER

AP0801



User Manual

❖ Customer support

Thank you so much for purchasing our Aircillin air purifier. Please study this manual carefully to familiarize yourself with the features and functions of your Aircillin air purifier. Inside you will find many helpful hints on how to use and maintain your Aircillin air purifier properly.

If you encounter any issues or have any questions regarding your new product, feel free to contact our helpful Customer Support Team. Your satisfaction is our goal!

LIVE CHAT SUPPORT

Scan QR Code & Start Chatting



PLEASE READ AND SAVE THESE INSTRUCTIONS

When using an electrical appliance, basic safety precautions should always be taken to re duce the risk of fire, electric shock, and/or injury, including the following:

1. READ ALL INSTRUCTIONS BEFORE USE.
2. To reduce the risk of shock, always unplug the air purifier from the electrical outlet im mediately after using as well as before replacing or removing any filters.
3. The air purifier should always be placed on a flat, secure surface.
4. The cord should be kept away from any heated surfaces.
5. Never place or store the air purifier where it could fall or be pulled into a sink or bathtub.
6. Do not reach for the air purifier if it has fallen into water. Unplug the appliance immediately.
7. Do not place in or drop into water or liquid.
8. Do not place anything on top of unit.
9. Always keep the air purifier dry and do not operate in wet or moist conditions like bath rooms, laundry areas or similar moist indoor places.
10. Always unplug the air purifier when not in use.
11. Check your air purifier cord and plug connections. A faulty wall outlet or loose plug can cause the outlet or plug to overheat. Make sure the plug fits tightly in outlet.
12. Do not run power cord under carpeting, runners or similar type floor coverings.
13. Do not use this product outdoors.

14. Do not block air intakes or exhaust in any manner. Do not use on any soft surface, like a couch or bed, where the openings may become blocked.
15. Do not tilt or move the air purifier while the unit is powered on. Make sure the power is off and remove the plug from the outlet before moving.
16. Use this air purifier only for its intended use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or serious injury to a person.
17. Press the power button to turn off the air purifier prior to removing plug from outlet.
18. Children aged 8 and over, as well as persons with reduced physical, sensory or mental abilities or who lack experience and knowledge, may use the device if they are supervised or instructed in the safe use of the device and are aware of the risks involved. Children sho uld not play with this instrument as a toy.
19. The device is not to be operated by any supply sources other than Information and Com munication Technology Equipment or A Class 2 Power Unit.
20. Unplug or disconnect the appliance from the power supply before servicing
21. WARNING: To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Soid–State Speed Control Device
22. WARNING: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do NotUse Replacement Parts That Have Not Been Recommended By The Manu–facturer (e.g. Parts Made At Home Using A 3D Printer)

WARNING
Important safety instructions

Read all instructions before using this air purifier.
When using an electrical appliance, basic precautions should always be followed, including the following:

- Make sure the air purifier is plugged into a live 120V AC outlet.
- Always turn off and unplug the air purifier when not in use.
- Disconnect the power supply from your air purifier by unplugging the power cable before replacing filters and before cleaning and before servicing.
- Do not use attachments or filters not recommended by Aircillin.
- Do not use the air purifier outdoors.
- Do not attempt to remove any part of the unit except the filters.
- Do not attempt to repair the air purifier.
- Do not attempt to plug in the machine when your hands are wet.
- Do not soak the purifier in water or splash water on it.
- Do not operate the air purifier near an open flame.
- Do not obstruct the air inlet and air outlet of the air purifier.
- Save these instructions for future reference.

❖ Packing List

Unpack your Aircillin purifier follows

1.Remove the Aircillin purifier from the packaging.

2.Check the components received against your packing slip to make sure you have all the parts.

3.Check the unit and all the components for damage. If the unit or any of the components show damage from shipping, contact Airtok Technology Inc. (www.airtok.com).



Host
(1PCS)



Aroma Pads
(12 PACK)



Filter
(1 PCS)
(loaded into the host)



Adapter
(1PCS)
(Put into the filter)



Manual
(1 PCS)

※ Product images are for reference only and may differ from the actual product

Packing list



Operating guide



❖ Introduction to quick start usage scenarios

When to replace filter

The filter life depends on the actual working environment. In the normal service environment, the filter life is 1,000 hours. After about 900 hours (90% of rated lifecycle) of cumulative operation, the Filter Replacement light will flash to Filter Replacement remind you to purchase and replace the used filter. Replace it with a new one, then press and hold the Filter Replacement button for 3 seconds. And the Filter Replacement light goes out as the buzzer makes a beep



Filter Replacement

What to do if the air is dirty

Turn on the machine and press the fan speed button to adjust the fan speed.



❖ Introduction to quick start usage scenarios

How to use child lock

In the power–on state, Press the “Child Lock” button, the child lock indicator light is on, and the child lock function is enabled; Press the child lock, the indicator light of the child lock goes out, and the child lock function is cancelled.



Child lock

Display light

Press the Display light button once and the Display light goes out. You can also turn off the Display light when it’s time for bed.



Display lights

Timer switch

Timing power–off method: in the power–on state, press the “2H”, “4H” or “8H” button, you can set power–off time of 2, 4 or 8 hours from the set time.



2 hours



4 hours



8 hours

❖ Where is the power adapter

The adapter is inside the machine. Please take it out according to the following steps.

1



Place the machine with the bottom facing up, Unlock the bottom cover by turning it counterclockwise

2



Separate the bottom cover from the machine

3



Take the power adapter package out of the machine

4



Take the power adapter out of the package

5



Close the bottom cover of the machine and turn the cover clockwise to lock

6



Place the machine bottom down and plug into the power adapter

How to replace filter

After about 1,350 hours (90% of rated lifecycle of filter) of cumulative operation, the Filter Replacement indicator will flash to to remind you to replace the used filter as a new one.

1



Place the machine with the bottom facing up, Unlock the bottom cover by turning it counterclockwise

2



Separate the bottom cover from the machine, Remove the old filter

3



Remove the packaging bag of the new filter

4



Install the new filter

5



Close the bottom cover of the machine and turn the cover clockwise to lock

6



After switching on the power, press and hold the filter replacement button for 3 seconds, and when you hear the beep, the installation is successful.

How to add essential oil

When the aroma pads does not have fragrance, you need to drop the essential oil into the aroma pads.

1



Press the "PUSH" button on the aromatherapy pad cover

2



Wait for the aromatherapy lid to pop off and pick up the

3



Drop essential oil into the new aroma pad

4



Put the aromatherapy cap back on.

How to handle aroma pads

New aroma pads does not have fragrance, you need to drop the essential oil into the aroma pads.

1



Press the "PUSH" button on the aromatherapy pad cover

2



Wait for the aromatherapy lid to pop off and pick up the

3



Take the new aroma pads out from the aroma pad package

4



Put the new aroma pads into the machine

5



Drop essential oil into the new aroma pad

6



Put the aromatherapy cap back on.

Product specification

Input Voltage (Adapter)	AC100–240V / 50–60Hz
Rated Voltage	DC12V,1A
Rated Power	12 W
CADR	53 CFM / 90 m^3/h
Operating Conditions	Temperature: 14˚F—104˚F / –10˚C—40˚C Humidity: ⩽ 85% RH
Noise Level	25–50 dB
Product Net Weight	2.2 lb / 1 kg
Product Size	7.9x7.9x12.6 inch / 175x175x255 mm

When to replace filter

- Your product is guaranteed by us for 12 months from your original date of purchase. If you want to extend your warranty for one more year, please do not hesitate to contact us.

- Become a AIRTOK member to get the information about the replacement filter and the latest products. (AIRTOK reserved the right of final explanation).

Share your stars

Leave a product review and help others out by sharing your experience.

❖ Troubleshooting and solutions

Problem	Check items	Solution
The air purifierdoes not turn on	Whether the socket has power	Power on
	Whether the plug is loose from the socket	Connect the power
When the purification function is turned on, the sound is dull and the wind is small	Whether the air outlet is covered	Turn off the purifier andremove the covering
There is a peculiar smell at the air outlet	Whether there is a large amount of peculiar smell near the air inlet that continues to release	After removing the odor and using the purifier to run for a period of time, the odor will gradually disappear
	Whether the filter has reached the replacement time	Replace the filter

◆ The product may have a slight peculiar smell during the initial period of use, which is a normal phenomenon.

Aircillin

www.airtok.com

support@airtok.com

Airtok Lifestyle