SAFETY PRECAUTIONS

- Do not disassemble, puncture, or crush the product. No user-serviceable parts inside.
- Do not expose to fire, high temperatures, or direct sunlight for extended periods.
- Do not immerse in water or other liquids. This product is not waterproof. If liquid enters, disconnect power immediately and stop using.
- Use only certified chargers and cables. Uncertified adapters may cause damage, overheating, or fire.
- Keep away from pacemakers and other medical devices. Wireless charging may interfere with medical electronics. Consult your doctor before use if you have a pacemaker or implanted device.
- Do not place metal objects (keys, coins, paper clips) on the wireless charging pad — they may cause overheating.
- Keep credit cards and magnetic-stripe cards away from the charging area — may demagnetize.
- Use in well-ventilated areas. Do not cover the product with blankets, pillows, or other insulating materials while charging.
- Stop using immediately if you notice swelling, leakage, unusual odor, or excessive heat.
- Keep out of reach of children.
- Do not drop the product or subject it to strong physical impact.
- Unplug the charger during lightning storms or when not in use for extended periods.WARNING: This product contains electronic components. Improper use may result in fire, electric shock, or injury.

- **Note:** The supplied manual artwork jumps from Section 4 to Section 6; there is no Section 5 visible in the image.

HOW TO USE:



(the LED indicator lights are hidden inside the charging port)

1. Connect the adapter to the charging cable, then connect it to the wireless charger. The red and blue lights will flash briefly, after which the red light will remain on, indicating that the charger is powered on but not charging.



2. Place a Qi-compatible device (such as a mobile phone) in the center of the wireless charger. The charger will begin charging the device, and the red light will turn off while the blue light stays on.

3. When you remove the phone from the wireless charger, the blue light will turn off and the red light will turn on.

4. If you place a device without wireless charging capability (e.g., an iPhone 7 Plus) or a metal object like a coin on the wireless charger, the red and blue lights will flash to indicate Foreign Object Detection (FOD).

TROUBLESHOOTING

IPhone not charging: Ensure the phone is centered on the charging pad. Remove thick or metal phone cases. Confirm the tray is connected to power. Try a different wall charger or cable.

Charging is slow: Use an 18W or higher USB-C PD/QC wall charger. Ensure the phone is properly aligned. Remove metal objects or cards between the phone and pad.

Intermittent charging: Check phone alignment on the pad. Ensure the cable is fully inserted at both ends. Try a different power outlet.

Product gets warm: Slight warming during wireless charging is normal. If uncomfortably hot, remove the phone and disconnect power. Ensure no metal objects are on the charging pad.

No power at all: Check the wall charger is working. Ensure the cable is fully inserted. Try a different cable and wall charger. Try a different power outlet.
Phone charges then stops: This may be normal if the phone reaches 100%. If it stops early, reposition the phone. Ensure no foreign objects are between the phone and pad.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a wireless power charger, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment o and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

PRODUCT SPECIFICATIONS



Wireless Output: Max 15W (compatible with 10W, 7.5W, 5W)

Input: DC 5V/2A, 9V/2A (Type-C)

Operating Temperature: 0°C ~ 45°C
Storage Temperature: -10°C ~ 60°C

Package Includes:
(1) iHome Wireless Charging Valet Tray
(1) USB-C® to USB-C® Charging Cable
(1) User Manual

2026 © Lifeworks Technology Group LLC. New York, NY 10018
iHome® is a registered trademark of SDI Technologies Inc., used under license. iPhone® is a trademark of Apple Inc., registered in the U.S. and other countries. All other brands and logos are trademarks of their respective companies. *Actual products may differ slightly from Images. **MADE IN CHINA**

California Proposition 65 Warning:

WARNING: Cancer and Reproductive Harm – www.P65Warnings.ca.gov

iHome

2IHQI1034

WIRELESS CHARGING LINEN VALET TRAY

15 WATTS | FAST CHARGING

SUPPORT: 877 543 3540



FRONT