VEHICLE BATTERY INSTALLATION



Use 4X1.5V "AA" batteries
(Not included)

1.Turn the power switch to OFF.
2.Open the battery compartment on the underside of the vehicle using a screwdriver.
3.Insert 4 × 1.5V AA batteries according to the polarity markings. (Batteries not included)
4.Close the battery cover and tighten the screw

CONTROLLER BATTERY INSTALLATION



Uses 2X1.5V "AA" Size batteries
(Not included)

1. Open the battery compartment on the back of the controller using a screwdriver.
2. Insert 2 × 1.5V AA batteries following the polarity markings. (Batteries not included)
3. Replace the battery cover and tighten the screw securely.

CONTROLLER FUNCTIONS



Forward – Push the left control stick forward
Backward – Pull the left control stick backward
Turn Left – Push the right control stick left
Turn Right – Push the right control stick right

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

The packaging must be retained since it contains important information.

IMPORTANT: Keep these instructions. DO NOT DISCARD.
Caution:
Please read these carefully before using:
1. Only adults should install and replace batteries.
2. Rechargeable batteries are only to be charged under adult supervision
3. Rechargeable batteries are to be removed from the toy before being charged.
4. Non-rechargeable batteries are not to be recharged.
5. If the device is not used for a long time, remove the batteries.
6. Do not mix old and new batteries.
7. Do not mix alkaline, standard (carbon zinc) or rechargeable batteries.
8. Exhausted batteries are to be removed from the toy.
9. The supply terminals are not to be short-circuited.
10. Only batteries of the same or equivalent type as recommended are to be used.
11. Batteries are to be inserted with the correct polarity.
12. Do not dispose of batteries in fire, batteries may explode or leak.
13. Batteries may explode or leak if misused.

MADE IN CHINA
©2026 Kid Galaxy, Inc.
All Rights Reserved.

Kid Galaxy, Inc.
150 Dow St.
Manchester, NH 03101
USA

1-800-816-1135 | **Visit our website! www.kidgalaxy.com**
Conforms to the safety requirements of ASTM F963 and FCC regulations.
Product and colors may vary from items shown.
Contains 1 vehicle.

Proof of Purchase
Item #10372
6 77869 10372 4

KG26125S