NEWFAST

Quick Installation Guide

WebRIPRR: NF-U351, CF-970KUW, AK-U305

Note: Please read this Quick Installation Guide carefully before installation and operation.
NF-U351/970KUW/AK-U305

USB Port Cover
Cover the USB port

Package Contents

USB WiFi Dongle
Antenna x 2

One user handbook 1x1.00
Credit Manual 2x1.00
Warranty/package Card 1x1.00
Quality Inspection Card 1x1.00
Mouse x 1 (optional) 1x6.00
Cable x 1 (optional) 1x3.00

Product Overview

Setup

1. Install Driver & Software

1. Insert the provided CD into your computer.
2. Find the WiFi dongle in the CD and run the program.

3. Follow the wizard to complete the driver installation.
4. Restart your computer if the wizard prompts you to do so.

2. Plug in and Set up the Device

1. Turn "On/Off" of the device. Turn the Ethernet port into the Ethernet port, and plug in the USB port.

2. Follow the wizard to complete the set-up.
3. Restart your computer if the wizard prompts you to do so.

3. Plug in and Set up the Network

1. Connect the Ethernet port to the network.
2. Open the Ralink Wizard, and click "Next" button to set up the network.
3. Restart your computer if the wizard prompts you to do so.