GET IN TOUCH?

support@meowanthome.com

DISTRIBUTOR
Shenzhen Guiyang Network Technology Co., Ltd

ADDRESS
1404K3, East Block, Shengtang Commercial Building,
Futian District, Shenzhen, China

Intertek
5030403

Made In China

Rev_1.1_EN

Meowant

AIR PURIFIED





User Manua

Model: MW-PA16

CONTENT

01

01-03

IMPORTANT SAFETY INSTRUCTIONS

Safety Instructions 01
Specifications 03

02

04-06

EXPLORING AIR PURIFIER

In the Box 04
Control Function 05
LED Display 06

03

07-11

USING AIR PURIFIER

Setting Up 07
Replacing Filter 09

04

11-13

CARE AND MAINTENANCE

05

14-15

TROUBLE-SHOOTING GUIDE

IMPORTANT SAFETY INSTRUCTIONS

WARNING

READ ALL INSTRUCTIONS BEFORE USE AND SAVE FOR FUTURE REFERENCE

When using an electrical appliance, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:



Always ensure the filters are properly installed with plastic wrap removed before use.



DO NOT cover or block the air inlets or outlets in any manner. Allow at least 8 in of clearance.



DO NOT insert fingers or any objects through the grille or openings while in operation.

INTENDED USE

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by person responsible for their safety.
- Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children.
- Use the appliance only for intended household purposes as described in this User Manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- **WARNING** - To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Solid-State Speed Control Device.

ELECTRICITY SAFETY

- **DO NOT** use the appliance with a damaged cord or plug or if it malfunctions, is dropped or damaged in any manner.
- **DO NOT** operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- **DO NOT** use an external power supply other than the one provided with the appliance. Use only the provided power adapter.
- **DO NOT** immerse the appliance, power cord or plug in water or other liquid.
- **DO NOT** touch or hold the plug or operate the control panel with wet hands.
- **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

RELATED TO USE

- **DO NOT** use the filter as fuel or for similar purposes.
- **DO NOT** use the air purifier in an enclosed space where flammable, combustible or explosive gases are present.
- Always place and use the air purifier on a dry, stable, level, and horizontal surface. Arrange the air purifier and cord away from traffic areas and where it will not be knocked over.
- **DO NOT** expose to direct sunlight or other sources of sustained heat. Do not place near any heat sources such as radiators, heat registers, stoves, etc.
- **DO NOT** place the air purifier directly below an air conditioner to prevent condensation from dripping onto the appliance.
- **DO NOT** place the air purifier directly on or against soft furnishings, such as bedding or curtains, as this could cause the air purifier to block the air inlet or outlet.
- Keep indoors in a cool, dry location. Reduce exposure to high temperature and humidity.
- **DO NOT** sit on or place any object on top of the air purifier.
- **DO NOT** allow pets to chew on or swallow any parts. Cover or hide the power cord with care to prevent pets from biting.
- **DO NOT** allow anything to rest on the power cord. Do not plug in power adapter in an area where people or animals may walk or trip on cord.
- **DO NOT** run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

- **DO NOT** attempt to disassemble, repair, modify or replace any part of the appliance. No user serviceable parts inside. All servicing should be performed by qualified personnel only.
- To reduce the risk of fire, electric shock, or injury to persons, do not use replacement parts that have not been recommended by the manufacturer (e.g., parts made at home using a 3D printer).
- Always turn off and unplug the air purifier before moving, opening the covers or changing the filter.
- Always turn off and unplug the air purifier before cleaning, making any repairs or servicing, or whenever not in use. To disconnect, turn it off, then remove the plug from the outlet. Do not pull on cord.
- Dispose of all packaging materials properly. Keep away from children and pets. Keep plastic bags away from babies and small children. Do not use in cribs, beds, carriages or play pens.

FOR HOUSEHOLD USE ONLY
READ AND SAVE THESE INSTRUCTIONS

Specifications

Rated Voltage	24V ⎓
Rated Power	48W
Power Adapter	Input: 100-240V~ 50/60Hz 1.0A Output: 24V ⎓ 2A

EXPLORING AIR PURIFIER

In the Box

Check if all parts and accessories are included. Contact us via **email: support@meowanthome.com** if there is any part missing or damaged.





Control Function

ON / OFF
- Press once to turn the air purifier on (Auto mode on by default).
- Press once again to turn the air purifier off.

Auto Mode
- With air purifier on, press to turn Auto mode on or off.
- Once Auto mode is enabled, the air purifier automatically adjusts the fan speed based on the air quality.

Sleep Mode
- With air purifier on, press to turn Sleep mode on or off.
- Once Sleep mode is enabled, the air purifier automatically runs at low fan speed with display off. Press any button to wake up the display.

Fan Speed

With air purifier on, press repeatedly to cycle through fan speeds: P1 → P2 → P3 → P4 → P0 (Auto mode)→ P1...

Auto OFF Timer
- With air purifier on, press repeatedly to set a time (0-12H) to turn off automatically.
- To cancel, set timer to 0H, or turn the air purifier off.

Child Lock

With air purifier on, press and hold for 3 seconds to turn on or cancel child lock.

Check / Reset Filter
- With air purifier on, press once to check the filter life. The filter life will display for 6 seconds.
- When the filter reaches its service life (2000 hours), button indicator and ▥ will flash red. Replace the filter and reset the filter life by holding the button for 6 seconds until three beeps are heard.

LED Display



Air Quality Indicator Chart			
PM2.5 (μg/m³)	**Indicator Color**	**Air Quality**	**Fan Speed**
007-079	Green	Excellent	P1
080-149	Yellow	Moderate	P2
150-199			P3
200-500	Red	Poor	P4



USING AIR PURIFIER

Setting Up

- **IMPORTANT: Remove the plastic wraps from the filters before use.**
- Always ensure that the pull tabs are facing outward when inserting the filter in.
- Always ensure that the filters and covers are properly installed in place before use.



Remove the adapter from the bottom before use. Place the air purifier on a flat, stable surface. Pull the sides of the front and rear covers to remove both covers.

1



Remove the filters from the front and rear of the air purifier.

2



Remove the plastic wraps from both filters.

* Discard and do not allow children to play with the plastic wraps.

3



Place both filters back into the air purifier. Ensure that the pull tabs are facing outward when inserting the filter in.

4



Align with the bottom slots and attach the front and rear covers back. Press the covers to secure in place.

5



Locate the air purifier with enough circulation space around (> 8 inches). Run the cord through the slot and plug in the air purifier.

6

Replacing Filter

- When the filter reaches its service life (2000 hours), will flash red as a reminder to replace the filter.
- Turn off and unplug the air purifier before replacing the filter.
- Using your purifier in heavily polluted or dusty environments may cause the filter to clog faster, reducing its lifespan. To maintain optimal performance, clean and replace the filter more frequently.



will flash red as a reminder to replace the filter. Press once to turn off and unplug the air purifier.

1



Open the front and rear covers to remove the old filters from the air purifier.

2



Place new filters in. Ensure that the pull tabs are facing outward.

3



Align with the bottom slots and attach the front and rear covers back. Press the covers to secure in place.

4



Plug in and press once to turn on the air purifier.

5



Press and hold for 6 seconds until three beeps are heard to reset the filter life.

6

CARE AND MAINTENANCE

- Always make sure the air purifier is turned off and unplugged before cleaning.
- DO NOT stick any foreign objects or your fingers inside of the air purifier.
- Never immerse in water or allow water to drip into the motor housing.
- DO NOT clean with abrasive chemicals or flammable cleaning agents.



Outer Surface

Wipe the surface with a soft, dry cloth. If necessary, wipe with a damp cloth, then immediately dry.



Air Outlet

Vacuum up dust with a vacuum cleaner or wipe it with a cloth.



Dust Sensor

Clean the dust sensor with a lightly dampened cotton swab. Wipe dry with a dry cotton swab.

* Clean every 6 months to help maintain the efficiency of the sensor. If your air is often polluted with dust, dander, smoke, and other particles, you may need to clean the dust sensor more often.

Cleaning HEPA Filter & Pre-Filter

- Clean the pre-filter when particles are visible or excessive noises are heard. It is recommended to clean every 2 weeks.
- Using your purifier in heavily polluted or dusty environments may cause the filter to clog faster, reducing its lifespan. To maintain optimal performance, clean and replace the filter more frequently.



Turn off and unplug the air purifier. Open the front and rear covers and remove the filters from the air purifier.

1



Vacuum up dust on the main unit and filters with a vacuum cleaner.

2



Gently pull the pre-filter apart from the HEPA filter. If the pre-filter is heavily soiled with dust and debris, rinse it with water. Air dry thoroughly before attaching it back.

3



Vacuum up dust on the HEPA filters with a vacuum cleaner. Do not rinse or immerse in water. Replace the filters when service life is reached.

4



Attach the pre-filters back to the HEPA filters. Place both filters back. Ensure that the pull tabs are facing outward.

5



Align with the bottom slots and attach the front and rear covers back. Press the covers to secure in place.

6

TROUBLESHOOTING GUIDE

The troubleshooting guide addresses the most common problems. If problems persist, feel free to contact the Customer Support via **email: support@meowanthome.com**

Problem	Solution
Air purifier does not turn on or respond to button controls.	• Ensure that the air purifier is properly connected to a powered electrical outlet. • Ensure that the power adapter is firmly plugged into the power port. • Check if the power cord is damaged. Stop using the air purifier if damaged and contact our Customer Support for help. • Check if child lock is turned on. Press and hold child lock button for 3s to cancel.
Airflow is significantly reduced.	• Ensure that the filters are removed from the packaging and properly installed in place. • Leave at least 8 inches / 20 cm of clearance around the air purifier. Ensure enough circulation space. • Adjust to a higher fan speed. • The pre-filter may be clogged by large particles, such as hair or lint, blocking airflow. Clean the pre-filter. • Check if HEPA filter reaches its service life. Replace the filter if necessary.
Strange smell coming from air purifier.	• Check and clean the filters. Replace the filters if necessary. • Make sure not to use your air purifier in an area with high humidity. High humidity levels may cause mildew to grow on the filters.

Air purifier makes an unusual noise while the fan is on.	• Ensure that the filters are properly in place with plastic wraps removed. • Ensure that the front and rear covers are properly installed in place. • Ensure that the air purifier is operating on a hard, flat, level surface. • Check and clean the filters. Replace the filters if necessary. • Remove the covers and filters to check if there is any foreign objects inside the air purifier.
Poor air purification quality.	• Adjust to a higher fan speed. • Ensure that no objects are blocking the front, rear or top of the air purifier (inlet or outlet). • Ensure that the filters are properly in place with plastic wraps removed. • Check and clean the filters. Replace the filters if necessary. • For optimal purification performance, close doors and windows while using the air purifier. • If the room is too large, air purification will take longer.
Air quality indicator always stays red under good air quality.	• Clean the dust sensor. • Avoid using an ultrasonic humidifier near the air purifier. If you are using an ultrasonic humidifier near the air purifier, the mist may affect the accuracy of the dust sensor.
Air quality indicator always stays green even under poor air quality.	• Clean the dust sensor. • The dust sensor detects airborne particles, but it cannot detect gas. Make sure there are no gasses polluting the air.
How to get replacement filters?	For replacement filters, search for MeoWant replacement filter on Amazon or contact our Customer Support via email: support@meowanthome.com. DO NOT use replacement filters that are not recommended by the manufacturer.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.