

How to add a device?

There are 2 methods to add the device to your z-wave hub:

Scan code to add:

1. Scan the Pin QR Code on the product.
2. It will prompt to wait for the device to be added. At this time, press the button 3 times to enter the pairing mode.
3. Wait for the addition to complete.

Add Manually:

1. The Hub prompts to wait for the device to be added. At this time, press the button 3 times to enter the pairing mode.
2. It will prompt that it is being added, and then it will pop up that you need to enter the Pin Code.
3. After confirming the Pin Code, wait for the addition to complete.