

SE-100 Bluetooth Glasses Instructions

Product Overview

The SE-100 Bluetooth Glasses is a smart wearable device that integrates audio playback, call functions, and an AI assistant. It adopts Bluetooth 5.3 technology to provide a stable wireless connection experience, making it suitable for daily commuting, sports, and office use.

Technical Parameters

Parameter items	Specifications
product model	SE-100
Bluetooth version	5.3
transmission distance	10-15 meters (barrier-free environment)
Music playback time	10-15 hours (medium volume)
holding time	10-15 hours
Charging method	Type-C joggle
charging interval	About 2 hours
battery capacity	3.7V/150mAh

Operation Manual

I. Music Control

1. Play/Pause: Click the function key once.
2. Volume Adjustment:
 - Double-click the function key to increase the volume by 3 levels.
 - Triple-click the function key to decrease the volume by 3 levels.
1. Note: This device does not support track forward/backward switching.

II. Call Control

1. Answer a Call: Click the function key once.
2. Reject an Incoming Call: Long-press the function key for 2 seconds.
3. End a Call: Long-press the function key for 2 seconds.
4. Call Volume Adjustment: Same as the volume adjustment method for music control.

III. AI Control

1. Activate AI Assistant: Long-press the function key for 2 seconds.
2. Deactivate AI Assistant: Long-press the function key for 2 seconds.

Charging Instructions

1. Connect the glasses to a charger using a standard Type-C cable.
2. The indicator light turns red during charging and turns off once fully charged.
3. It is recommended to use a 5V/1A charger and avoid fast-charging devices.

Matters Needing Attention

1. Keep this product out of the reach of children.
2. Use and store the product and its accessories within a temperature range of 0°C–40°C. Extreme high or low ambient temperatures may cause product malfunctions.
3. Reasonably control the volume and duration of product use to prevent hearing damage.
4. Do not use the product while driving, riding a bicycle, operating machinery, or performing tasks that require attention to external sounds.
5. Do not disassemble, impact, squeeze, or expose the product to fire, as this may cause an explosion. If the battery swells or leaks, stop using the product immediately.
6. Do not use the device during thunderstorms, as this may cause abnormal operation of the device and increase the risk of electric shock.
7. When using this device, maintain a distance of at least 15 cm from implanted medical devices (e.g., pacemakers).
8. Due to the characteristics of Bluetooth technology, signal strength depends on the usage environment. If there are many overlapping wireless signals or strong electromagnetic interference nearby, the product's received signal may weaken or even disconnect.
9. If the product will not be used for an extended period, charge it every three months to prevent battery damage that may render the product unbootable.
10. Stop using the device before cleaning or maintenance. Wipe the device with a clean, dry, soft cloth.
11. It is recommended to use a brand-manufactured charger that is CCC-certified and has an output voltage of 5V to charge this product. Avoid using fast chargers with an output voltage exceeding 5V, as this may damage the product.

12. Maintain a steady press when using the long-press function to avoid accidental triggering.
13. The waterproof function is not permanent, and its protection level may decrease due to daily wear and tear. Do not charge the glasses in wet conditions.

Additional Information

- Storage Method: Store in a cool, dry place.
- Main Material: PC (Polycarbonate)

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.