



AMATINHOME X107 SMART RING USER MANUAL

Thank you for choosing the AMATIN HOME X107 Smart Ring.
We're dedicated to supporting your daily health tracking and wellness experience.

Customer Service: 4006685002 TIME: 9:00-18:00 (weekday)

Getting Started - Connect Your AMATIN HOME X107 Smart Ring

Follow these three simple steps to set up your AMATIN HOME X107:

Step 1: Charge & Activate

Place your ring into the charging cradle to activate it. The ring will power on and begin charging automatically. A brief charge is all it takes to wake up the ring and get it ready for pairing.

Step 2: Download

Scan the QR code below or search "AMATIN HOME" on the App Store (iOS) or Google Play (Android) to download the "AMATIN HOME" App.

Step 3: Pair Your Ring

Open the "AMATIN HOME" and go to the Devices tab. Tap Add Device and wait for search for your ring.

When "Amin Home Ring" appears in the list, select it to complete pairing.



AMATINHOME

Key Product Highlights

Premium Titanium Build: Lightweight, durable, and comfortable for 24/7 wear

100M Water Resistance: Wear for showering, swimming, and snorkeling

Battery & Charging: Up to 5-6 days usage per charge; fully charged in just 90 minutes. Actual battery life may vary by usage and app settings

All-Day Health Tracking: Heart Rate & SpO2 monitoring with safe optical sensors

Secure Bluetooth Connection: Stable & encrypted data sync to your phone

Easy touch operation for volume adjustment: music control ebook page flipping, remote camera shutter, short video scrolling and PPT slide navigation.

AMATINHOME

Product Specifications

Model: X107

Material: Ceramic+Titanium

Operating Temperature: - 10°C to 54°C (14°F to 129°F)

Sensors: Red/Green LED (heart rate); Infrared sensor (SpO2) | All LEDs meet safe visible/infrared standards

Battery: Rechargeable 16mAh lithium-ion battery

Typical Battery Life: Up to 5 days (varies by usage & app settings)

Connection: Bluetooth Low Energy (BLE) | Encrypted secure communication

App Compatibility: Android 5.0+ / iOS 10.0+

Packaging List: Instruction Manual, Warranty Card, Charging Case, Smart Ring

Three package instructions: charging compartment, ring

AMATINHOME

Safety & Compliance Information

Not a Medical Device

The AMATIN HOME X107 is a wellness & fitness tracker- NOT a medical device. It is not intended to diagnose, treat, cure, or prevent any disease or health condition. For medical concerns, always consult a qualified healthcare professional.

Skin Comfort

Materials comply with ISO 10993 standards for safe skin contact. If skin irritation occurs, remove the ring. Consult a doctor if irritation persists.

Heat & Battery Safety

Do not expose the ring/charger to extreme heat (e.g., hot car, direct long-term sunlight). Do not open, puncture, disassemble, or incinerate the ring — contains lithium-ion battery.

Electrical Safety

Do not handle the charger with wet hands.
Do not charge in locations with risk of electric shock

AMATINHOME

General Usage & Care

AMATINHOME

Wear & Water Resistance

Designed for 24/7 continuous wear (sleep, daily use, workouts, showers, swimming, snorkeling) Water-resistant up to 100 meters (328 feet).

Important: Rinse with clean fresh water after exposure to saltwater or chlorinated water to protect the titanium finish and sensor accuracy.

Cleaning Instructions

Clean regularly to maintain performance and avoid skin irritation. Wipe gently with a soft damp cloth, then dry completely before wearing.

Charging Guidelines

Use only the original AMATIN HOME X107 charger. Charger is for indoor use only - NOT waterproof. Keep away from humidity (e.g., bathrooms). Optimal charging temperature: 18 °C - 32 °C (65°F - 89°F) | Charge at room temperature.

Material Care

Titanium is highly scratch-resistant. Avoid close contact with softer metals, jewelry, or electronics to prevent scratching those items.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.