


Under Cabinet Installation



Installation
Tutorial Video




Under Cabinet Installation

Preparation

- ▶ Decide the location of the venting pipe from the hood to the outside.
- ▶ Check hood for clearance.
- ▶ A straight, short vent run will allow the hood to perform more efficiently.
- ▶ Try to avoid as many transitions, elbows, and long runs as possible. This may reduce the performance of the hood.
- ▶ For installing under the cabinet with recessed bottom, attach 4-inch wide wood filler strips (not provided) on each side.
- ▶ Puncture the knockout holes (for mounting under the cabinet) on the hood.


- 1 Measure the distance between stove top and the bottom of the range hood. A distance of 30" to 36" is recommended.




- 2 Attach mounting brackets to the back of the hood.

- 3 Mark the leveling point of the hood. Position two mounting screws on the wall, leaving $\frac{1}{8}$ " space away from the wall. **Make sure that you are mounting the hood to a secure backing to hold the weight of the hood.**

- 4 Tighten ducting (provided) with the hose clamp provided. Use silver or duct tape wherever needed.



- 5 Draw electrical wires through cabinet access opening, center the hood beneath the cabinet.



- 6 Align hood-mounting brackets to the screws on the wall and hook hood into place. Tighten screws to secure hood to the wall.

- 7 Connect ducting.

