

SENCOR®

Let's live!

**BLUETOOTH SPEAKER
SSS 6501 AULUS**

**USER'S MANUAL
EN**



Table of Contents


1. Supply content.....	3
2. Description of the BT speaker	3
3. Putting into operation.....	4
4. LED indicator	4
5. Pairing devices via Bluetooth.....	4
6. Audio AUX IN.....	5
7. USB connection.....	6
8. Play/Pause button	7
9. Volume and track playback control.....	7
10. Technical specifications	8

1. Supply content

- BT speaker
- Power adapter
- User's manual
- 3.5mm audio jack cable connection cable

2. Description of the BT speaker

BT speaker rear view



1	Volume increase/next track
2	Play/Pause
3	Volume decrease/previous track
4	Mode switch button (Bluetooth/AUX IN/USB)
5	Power On button/Reset button
6	USB connector
7	AUX output
8	Power connector
9	Bluetooth pair/unpair button

3. Putting into operation

Before first use, be sure to read the safety instructions contained in this user's manual carefully.

Hold down the power On button to turn on the BT speaker.

Turning on/off is indicated by a sound signal. To turn the BT speaker off, hold down the power On button. To switch between individual modes (Bluetooth/AUX IN/USB), press the Mode switch button repeatedly.



Attention: After a longer period of inactivity, the appliance will turn itself off.

4. LED indicator

The LED indicator shows the following states of the BT speaker:

- Blinking blue - the unit is ready to be paired via Bluetooth and the audio signal source is not connected.
- Solid blue - the BT speaker is paired with another device via Bluetooth.
- Solid blue-green - playback via USB device.
- Solid green - audio jack is connected to the device

5. Pairing devices via Bluetooth

Turn on the BT speaker and search for its Bluetooth name "SSS 6501" in the device to which you wish to pair and start the pairing process. If you are requested to enter a pairing code while your device and the BT speaker are pairing, use the code: "0000". After disconnecting the paired device, hold down the "Bluetooth pair/unpair button" until a beep sounds.

Note: To ensure a stable Bluetooth connection, make sure that the distance between the BT speaker and your connected device is kept within 10m.



Attention: Some connected devices support common volume setting. If some of the connected devices do not support this feature, the volume setting will operate separately on each device.

6. Audio AUX IN

The BT speaker is equipped with a 3.5mm audio jack. Your device can be connected to the BT speaker via the audio cable. First connect the audio plug to your device and then to the BT speaker's jack.



Notice: Before connecting your device to the BT speaker, ensure that the output signal from your device is at its minimum level (minimum output volume). This will prevent the BT speaker from damage.

Note: The Bluetooth function is not active if the audio jack is connected to the BT speaker.

7. USB connection

After connecting the USB memory to the USB slot, the BT speaker will automatically switch to the USB playback mode. The BT speaker supports playback in MP3, WMA and FLAC formats.



Warning: To prevent undesired interference, always connect the USB memory directly to the unit. To connect the USB memory to the unit, do not use an extension USB cord.

Important: The USB port is designed for data transfer only. Other devices should not be connected to this port. Do not connect any devices other than USB flash memories up to 32 GB.



Attention: Due to a number of devices on the market, compatibility and playback support are not guaranteed for all media. The memory devices you want to connect should be tested in advance and/or formatted as FAT32. The playback of protected media, files or content stored inside them may fail.

8. Play/Pause button

- 8.1 Press the Play/Pause button to start or stop music playback during a Bluetooth connection.
- 8.2 The incoming call to a Bluetooth connected paired device will be accompanied by an acoustic signal which will interrupt the music being played back. To answer/hang up an incoming call, press the Play/Pause button briefly. To reject incoming call, long press and hold the button.

Note: To improve the microphone reception during ongoing phone call via Bluetooth, please speak loud and in the vicinity of the BT speaker.

9. Volume and track playback control

To control the BT speaker's volume (+/- buttons), press briefly the BT speaker's relevant buttons. To jump to the next track during music playback, press and hold the Volume increase/next track button. To select the previous track, press and hold the Volume decrease/previous track button.

10. Technical specifications

SSS 6501 AULUS

Premium Bluetooth Speaker

Wireless speaker SSS 6501 AULUS sounds small or bigger places according your ideas. Speaker is covered by premium fabric for minimize sound distortion and body design is create for connection with modern interior. System DSP provide completely new standards for dynamic, clean and quality sound. Two stereo mid-range and two treble speakers with a maximum power of 50W take care of the quality sound. You can enjoy your favorite music via Bluetooth wireless access with range up to 15 meters, USB stick or another device with a 3.5mm Jack connector.

Powerfull Bluetooth Speaker with Elegant Design
Digital Sound Processor DSP

Sound:

Power Output: 50W (Impedance: mid 4 Ω , treble 6 Ω)
Frequency Response: 50 Hz - 20 KHz
Total Harmonic Distortion: $\leq 1\%$
4 Speakers (2 Mid-Range + 2 Treble)

Inputs:

Bluetooth Audio 4.2
Connection Distance up to 15m
Audio Aux Input (3.5mm stereo Jack)
USB Input for Playback

Others:

Handsfree Function

LED Status Indicator

Accessories: Charging Adaptor, 3.5mm Aux Cable, User Manual

Power Supply: DC 15 V/2.5 A

Standby Consumption: $\leq 0.5\text{W}$

Dimension: 340 x 99 x 152mm

Weight: 1,8 Kg

INSTRUCTIONS AND INFORMATION ABOUT THE DISPOSAL OF DISCARDED PACKAGE

Return the packaging to a collection centre for disposal.

DISPOSAL OF DISCARDED ELECTRICAL AND ELECTRONIC EQUIPMENT



This symbol placed on the product, accessories or package notifies that the product must not be treated as household waste. Please dispose of this product in a collection centre designed for recycling electric and electronic equipment. In some EU or European countries, you can return your products to your local dealer when buying a new equivalent product. Proper disposal of this product helps save valuable natural resources and prevents possible adverse impacts on the environment and human health that might be caused by improper waste disposal. For further information, please contact your local authorities or the nearest waste disposal collection centre. Wrong disposal of this type of waste may be subject to a legal penalty.

For EU companies

If you need to dispose of an electric or electronic device, ask your dealer or supplier for necessary information.

Disposal in countries outside the European Union

To dispose of this product, please ask the ministry or your dealer for the necessary information on correct disposal.



FAST ČR, a.s. hereby declares that the radio equipment type SSS 6501 AULUS conforms to the 2014/53/EU Directive. For full version of the EU declaration of conformity, please refer to www.sencor.eu website.

Changes in the text, design and technical specifications may be made without prior notice and we reserve the right to make such changes.

The original version is in Czech.
Address of the manufacturer: FAST ČR, a.s.,
Černokostelecká 1621, Říčany CZ-251 01

EN Warranty conditions

A warranty card is not included with this product.

This product is warranted for the period of 24 months from the date of purchase to the end-user. Warranty is limited to the following conditions. Warranty is referred only to the customer goods using for common domestic use. The claim for service can be applied either at dealer's shop where the product was bought, or at below mentioned authorized service shops. The end-user is obligated to set up a claim immediately when the defects appeared but only till the end of warranty period. The end user is obligated to cooperate to certify the claiming defects. Only completed and clean (according to hygienic standards) product will be accepted. In case of eligible warranty claim the warranty period will be prolonged by the period from the date of claim application till the date of taking over the product by end-user, or the date the end-user is obligated to take it over. To obtain the service under this warranty, end-user is obligated to certify his claim with duly completed following documents: receipt, certificate of warranty, certificate of installation.

This warranty is void especially if apply as follows:

- Defects which were put on sale.
- Wear-out or damage caused by common use.
- The product was damaged by unprofessional or wrong installation, used in contrary to the applicable instruction manual, used in contrary to legal enactment and common process of use or used for another purpose which has been designed for.
- The product was damaged by uncared-for or insufficient maintenance.

- The product was damaged by dirt, accident of force majeure (natural disaster, fire, and flood).
- Defects on functionality caused by low duality of signal, electromagnetic field interference etc.
- The product was mechanically damaged (e.g. broken button, fall).
- Damage caused by use of unsuitable media, fillings, expendable supplies (batteries) or by unsuitable working conditions (e.g. high temperatures, high humidity, quakes).
- Repair, modification or other failure action to the product by unauthorized person.
- End-user did not prove enough his right to claim (time and place of purchase).
- Data on presented documents differs from data on products.
- Cases when the claiming product cannot be indentified according to the presented documents (e.g. the serial number or the warranty seal has been damaged).

Authorized service centers

Visit www.sencor.eu for detailed information about authorized service centers.

