

Hot Air Fan

User's manual

EN



SENCOR[®]

SFH 8010

Prior to using this appliance, please read the user's manual thoroughly, even in cases, when one has already familiarised themselves with previous use of similar types of appliances. Use the appliance only as described in this manual. Keep this manual for later use.

Save the original shipping transport box, packaging material, receipt and warranty card for the duration of the warranty. In the event of transportation, pack the appliance using the original packaging materials only.

EN-1

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	3
DESCRIPTION OF THE HOT AIR FAN	4
USING THE HOT AIR FAN	5
THERMAL PROTECTION	6
MAINTENANCE AND CLEANING	6
STORAGE	6
TECHNICAL SPECIFICATIONS	6
INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS	7
DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT	7

IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND STORE IT FOR FUTURE USE.

- This appliance must not be used by persons (including children) with physical or mental impairments or by inexperienced persons, unless properly trained or schooled in the safe use of the appliance, or unless they have been properly supervised by a qualified person who will be responsible for their safety.
- Children must be supervised to ensure that they do not play with the appliance.
- Do not subject people or animals to the direct flow of hot or cold air for an extended period of time. It may negatively affect their health.
- Before connecting the appliance to a power socket check that the technical details on the appliance label match the electrical voltage in the socket.
- Do not connect the appliance to an extension cord or two way adapter.



Attention:

Do not use this appliance with a programmer, time switch or any other device which would switch the appliance on automatically, because there is a danger of a fire if the appliance is covered or incorrectly located.

- The appliance is designed for use in households, offices and similar types of areas.
- Do not use the appliance in very dusty or humid rooms such as laundries or bathrooms, in areas where chemicals are stored, in industrial surroundings or outdoors!
- Do not use the appliance in the near vicinity of a bath, shower or swimming pool.
- This appliance is not intended to be mounted on a wall.
- Do not locate the appliance directly under an el. power socket.
- Do not place the appliance on unstable surfaces such as carpets with very long and thick fibres. The appliance must be located on a stable and even surface.
- Do not use the appliance near furniture, curtains, drapes or other flammable materials.
- Free space of at least 100 cm in front of the appliance and 50 cm behind the appliance must be maintained while it is running to ensure sufficient air circulation.




Attention:

To prevent the appliance from overheating, do not cover it with any items.

- Do not insert any objects through the front air outflow grill or the back air inflow grill. This could lead to an electrical short circuit, fire or damage to the appliance.
- Do not touch the front grill of the heater during operation, so as to avoid skin burns.
- To avoid potential injury by electric shock do not submerge any part of this appliance in water or any other liquid and do not touch the appliance with damp or wet hands.
- Always turn off the appliance and disconnect it from the power socket, if you will not be using it or before cleaning.
- Do not leave the appliance in operation if you are getting ready to go to sleep.
- Before cleaning the appliance, first turn it off and disconnect it from the power outlet. When cleaning the appliance, do not submerge it in water or wipe it with a wet cloth.
- To avoid damaging the power cord, do not excessively bend or twist it.
- Ensure that the power cord does not come into contact with hot surfaces or sharp objects.
- Do not disconnect the appliance from the power socket by pulling on the power cord. This could damage the power cord or the power socket. Disconnect the cord from the power socket by gently pulling out the plug of the power cord.
- If the power cord is damaged, it must be replaced by an authorised service centre or by another similarly qualified person, this will prevent the creation of a dangerous situation.
- Do not use the appliance if it is not working correctly, if it has been damaged or has been submerged in water. To avoid the danger of injury by electrical shock, do not repair the appliance yourself or make any adjustments to it. Have all repairs or adjustments of the appliance performed at an authorised service centre. Tampering with the appliance during the warranty period may void the warranty policy.
- The manufacturer is not responsible for any damages caused by the incorrect use of this appliance.


DESCRIPTION OF THE HOT AIR FAN



USING THE HOT AIR FAN

1. TURNING ON AND SETTING THE MODE

- 1.1 Connect the hot air fan to an el. power socket and turn the thermostat ⑤ clockwise to maximum.
- 1.2 Turn dial ⑥ to set the operating mode.

Operating mode	Function
	Cold air flow Only the fan is running.
I	Hot air flow I The heating elements are operating at 1000 W and the fan is running. The fan will help heat up the room faster.
II	Hot air flow II The heating elements are operating at 2000 W and the fan is running. The fan will help heat up the room faster.

- 1.3 The power On indicator light ④ will turn on as soon as the hot air fan is put into operation.



Note:

A slight odour may be felt when the fan is first turned on or after an extended period where it has not been used. This event will go away after a short while.

2. SETTING THE THERMOSTAT


- 2.1 If you have selected the cold air flow mode then leave the thermostat set at the maximum level.
- 2.2 If you have selected the hot air flow mode then after achieving the desired temperature in the room adjust the thermostat. Adjust the thermostat by slowly turning the dial ⑤ anticlockwise. Stop turning the dial as soon as you hear a click. Now the thermostat is set and will automatically maintain the room temperature by turning the heating elements on and off. The fan will turn on and off together with the heating elements.



Note:

Turn the thermostat ⑤ clockwise to increase the set temperature. Turn the dial in the opposite direction to decrease the temperature.

3. TURNING OFF

- 3.1 To turn off the appliance while the cold air flow mode is set, turn the thermostat ⑤ anticlockwise to the minimum and move the On/Off dial ⑥ to position O.
- 3.2 If the hot air flow mode is set, first turn the dial ⑥ to the position indicated by the symbol  and turn the thermostat ⑤ clockwise to the maximum. The appliance will be cooled down after 3 to 5 minutes. Then you can turn it off by turning the thermostat ⑤ anticlockwise all the way to minimum and move the On/Off dial ⑥ to position O.
- 3.3 The indicator light ④ indicates that the appliance has been turned off.

THERMAL PROTECTION

- This appliance is equipped with a resettable heat fuse, which is activated and shuts off the heating elements if the device overheats. To speed up the cooling of the appliance the fan will continue to run. The heat fuse is deactivated as soon as the appliance cools down.

MAINTENANCE AND CLEANING

- Ensure that the appliance is turned off and that it has cooled down before cleaning it.
- Clean the appliance using a soft dry cloth. Do not use chemicals or abrasive cleaning products for cleaning. Otherwise the surface of the appliance may be damaged.
- Do not spray the appliance with water or submerge it in water or another liquid.

STORAGE

- If you will not be using the appliance, store it in a dry, clean place out of children's reach. Allow the appliance to cool down before storing.

TECHNICAL SPECIFICATIONS

Nominal voltage.....	230 V
Nominal frequency.....	50 Hz
Rated power input.....	2000 W
Power input range	1000/2000 W
Safety class (for electric shock protection)	II
Noise level.....	60 dB(A)

The declared noise emission level for this appliance is 60 dB(A), which represents level A of the acoustic power relative to the reference acoustic power of 1 pW.

Glossary of technical terms

Safety class for electric shock protection:

Class II – Electric shock protection is provided by double or heavy-duty insulation.

We reserve the right to change text and technical specifications.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Hot Air Fan

SFH 8010