

W462AQC : 2K Pan-Tilt Indoor Wi-Fi Security Camera - Troubleshooting

 help.lorextechnology.com/link/portal/57356/57366/Article/3627/w462aqc-hd-wi-fi-camera-troubleshooting

The following are some of the most common issues and troubleshooting tips for the **2K Pan-Tilt Indoor Wi-Fi Security Camera** ([W462AQC](#)).

General troubleshooting support


Many issues can be resolved with the following troubleshooting steps:


- Ensure the latest version of the required software/app is installed and has the most recent firmware (if applicable).
 - If using client software or a mobile app, ensure your device meets the minimum system requirements.
 - Ensure the Internet connection and speed meet the minimum requirements for the product.
 - Check the power connection(s).
 - Power cycle the product(s). To power cycle your product, please power off (if applicable) and disconnect the power source for approximately 30 seconds. Reconnect, and power on.
-

How to reset 2K Indoor Wi-Fi Pan-Tilt Security Camera?

Ensure your camera is plugged in and powered **ON** throughout the reset process.

1. Locate the reset button located at the side of the camera.
The SD card slot and reset button is located below the lens. To find the button, turn the lens all the way up.

 Do not damage the PTZ motor.



2. Press and hold the reset button for 10 seconds until the chime sounds to reset the camera.
3. Look for flashing green light below the lens to indicate that the camera has been fully reset.

Note: A solid or steady green light indicates that the camera has not been fully reset. You may have to redo the process again.

The status indicator is not flashing green

If you don't hear a chime or if the status light is not flashing green, then your mobile device is not connecting with your Wi-Fi network. Reboot your Wi-fi OR perform the following steps to reset your device.

1. Lift the panel on the top of the camera to access the **Reset** button.
2. Press and hold the **Reset** button for 10 seconds to reboot the camera.
3. Wait for one minute until the camera LED is flashing green.

The camera is stuck downwards

Turn off **Privacy Mode** in Device Settings on the Lorex App. This will enable the lens to slide upwards.

The camera image is not clear

- Check the camera lens for dirt, dust, and spiderwebs. Clean the lens with a soft, clean cloth.
- Remove the vinyl cover on the camera lens.

The audio function is not working

1. Launch the Lorex App.
 2. From the Devices screen, tap a device thumbnail to start live view for a single camera.
 3. Tap **Talk** to speak through your camera from your mobile device. Tap again to listen in.
-

How do I reset the password of my camera?

If you have forgotten the password for your camera, the quick and easy way to resolve the issue is to perform a hard reset on your camera **OR** perform the following steps:

1. Launch the Lorex App.
 2. Tap **⋮** icon above the channel thumbnail on the **Devices** screen.
 3. Tap the thumbnail of your device on the **Device Settings** screen.
 4. Tap **Device Password**.
 5. Enter your old password and the new password.
Note: Your password must be 8-32 characters in length, and must contain a combination of numbers, letters, and symbols.
 6. Tap **Save**.
-

How do I reset the password of my Lorex App?

1. Launch the Lorex App.
2. Tap **Settings** tab.
3. Tap **Account Settings**.
4. Tap **Log out**.
5. Tap **Forgot password?** on the login screen and follow the in-app instructions.

OR

Re-install the app, and tap **Forgot password?** on the login screen and follow the in-app instructions.
