



SAMSUNG



Unpacking and Installation Guide
 Guide de déballage et d'installation
 Guía de desembalaje e instalación
 Manual de desempacotamento e instalação
 Auspacken und Installationsanleitung
 Guida al disimballaggio e all'installazione
 Руководство по распаковке и установке
 Қаптамадан шығару және орнату нұсқаулығы
 Посібник з розпаковки та встановлення
 Qadoqdan chiqarish va o'rnatish qo'llanmasi



USB	USB ↔	OPTICAL	
ARC	HDMI (eARC)	LAN	
	HDMI	ANT	


1 **55"**

65"


2 **3**

4




5



6




7



	A	B	C	D	E	F	G	H
55S8*H 55SH8*	48.3 inches (1225.7 mm) (122.57 cm)	27.8 inches (705.6 mm) (70.56 cm)	1.3 inches (33.9 mm) (3.39 cm)	30.1 inches (764.4 mm) (76.44 cm)	9.3 inches (235.3 mm) (23.53 cm)	54.6 inches (138 cm) (138 cm)	28.7 lbs (13.0 kg) (13,0 кг)	29.5 lbs (13.4 kg) (13,4 кг)
65S8*H 65SH8*	57.0 inches (1446.6 mm) (144.66 cm)	32.7 inches (829.7 mm) (82.97 cm)	1.3 inches (33.9 mm) (3.39 cm)	35.3 inches (897.8 mm) (89.78 cm)	10.4 inches (263.3 mm) (26.33 cm)	64.5 inches (163 cm) (163 cm)	38.4 lbs (17.4 kg) (17,4 кг)	39.2 lbs (17.8 kg) (17,8 кг)

*: 0-9, A-Z



	VESA A x B (mm) VESA A x B (MM)	C (mm) C (MM)	D x 4
55S8*H 55SH8*	300 x 200	19-21	M8
65S8*H 65SH8*	300 x 200	19-21	M8

*: 0-9, A-Z