

Kinglucky



H9 USER MANUAL

I Packing list



Host *1



Charging cable *1



Instructions *1



Certificate *1

II Microphone parameters and functions

Product name: Junyun Sound microphone

Product model: H9

Channel system: Dual channel

Transmission distance: ≤ 10 m

D C Power source: 5V $\approx$ 1A

Horn: 4 Ω

Battery capacity: 2500 mAh

Charging time: about 2-3 hours

Spirit sensitivity: 90DB

Product weight: 0.53kg

III Instructions for use

1. Accompaniment Connection Instructions

(Just choose one method of accompaniment, it is recommended to use wireless Bluetooth accompaniment)



Long press "  " to turn on/off:

(Power on defaults to "Bluetooth mode")

Short press "  " mode to switch between Bluetooth and TF card


Long press "  " to turn Bluetooth on/off,

The Bluetooth name is "H9 Sound microphone "

Method 1: Wireless Bluetooth connection for accompaniment

(live streaming and accompaniment cannot be on the same phone)


Use another audio device to open Bluetooth and search for "H9Sound microphone". After successful connection, the product prompts with the following sound: "Bluetooth connection successful";



Method 2: Insert a TF card for storing music (Pre-store audio files that need to be played)

Insert the TF card into the TF card slot of the sound card to automatically play the audio file.

IV Product appearance description



V After-sales service description

Dear users, thank you very much for using our products. In order to effectively protect your rights and interests, it is clear that the distribution agents and the company should undertake the maintenance, replacement and return of products (hereinafter referred to as "three guarantees") responsibilities and obligations, please read the matters:

1. The Product Warranty Card is the necessary proof for our company to provide free after-sales service within the warranty period.
2. According to the principle of "three guarantees", if there is a product quality problem, contact the distributor with the "Product warranty card", and the distributor will provide service to the customer, and our company will provide service support to the distributor;
3. The company promises that if any quality problem occurs within 7 days from the date of sale (subject to the date of valid bill, the same below), the customer can return the product now for replacement or repair; From the date of sale from 8 days to 15 days of quality problems, customers can choose to replace and repair; From the date of sale. Within one year quality problems, customers can free maintenance; The product will enjoy lifelong maintenance if quality problems occur after the warranty period (all after-sales service points only charge for components and materials); Please fill in the "Product Warranty Card" with the dealer carefully.
4. The following circumstances do not enjoy the three-guarantee service:
 - (1) Exceeding the term of three contracts;
 - (2) Damage caused by failure to use, maintain and keep the product according to the instructions;
 - (3) Damage caused by disassembly by the repairman who is not responsible for the three packages;
 - (4) The content of the Product Warranty Card is inconsistent with the physical identification of the product or altered;
 - (5) Damage caused by force majeure.

Attention: The product has a built-in rechargeable battery. Please do not disassemble or replace it by yourself. Use the correct method to charge the device. Do not place the device near a fire source or expose it to direct sunlight, otherwise the battery heating will damage the safety device and cause the battery to explode or burn.



Made in China

VI Common problem handling

1. If the indicator light does not turn on after startup, please check whether the audio power is sufficient, or connect the audio to the 5V/1A power supply for charging, charging time is about 3-4 hours.
2. The microphone has no sound, which may be because the power is not turned on, the mode is incorrect, or the volume is not adjusted. Please adjust the volume of the microphone and check whether the Bluetooth light is steady on.
3. If the sound has no reverberation, the reverberation switch may be off. Please turn on the reverberation switch.
4. If the microphone is noisy, it may be due to environmental noise, signal interference, microphone too close to the speaker, etc. Please adjust the direction of the microphone again.
5. If the Bluetooth playback is interrupted, it may be because the Bluetooth is too far away or there is an obstacle between the phone and the loudspeaker, which will affect the signal transmission. Please get close to the connected phone and avoid the obstacle.
6. If the Bluetooth cannot be connected, it may be because the distance is too far, there is an obstacle, or it is connected by other mobile phones. Please approach the mobile phone to avoid the obstacle.
7. If it cannot be charged, check whether the charger is normal and whether the red indicator light of the charging port is on when the sound is charged.

Product model : _____

Purchase date : _____

Agent : _____

Invoice date : _____

Telephone : _____

Customer Name : _____

Postal Code : _____



Eertificate

Examination clerk

This product has been inspected
and found to be qualified