



Auto-Guard

Saving you money. Protecting your asset

User Manual

Please register your device to activate it.

See page 4.

Contents Guide:

Page 2	Contents Guide / Important Information
Page 3	Controls & Indicators / Installation
Page 4-5	Setup
Page 6	Home Page / Impact / Perimeter
Page 7	Perimeter / Temperature
Page 8	Speed / Locate
Page 9	Make a claim User Guide
Page 10	Alarms
Page 11	Products
Page 12	Navigating the Settings
Page 13	Frequently Asked Questions
Page 14	Warranty

Important Information


Understanding your smart alarm:

The most common question is, why, when an alarm is triggered, can it take a short while for the App to notify me?

On average, this can take anywhere from 30 seconds to 2 minutes, based on several variables. Satellite signal, data upload, network latency, server processing, and your mobile's background activity.

However, when the alert/notification comes through, it will display the correct time the alarm occurred.

Controls & Indicators / Installation:



Functions:

- Please see the side of the box for fitment instructions.
- Once powered on, the device automatically turns on.
- Blue light: GPS status indicator.
- Red light: GSM/LTE.
- USB-C to the power cord.
- SIM Card – Mini
- Face the SIM card (chip down) as illustrated above.
(Clips in – click sound)

Installation:

- Locate your vehicle's OBD port – usually within arm's reach of the driver.
 - Insert the provided harness's USB-C into the smart alarm's USB-C Port.
 - Plug the harness's OBD plug into your car's OBD port.
 - Place the double-sided tape over the logo (not over the light sensor).
 - Find a flat area and place the device, logo, and light sensor face down.
 - The device will power on straight away.
-
- Red light on, then flashing with blue for approximately 30-40 seconds.
 - Solid red light, with flashing blue 30-40 seconds.
 - After approximately 70 seconds - no lights.

Once you've installed and activated your device, it may take up to 30 minutes for it to become fully operational in the App.

Setup:

If you do not register your device, any claim made will be assessed based on the original invoice date.

Step 1:

Download the app from your app store.
(Google Play for Android and Apple Store for IOS).
Search “**Auto Guard**” and select download.



Step 2:

Go into the Auto-Guard app.
Click on “Register”.


Complete the form. (Please ensure this information is accurate.)
You will find your unique Product No. located on the box and the device.
Press “Submit”.
You will receive your welcome letter via email, with your app login details.
(Username & Password) Please check your spam and junk folders.
If the images and words are blocked, view them on your mobile device.

The image displays two screenshots of the Auto-Guard app's registration process, connected by a blue arrow pointing from left to right. The left screenshot shows the initial registration screen with fields for 'Username' and 'Password', a 'Submit' button, and a 'Register' button which is circled in blue. Below these are a 'Remember me' checkbox and a 'Forgot my password' link with a 'Submit' button. The right screenshot shows the subsequent registration form with fields for 'First Name', 'Surname', 'Email Address', 'Mobile Number', 'Product No.', 'Plan Duration', and 'Rego / Plate No.', followed by a 'Submit' button. Both screens feature the Auto-Guard logo at the top and a status bar at the top indicating 'No SIM' and the time '6:27PM'.

Step 3:

Go back into the app.
Enter your login details and press “Submit”.

Select your Asset.
If you have purchased more than one Auto-Guard product and wish to add it to an existing account, select “Add Asset”.




Home Page:

Here you can manage your smart alarm according to your preferences. You can also adjust the settings and purchase additional value-added products.

Option to rename your asset.

The Impact alarm can be turned on and off with the toggle switch. You can press "Setup" and adjust the sensitivity. This feature will send a push notification to your mobile phone in the event an impact/accident has taken place.

Here you can create an invisible barrier around a location of your choosing. Receive an alarm if your vehicle enters or leaves these locations.






Enter an address

Increase / Decrease size



Name this location

Alarm to enter / exit



Create a new Perimeter




Set up a temperature alarm. Receive an alarm once the preset temperature is reached. Based on the temperature around the device. The device can be up to 10 degrees warmer, as it a little PC.



Here you can preset a high-speed alarm. In the event the vehicle goes over this speed, you will receive the alarm.




Need to find your vehicle? Simply press "Locate" - using the built-in GPS, your vehicle's current location will be displayed.



Press the **Bell** Icon to get a new location update. If you have good signal, this may take anywhere from 30 seconds to 2 minutes.

Refresh
Refreshes the map page.




Make a Claim (Subject to your region/country)

If you have had an at-fault collision and made a claim with your car insurer.

Click “select” and download the form to receive a refund for your excess.


The email address is located on the form.



User Manual

A digital version of this manual.




Easy to read and can be updated in the app when new features are added.





Alarms

Here you can view all the alarms that you have received. All historical alarms are saved here and can be deleted.

A red dot indicates that you have unread alarms.




Click on the alarm.




Products (Post Purchase)

Be sure to view this tab from time to time as there will be exclusive specials on all vehicle-related products after you take delivery.

Loyalty discounts will be applied.



Navigating the Settings:



Map – The mapping platform used.

Low Battery - Only applicable for the battery-powered units.

Tamper - Notification sent if the device is removed.

Password – Change your login password.

About – Details about the product.

Current Version – Your current app version.

Frequently asked Questions:

Why am I not receiving the alarms?

- Head to your phone's settings, find the App, and ensure "Push Notifications" are turned on.
- Ensure that you have turned the alarm/s "on" within the app.
- If your device is in an area that is out of GPS signal, it may delay the alarm from being sent. An example, in the basement of a building.
- Your mobile phone must be within a mobile coverage area to receive the alarm notifications from the device.
- On rare occasions, when your smart alarm has been fitted within your vehicle, it may be causing interference. To test this, unplug the device and plug it into a power bank outside the vehicle. Test by using the "Locate" function.

The temperature doesn't seem accurate:

The temperature of your device will be higher than your car's cabin temperature. Much like any computer, it will generate its own heat.

My smart alarm doesn't seem to be working:

First, locate where the device has been installed, usually within arm's reach of the driver. Unplug the USB-C power cord and plug it back in. You should see a "red" light come on.

I activated/registered my device in the app, but I did not receive the activation letter:

The letter will be sent to the same email address you entered on the registration form. Please check your spam and junk folders. If you still have not received the letter, please head to www.auto-guard.com.au/contact with your name, surname, plan length, product number, and vehicle's registration/plate number. Some email programs may block the content; try viewing it on another device.

Warranty:

Important:

You must register your smart alarm and activate the excess benefit within 7 days of purchase. If registration is not completed within this period, your coverage will be deemed to commence from the retailer's date of sale, not the date of activation.

This product (The Smart Alarm unit) is covered by a **24-month limited warranty** (Unless otherwise specified by your retailer) against defects in materials and workmanship under normal use from the date of purchase.

The warranty does not cover:

- Damage due to misuse, accident, modification, or improper installation.
- Consumable components such as batteries (unless damaged due to defects).
- Loss or damage resulting from external causes, including, but not limited to, power failures, weather conditions, or network outages.
- The warranty is non-transferable.

Warranty Card:

Retailers Name:

Client's Full Name:

Date Of Purchase:

Warranty End Date:

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important Note:

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.