


Ice Maker



SLICM63



IMPORTANT SAFETY INFORMATION	01
PRODUCT INTRODUCTION	04
CONTROL PANEL INTRODUCTION	05
USING YOUR ICE MAKER	06
CLEANING AND MAINTENANCE	10
PRODUCT SPECIFICATIONS	13
TROUBLESHOOTING	14
WARRANTY INFORMATION	17

IMPORTANT SAFETY INFORMATION

To reduce the risk of injury or property damage, please follow these safety precautions.

WARNING



- Voltage power from outlet must match specifications on appliance nameplate.



- This appliance **must be** grounded.



- Using an extension cord may cause overheating and increase the risk of fire.

If an extension cord **MUST** be used:

- 1) **Only use an** extension cord with grounding plug.
- 2) The marked rating of an extension cord **must be** equal to or greater than the rating of this appliance.

- **Do not** operate if any component, including the cord or plug, is damaged.
- Unplug the unit before cleaning by hand.



- Only responsible and capable adults should operate the ice maker.
- **Do not** place the power cord where it could be pulled by children or pose a tripping hazard.
- Children should not be left unattended near the ice maker during operation.



- **Do not** use water that is micro-biologically unsafe or of unknown quality.



- **Do not** remove any safety, warning, or product information labels from the unit.



- **Do not** touch the evaporator with your hands while the ice maker is operating.
- **Do not** plug in or unplug the unit with wet hands.



- **Never** put flammable, explosive and corrosive articles into the ice maker.



- The unit **must be** placed and set up according to installation instructions before use. The unit is for indoor household use only.



- **Do not** store or use flammable vapors or liquids near the unit.
- **Do not** immerse any part of the unit in water.



- **Do not** attempt to disassemble, repair, modify or replace any part of the ice maker unless permitted by the manufacturer.



WARNING

FIRE OR EXPLOSION HAZARD Flammable Refrigerant

This unit contains an isobutane refrigerant, also known as R600a, a natural gas with high environmental compatibility. However, it is also combustible. Adhere to the warnings below to reduce the risk of injury or property damage.

WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.

WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.



1. When handling, installing, and operating the unit, care should be taken to avoid damage to the refrigerant tubing.



2. Keep ventilation openings around the unit's enclosure clear of obstruction.



3. **Do not** place the unit near heat sources such as an oven.



4. Ensure a minimum of 6" of clearance around the side and back walls of the unit for proper air circulation.



5. **Do not** place the unit in direct sunlight.



6. Risk of fire or explosion. Flammable refrigerant used. **Do not** use mechanical devices to defrost the unit. **Do not** puncture or damage refrigerant tubing.



7. Only dispose of the unit according to Federal and Local Regulations. Contact your local authorities for the environmentally-safe disposal of the unit.




ATTENTION

- The ice maker parts should be replaced with parts that have the same specifications and the maintenance should be done by authorized service personnel, to minimize the risk of fire hazards due to incorrect parts or improper operation.
- The ice maker should be installed in accordance with the Safety Standard for Refrigeration Systems, ASHRAE 15.
- The ice maker should not be installed in hallways or corridors of public buildings.

SAVE THESE INSTRUCTIONS.

PRODUCT INTRODUCTION



1. Removable Top Cover

2. Viewing Window

3. Control Panel

4. Ice Outlet

5. Drawer Water Tank

6. Water Level

7. Water Dripping Tray
(with Removable Cover)


8. Air Outlet






9. Water Drain Hose

10. Air Inlet

11. Power Cord

CONTROL PANEL INTRODUCTION



	Button/Icon	Function
1	 ICE/CLEAN	After plugged into power, the machine enters standby mode. Press this button to start making ice. <hr/> In standby mode, press and hold this button for more than 5 seconds to enter self-cleaning mode.
2		Press this button to dispense ice cubes. Press it again to stop the ice dispensing.
3	 CLEAN	The indicator light turns on when in the self-cleaning mode.
4	 ICE FULL	The indicator light turns on when the ice storage bin is full.
5	 ADD WATER	The indicator light turns on when the water tank is low.

USING YOUR ICE MAKER

BEFORE FIRST USE


1.

Verify all parts and ice maker accessories were received.

Missing parts? Contact Customer Service.



Stand upright for 24hrs.




Use in locations
50°F ~ 90°F
(10°C ~ 32°C).




2.

Carefully **remove the protective film** and clean the ice maker thoroughly before first use.

Note: Make sure the water drain hose is installed in place.



Put all parts back in place. Install the water dripping tray.




It is recommended to run a self-cleaning cycle before the first use or after a long period of non-use. Then discard the first cycle of ice cubes produced.




3. What Not To Do!


No other liquids
(Drinking water only).




Do not use in high or low temps,
especially **lower than 41°F/5°C**.



Unstable base.




After filling, make sure to fully
push the drawer water tank in.



HOW TO USE YOUR ICE MAKER


1.

Remove the water tank,
then add water.




2.

Push hard to place the water tank into place.



3.

Press the  ICE/CLEAN button.




4.

Wait for some time. The ice-making time depends on room temp and water temp.



Due to temperature variations and other factors, ice quality should become stable after 5 minutes of continuous ice cube release.




More Cycles = Perfect Shape


5.


If needed, press the  button to get ice early. Ice dispensing will stop automatically after 60 seconds.

Note: Sufficient ice cubes are required for ice-dispensing function.







DONE:

 ICE FULL stays illuminated when the ice storage bin is full.




REFILL:

When  ADD WATER turns on, ice-making will stop. Refill water, then press the  ICE/CLEAN button to restart the machine.



After one cycle of ice-making completes, perform ice-dispensing before they start to melt.



Note: After accidental power-off, it takes a little more time to restart the ice maker.

CLEANING AND MAINTENANCE


To keep your ice tasting fresh and the unit looking great, we recommend cleaning the unit once per week.

SELF-CLEANING (20-MIN PROCESS)

1.

Add 100% vinegar to the water tank, then put the water tank back into the machine.


Note: In areas with hard water, professional ice maker detergent can be used to clean the ice maker. Leave the detergent in the machine for 12 hours.



2.


IN STANDBY MODE:

Press the  **ICE/CLEAN** button for 5 seconds to start self-cleaning.




3.

Pull hard to remove the drain plug from the drain hose to drain excess water over sink. Then repeat the process several times using clean water to ensure the machine is thoroughly cleaned.



4.

Wipe the exterior with a cloth using mild dishwashing soap.




MANUAL CLEANING

Turn off the unit and disconnect from power before cleaning.


1.

Remove the top cover, the water tank, and the water dripping tray.




2.

Add 100% vinegar, then leave it in the machine for a period. Clean the drawer water tank, the cavity, and other small corners to prevent dirt buildup.




3.

Pull hard to remove the drain plug from the drain hose to drain excess water over sink. Then repeat the process several times using clean water to ensure the machine is thoroughly cleaned.




4.

Put all parts back into the machine. Wipe the exterior with a cloth using mild dishwashing soap.



⚠️ Tips for Drain Hose

Route the drain hose flat and avoid bending it. Do not immerse the drain hose outlet in water.



⚠️ DO's & DON'Ts while cleaning and maintaining

- **Do not** use organic solvent, boiled water, strong acid and strong alkali etc. for cleaning. This will cause corrosion of the evaporator.
- Considering the wide range of water quality across different regions, it is recommended to perform regular manual cleaning.
- Limescale can easily form if the water tank is submerged in water for a long period of time. Drain water if the machine is not in use.
- It is recommended to **drain the water tank** at least once every three days.
- When the unit is not to be used for a long duration, **drain** the water completely & dry the interior.
- **Store** in a well-ventilated area.


PRODUCT SPECIFICATIONS

Voltage/Frequency	115V~ / 60Hz
Electric Current	1.7A
Water Tank	0.5 gal (1.8L)
Ice Storage Capacity	1.5 lbs (0.7kg)
Ice-Making Rate	40 lbs (18kg) per Day
Ice Shape	Nugget
Material	ABS, PP, Stainless Steel
Product Size	Water Dripping Tray Not Included 15.7 x 6.7 x 13.5" (403 x 170 x 342mm)
	Water Dripping Tray Included 16.4 x 6.7 x 13.5" (416 x 170 x 342mm)

TROUBLESHOOTING

Problem	Possible Causes	Solution
Poor ice shape or quality.	Poor heat dissipation.	Leave a 6" (15cm) clearance on all sides of the ice maker for ventilation.
	The water temperature is too high.	The water temperature should be 45°F - 90°F.
	The ambient temperature is too high.	Use the ice maker in room temperatures between 50°F and 90°F.
Ice maker creating loud noise.	If the ice maker has not been cleaned for a long time, a residue may form around the inlet of the water pump.	Run the self-cleaning program using professional ice maker detergent and leave the detergent in the machine for 12 hours to remove scale.
		Clean every week using mild cleaning agents.
	Lack of water to pump will create noise when pumping water.	Add more water.
	Machine overload.	The water temperature should be 45°F - 90°F.
		Maintain 6" (15cm) distance between the hot air outlet and the wall.
	Fan or ice maker is damaged.	Please contact customer service.
Water pump is damaged.		

Problem	Possible Causes	Solution
☐☐☐ ICE FULL indicator light turns on.	There is too much ice, or there is no ice being detected.	Remove the ice promptly or wipe the infrared sensor.
	Infrared sensors do not work.	Press and hold the ⏻ ICE/CLEAN button for more than 5 seconds to run the ice-making cycle for 50 minutes. Contact customer service if the infrared sensors still don't work.
⏻ ICE/CLEAN indicator light flashes red.	Ice is sticking together.	The evaporator may be frozen. Power off for 2 hours, then run the self-cleaning cycle.
	Water pump malfunction.	Please contact customer service.
	Refrigeration system malfunction.	
⏻ ICE/CLEAN indicator light flashes fast, then slowly.	Ice is sticking together.	The evaporator may be frozen. Power off for 2 hours, then run the self-cleaning cycle.
	Ice release device malfunction.	Please contact customer service.
Water leakage.	The drain plug is not installed properly or is damaged.	Reinstall the drain plug or contact customer service for replacement.
	Water pipe joints may be loose.	Please contact customer service.

Problem	Possible Causes	Solution
Not making ice.	Low water level or not enough water.	Refill water, press the  ICE/CLEAN button to restart and try again.
	The water tank is not fully pushed in.	Push hard to place the water tank into place.
	The floating ball is not rising in the ice-making cavity.	Remove the top cover and clean the ice-making cavity.
	If the ice maker has not been cleaned for a long time, a residue may form around the inlet of the water pump.	Perform regular cleaning every week using professional detergent. Leave the detergent in the machine for 12 hours to remove scale.
	Ambient or water temperature is too high.	Keep ambient temperature less than 90°F and fill with colder water.
	Water pump is damaged.	Please contact customer service.
	Refrigerating system leaking.	
	Refrigerating system blocked.	
	The fan stopped working.	
	The wires are loose.	
The gears in the motor are broken.		

WARRANTY INFORMATION

30-DAY LIMITED WARRANTY

To provide customers with a quality shopping and user experience, the unit can be replaced or returned for a full refund within the 30-day period from the date of purchase.

30-DAY TO 1-YEAR LIMITED WARRANTY

After the 30-day warranty has expired, a 1-year warranty from the date of purchase that covers product replacement is automatically activated. Please note that proof of purchase is required for all warranty claims.

30-DAY TO 1-YEAR WARRANTY LIMITATIONS

This warranty does not cover:

- Any condition resulting from incorrect or inadequate maintenance or care.
- Damage resulting from misuse, abuse, negligence, accidents, or shipping damage.
- Dissatisfaction due to buyer's remorse.
- Normal wear and tear.
- Damages incurred after initial transportation.

Thank You

for Choosing Us!

860-04405-00 V1

