


Intelligent visual doorbell

Instruction manual V1.0

1 Appearance introduction: Doorbell:



Ding dong:



Indicator light Speaker Pairing key Volume size
Music toggle USB Charging Port

1. Download mode of APP:

For Android phones, it can be downloaded from its own app market or APP Treasure Search [IT Life]. For iOS phones, search for 'IT Life' in the APP Store to download.



2. APP registration:


- For the first download and use, please click "Register". If you have an account, click "Login".
- Click "Register", read "Privacy Policy", and click "Agree". Enter a valid mobile

phone number or email address and click Continue. Then enter the verification code to log in to the APP. Try Now login can not add doorbell devices normally, please register and log in.)

3. APP permissions pop-up prompts, such as message push, access geographical location, connect peripheral devices, etc., please set to 'Allow'.


IV. Adding a device:

- Turn on the Bluetooth and location permission functions of the mobile phone.
- Press the doorbell button to turn on the device. When using it for the first time, press the doorbell button twice in a row to start the device. The working indicator light will flash, and the device will enter the distribution network mode.
- Open the APP, enter the "Home page", click '+' on the upper right corner of the page, the APP will automatically scan and discover the device, click 'Add'.



Note:

- If the device is not automatically searched, please click "Turn on Bluetooth" in the picture below and set "Allow device permissions near this application".




- Access permission management, enable WLAN, Bluetooth, and nearby devices, and select Always Allow.



- After adding the doorbell, select the 2.4GHz WiFi network and enter the password. Then, click Next. Please keep the router, phone, and doorbell as close as possible. After successful addition, click Finish.

(Note: If the connection is not successful, please reset the device and reconnect)




- After fully charging the doorbell, install it within the range of WiFi signal coverage and good signal.
- Kind Reminder:**
When charging, the charging indicator light is red.
After being fully charged, the charging indicator light goes out.

V. Doorbell and Ding Dong matching



- Power on the ding Dong machine (left).
- Long press the pairing button of the ding Dong machine for 3 seconds (as shown in the picture), and the indicator blinks.
- Press the doorbell button (right), the ding Dong machine rings, that is, the match is successful.



V1. Mobile message push

Enter mobile phone - Settings - notification and status bar - Application notification management - open IT life APP notification permission, enable notification, suspension, lock screen, sound reminder and other notification functions.

(Note: Due to different mobile phone models, the operation interface and options are different, please choose independently)

V. Function Introduction:

- V1. Video call:** When a visitor rings the doorbell, the mobile app will receive a reminder notification and click on the push pop-up to enter the video, long press to conduct intercom.
- APP remote monitoring:** When you want to observe the outdoor situation, you can remotely check the situation at the door through the mobile APP.
- Device sharing:** Enter the real-time interface of the APP, click on Settings - Share Device - Add Share - Enter Account in the upper right corner.
(Note: Shared members need to download and register the 'IT Life' app first)
- Night vision:** Equipped with a photosensitive sensor, the LED light automatically turns on in dark environments.
- Low battery reminder:** When the battery level is low, the app will push a low battery reminder, please charge it in a timely manner.
- Work indicator light:** Work status. Blue indicator light is always on. Distribution network status: Blue indicator light flashing. Charging status: The red indicator light is always on, fully charged and turned off.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

IX. Common problems:

What should be noted before use?

R: Before use, please carefully read our user manual and follow the detailed steps. When taking to the doorbell, please place your phone at least 5m away from the doorbell to avoid signal interference or noise.

When does the doorbell need to be restarted and how to reset it?

R: When the doorbell cannot work properly or cannot connect to the phone, it needs to be restarted and reset. Press and hold the 'Reset' button, hear a "beep" prompt sound, restart and reset, and then add the device again.
What should I do if the repeated addition of devices fails?

R: After the first failed addition, please restart the doorbell, long press the 'Reset' button, hear a "beep" prompt sound, and then try adding again. The device only supports 2.4GHz WiFi network. Please ensure that you are using a 2.4GHz WiFi network and enter the correct WiFi password.

Note: 5G networks are not currently supported, and all routers will have a 2.4GHz WiFi network option.

4. Can't preview and watch the doorbell video correctly?

R: Check if the network is functioning properly and bring the doorbell closer to the router. If it still cannot be used, please restart the doorbell and add it again.

5. How to change the doorbell network to another router?

R: First delete the device on the app, and then reconfigure the network for the doorbell.

6. Why am I unable to receive push message notifications through my mobile app?

R: Please ensure that the app is running properly on your phone and that the phone system has enabled relevant push functions such as SMS notifications and permission confirmation.

7. Equipment installation location?

R: Do not install doorbells on metal doors to prevent them from blocking WiFi signals. When installing the doorbell, please follow the user manual to complete the operation. After testing that the doorbell is working properly, install it in the best signal position.

