



User manual Steam Iron





















FIRST USE *



WATER TANK FILLING *



TEMPERATURE AND STEAM ADJUSTMENT

					
			DRY	STEAM / AUTOSTEAM (**) (*)	
 AUTOSTEAM (**) (*)	LINNEN LIN LINO	•••			
	COTTON COTON ALGODÓN	•••			
	WOOL LAINE LANA	••			
	SILK SOIE SEDA	••			
	NYLON NYLON NYLON	•			

SETTING THE TEMPERATURE (*) (**)

Ironing label	Fabric	Temperature Control
	NYLON NYLON NYLON	•
	WOOL LAINE LANA SILK SOIE SEDA	••
	LINNEN LIN LINO COTTON COTON ALGODÓN	•••

DRY IRONING *




SHOT OF STEAM *




SPRAY *




VERTICAL STEAM (•••) *




AUTO-OFF *





IRON STORAGE *




SELF-CLEANING (EVERY 2 WEEKS) *





SOLEPLATE CLEANING *



IMPORTANT SAFETY INSTRUCTIONS

When using an iron, basic precautions should always be followed, including the following :

Read all instructions before using the iron

1. Only use an iron for its intended use.
2. To avoid the risk of electric shock, do not immerse the iron in water or other liquids.
3. Always turn the iron OFF before plugging or unplugging the iron from the electrical outlet. Never pull on the cord to disconnect the iron from the electrical outlet; instead, grasp the plug and pull on the plug to disconnect the iron.
4. Do not let the cord touch hot surfaces. Let the iron cool completely before putting the iron away. Coil the cord loosely around the iron when storing.
5. Always disconnect the iron from the electrical outlet before filling the iron with water, emptying the water from the iron, and when the iron is not in use.
6. Do not operate the iron with a damaged cord or in the event the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron. Take it to a

qualified serviceman for examination and repair. Incorrect assembly might result in a risk of electric shock when the iron is used after reassembly.

7. Close supervision is required for any appliance used by or near children. Do not leave the iron unattended while the iron is connected or on an ironing board.
8. Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a STEAM IRON upside down – there might be hot water in the reservoir.
9. In the event the malfunction indicator goes on, the iron is not operating properly. Disconnect the iron from the electrical outlet and have the iron serviced by qualified service personnel.
10. This appliance is not intended for use by children and other persons whose physical, sensory, or mental capabilities or lack of experience and knowledge prevents them from using the appliance safely without supervision or instruction by a responsible person to ensure that they can use the appliance safely.
11. Children should be supervised by the responsible person to ensure that they do not play with the appliance.
12. The iron must be used and rested on a stable surface;
13. When placing the iron on its stand, ensure that the surface on which the stand is placed is stable;
14. The iron is not to be used if it has been dropped, if there are visible signs of damage or if it is leaking.

SPECIAL INSTRUCTIONS

15. To avoid a circuit overload, do not operate an iron on the same circuit with another high wattage appliance.

16. If an extension cord is absolutely necessary, a cord with an ampere rating equal to or greater than the maximum rating of the iron shall be used. A cord rated for less amperage can result in a risk of fire or electric shock due to overheating. Care shall be taken to arrange the cord so that it cannot be pulled or be tripped over.

SAVE THESE INSTRUCTIONS

What water to use?

Your appliance has been designed to function with untreated tap water. If your water is very hard (check with your local water authority), it is possible to mix untreated tap water with store-bought distilled or demineralised water in the following proportions:

- 50% tap water, - 50% distilled or demineralised water.

However, it is necessary to operate the Self clean function regularly in order to eliminate hard water deposits from the steam chamber.

Use the Self clean function approximately every 2 weeks. If the water is very hard clean the iron weekly

Types of water not to use?

Heat concentrates the elements contained in water during evaporation. The types of water listed below contain organic waste or mineral elements that can cause spitting, brown staining, or premature wear of the appliance: water from clothes dryers, scented or softened water, water from refrigerators, batteries or air conditioners, pure distilled or demineralised water or rain water should not be used in your Rowenta iron. Also do not use boiled, filtered or bottled water.

Automatic 3-position cut-out*

If, although switched on, the appliance is not moved, it will automatically switch off and the auto off light will blink after the following intervals:

- After 30 sec., if the iron is left placed down on the soleplate or lying on its side.
- After 8 mins., if the iron is left standing on its heel.

To switch the iron back on, move the iron gently.

Autosteam*

Your iron is equipped with the Autosteam system, it automatically adjusts the steam amount and the temperature based on the selected fabric.

Select the fabric to be ironed on the thermostat dial.

You can also set your iron based on the international temperature measurements.



For each fabric, the iron will automatically adjust the steam rate for optimum performance.



If there is a problem?



PROBLEM	POSSIBLE CAUSE	SOLUTION
Water drips from the holes in the soleplate.	You are using steam while the iron is not hot enough.	Wait until the thermostat light goes out.
	You are using the shot of steam button too often.	Wait a few seconds between each use of the button.
	You have stored the iron horizontally, without emptying it and without setting it to  .	See the section "Storing your iron".
Brown streaks come through the holes in the soleplate and stain the linen.	You are using ironing water additives (i.e. scented water, starch).	Never use ironing water additives; these will permanently damage your steam iron.
	You are not using the right type of water.	Perform a Self cleaning operation and consult the chapter "What water should I use?".
	Your linen has not been rinsed sufficiently or you have ironed a new garment before washing it.	Make sure that your laundry is rinsed sufficiently in order to remove any deposits of soap or chemical products on new clothes.
The soleplate is dirty or brown and can stain the linen.	You are ironing with an inappropriate temperature selection (temperature too high).	Clean the soleplate (refer to chapter 11). Select the appropriate program.
	You have ironed over a printed area of a garment.	Never iron over printed areas or applications – always iron the reverse side of such a garment.
There is little or no steam.	The water tank is empty	Fill the water tank.
	Your iron has been used dry for too long.	Carry out a Self clean.

The soleplate is scratched or damaged.	You have placed your iron flat on a metallic rest-plate or ironed over a zip.	Refrain from ironing over metallic buttons or zippers.
Steam or water come from the iron as you finish filling the tank.	The steam control is not set to the DRY  position.	Check that the steam control is set to the DRY  position.
	The water tank is overfilled.	Never exceed the Max level.
The spray does not spray.	The water tank is not filled enough.	Fill up the water tank.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.