


USER MANUAL BEVERAGE COOLER

PARTS DESCRIPTION



PLACEMENT

- Before using the cooler, remove all packaging materials, including bottom cushions, foam pads, and tape inside the cooler. Tear off the protective film on the door and the cooler body.
- Make sure the cooler is placed in a well-ventilated, indoor environment on flat, sturdy ground (rotate left or right to adjust the wheel to level if unstable).
- Please operate this beverage cooler in a room of 133 cubic feet (or larger) for safety concern.
- Avoid putting the cooler in direct sunlight or too close to a heat source. Keep a safe distance of at least 30 cm between the cooler and a stove or furnace if it can't be avoided. We also advise applying an insulation board in that case.
- Keep a circulation space of at least 4 cm on both sides of the cooler to preserve power

OPERATION

PROPER USE OF BEVERAGE COOLER

Energy Conservation

- The cooler should be placed in a room that is dry and ventilated. The cooler cannot be placed under direct sunlight or next to a heat source (such as a radiator, stove, etc.), and a suitable insulation board must be applied if necessary.
- Try to shorten the opening time of cooler's door.
- Avoid putting warm beverages in the cooler.

Installation

- Keep in upright position for 24 hours before initial power up.
- While the cooler is empty, set the Temperature Control to maximum and leave for 1 hour.
- When you start putting beverages inside the cooler, maintain a 4 cm gap between the interior wall of the cooler and the beverages to keep the proper airflow.
- Follow steps below if you want to change the door orientation from left-hinge to right-hinge:
 1. Use a screwdriver to remove upper and lower left hinge (triangle with 3 screws).
 2. Transfer the hinge to the right of the cooler and attach to the right side of the door.

INTRODUCTION TO THE BEVERAGE COOLER'S FUNCTIONS

Display Controls

- When turning on for the first time, the display screen will be a full display for 3 seconds and the startup tone will ring.
- Standby Mode
- To activate standby mode, hold the standby button for 3 seconds. You will hear a beep and the display area will be cut off. To deactivate standby mode, press the button again. You will hear a beep and the standard display will show.

Lighting

Press the lighting button to turn the light on or off.

Temperature

Setting Press the increase temperature button to increase the temperature one degree at a time. Press the decrease temperature button to decrease the temperature one

degree at a time. To change display from OF to OC, press and hold the increase and decrease button simultaneously for 5 seconds.

Memory

Function If turned off, this cooler will remember any settings in place and will work according to those settings once it's turned on again.

Fault Indicators

If any of these indicators are displayed, it means the cooler has the following issues

FAULT CODE	DESCRIPTION
E1	R room sensor failure
E4	R room defrost sensor failure

MAINTENANCE

DISCONNECTING THE BEVERAGE COOLER

Unplug the power plug from the socket to disconnect the cooler.

CLEANING YOUR BEVERAGE COOLER

Dusting behind the cooler and on the ground will improve the cooling effect and save energy. The interior of the cooler should be cleaned to avoid any odor. Follow the cleaning procedure below: 1. Unplug the cooler. 2. Wipe the door seal with warm water. 3. Use soap and warm water to clean the cooler. 4. Reconnect the cooler when the cooler is clean and dry



TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSES	POSSIBLE CAUSES
Cooler isn't cool	The door is being opened too often. The cooler is too full of bottles or cans.	Reduce the frequency of opening the door and give it 4-5 hours.
Cooler is not refrigerating	The power is out or the cooler isn't plugged in.	Check the power. Make sure that the cooler is plugged in.
LED light is off	The LED light is broken.	Contact customer support.
Condensation on the glass door	The temperature is set too low or too high	Increase the temperature and use a rag to wipe away any drops of water.

IMPORTANT SAFETY INSTRUCTIONS

- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not store explosive substances, such as aerosol cans with flammable propellant, in this appliance.
- Do not use extension cords or ungrounded (two-prong) adapters.
- This appliance is intended to be used in households and similar applications, such as staff kitchen areas in shops, offices and other working environments; hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.
- Do not pull the power cord when pulling the power plug of the beverage cooler. Please firmly grasp the plug and pull it out from the socket directly

WARNINGS RELATED TO ELECTRICITY

- Do not damage the power cord under any condition.
- Please use a dedicated three-hole power socket, which is 15A or more and not shared with other electrical appliances.
- Please ensure that the grounding electrode of the power socket is equipped with a reliable grounding line.
- The beverage cooler uses an AC power supply of 115V/60 Hz.



- In case of leaking gas, turn off the leaking valve and open your doors and windows. Do not unplug the cooler yourself, as it may cause a fire. Contact customer support.
- For your safety, don't place electric devices on top of the cooler, like microwaves or electric kettles, and don't store your beverage cooler inside pantries.

WARNINGS RELATED TO USE

- Make sure the cooler is placed in a well-ventilated, indoor environment on flat, sturdy ground (rotate left or right to adjust the wheel to level if unstable).
- Be careful not to get fingers or dangling accessories caught in the cooler door.
- This cooler and its packaging are not intended to be played with or used by children. If a child is using the cooler, it must be with adult supervision to avoid injury.
- Keep the cooler out of moist, damp, or humid environments and situations, so as not to damage the electrical insulation.
- Do not use a base, cooler door, etc. as pedal or support.
- Do not place heavy objects on top of the cooler to prevent accidental damage or injury.

WARNINGS RELATED TO PLACING ITEMS

- Do not put flammable, explosive, volatile, or highly corrosive items in the cooler to prevent damages to the product or re accidents.
- Do not place flammable items near the cooler to avoid a fire hazard.
- This product is for household refrigeration appliances, mainly used for the storage of beverages. It's not used for other purposes, such as storage of blood, drugs, and biological products.
- Do not cover or close ventilation and exhaust holes.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.