

Model: 2209798

## Overview

This electric rice cooker is designed to cook rice and other grains automatically. It features a 6-cup cooked capacity (3 cups uncooked), a removable nonstick inner pot, a tempered glass lid, and automatic keep-warm and shutoff functions.



## Features & Components

### Main Unit

- **Housing:** Black exterior with cool-touch handles.
- **Control Panel:** Single button for one-touch operation.
- **Indicator Lights:** Lights for Cooking, Done, and Keep Warm statuses.

### Removable Parts & Accessories

- **Inner Pot:** Nonstick, removable cooking pot with measurement markings for rice and water.

- **Lid:** Tempered glass lid with a steam release vent.
- **Steamer Tray:** For steaming vegetables or other foods.
- **Measuring Cup:** Provided for measuring uncooked rice.
- **Rice Paddle/Spoon:** For serving.



## **6-CUP CAPACITY**

Holds 6 cups of cooked rice or grains



## Key Specifications

- **Capacity:** 6 cups cooked rice (3 cups uncooked).
- **Power:** 300 Watts, Corded Electric.
- **Dimensions:** 9.8"D x 8"W x 8.2"H.
- **Weight:** 1.59 kg.
- **Special Features:** Automatic Keep Warm, Automatic Shut Off.

## Safety Information

### Important Safety Instructions:

- Read all instructions before using the appliance.
- Do not immerse the cord, plug, or main housing in water or other liquids.
- Use the cool-touch handles when moving the unit.
- Ensure the inner pot is correctly seated before operating.
- Unplug the unit when not in use and before cleaning.

- This appliance is for household use only.

## Use Guide

### Before First Use

1. Remove all packaging materials and stickers.
2. Wash the inner pot, lid, steamer tray, measuring cup, and rice paddle in warm, soapy water. Rinse and dry thoroughly. The inner pot is dishwasher safe.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse it in water.

### Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to portion uncooked rice. One level cup of uncooked rice yields approximately two cups of cooked rice.
2. **Rinse Rice (Optional):** Rinse the rice in a separate bowl until the water runs clear to remove excess starch.
3. **Add Rice and Water:** Place the rinsed rice into the inner pot. Add the corresponding amount of water. Use the water level markings inside the pot as a guide for the correct

water-to-rice ratio.



## INCLUDED ACCESSORIES

Measuring cup & spoon

4. **Assemble:** Place the inner pot into the cooker base. Ensure it sits flat and is properly aligned. Place the glass lid on top.
5. **Cook:** Plug in the appliance. Press the cooking button down. The "Cooking" indicator light will turn on.
6. **Automatic Cycle:** The rice cooker will automatically switch to "Keep Warm" mode once cooking is complete. The "Done" or "Keep Warm" light will illuminate. The rice can be kept warm for several hours.
7. **Serve:** Unplug the unit. Use the cool-touch handles. Fluff the rice with the provided paddle and serve.

### Using the Steamer Tray

1. Add water to the inner pot, ensuring the water level is below the bottom of the steamer tray.
2. Place prepared food (e.g., vegetables, dumplings) in the steamer tray.
3. Place the steamer tray into the inner pot. Cover with the glass lid.
4. Press the cooking button. Steam until food is cooked to your preference.



## Cooking Other Grains

The appliance can be used for other grains like quinoa or oatmeal. Refer to the grain's packaging for water ratios and use the inner pot markings as a general guide. The automatic cooking and keep-warm functions will operate as with rice.

## Indicator Light Guide

- **Cooking Light (On):** The heating element is active, and cooking is in progress.
- **Done / Keep Warm Light (On):** Cooking cycle has finished. The unit is now in keep-warm mode, maintaining a safe serving temperature.
- **No Lights:** The unit is unplugged or the cooking cycle has not been started.

## Care & Cleaning

1. **Unplug** the appliance and allow it to cool completely.
2. **Inner Pot, Lid, Steamer Tray, & Accessories:** These are dishwasher safe for easy cleaning. They can also be washed by hand with warm, soapy water. Use a soft sponge or cloth. Do not use abrasive cleaners or scouring pads on the nonstick surface.

3. **Exterior & Heating Plate:** Wipe the exterior housing and the interior heating plate with a damp, soft cloth. Do not use abrasive cleaners or immerse the base in water.
4. **Drying:** Ensure all parts are completely dry before reassembling or storing.



## Troubleshooting

- **Rice is undercooked or watery:** You may have used too much water. Use the measurement markings in the pot for guidance.
- **Rice is burned or stuck to the bottom:** You may have used too little water, or the inner pot was not properly seated. Ensure the pot is clean and the nonstick coating is not damaged.
- **Appliance does not turn on:** Check that the unit is plugged in securely. Ensure the inner pot is correctly placed inside the cooker base.
- **Steam is escaping from the sides:** Ensure the glass lid is properly positioned and seated.
- **Keep-warm function does not activate:** The automatic cycle should switch to keep-warm. If it does not, unplug the unit and allow it to cool before inspecting for any visible issues.

**Warning**

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

---

Document generated by [ManualsFile](#)