

1. Overview

The King Lucky Clip-On Earbuds Gen 3 are open-ear wireless headphones designed for comfort and stability during active use. They feature a clip-on design that does not enter the ear canal, making them suitable for extended wear, sports, and for users who wear glasses.



Key identifiers for your product:

- **Model Name:** i121
- **Style:** Clip-on, Open-Ear
- **Color (as per this manual):** Black

- **Bluetooth Version:** 6.0

2. What's in the Box

Before you begin, verify that your package contains the following items:

- King Lucky Clip-On Earbuds (Left and Right)
- Charging Case
- Charging Cable (USB)
- User Manual (this document)

Note: Eartips are listed as a component but are not typically used with this open-ear design. Please refer to the physical contents you received.

3. Product Features & Parts

3.1 Physical Components



- **Earbud Unit:** Contains the speaker, microphone, and touch control surface.
- **Extended Slim Ear Hook:** The flexible, C-shaped clip that rests over the top of your ear. It is designed to be longer and thinner for reduced pressure.
- **Charging Case:** Holds and recharges the earbuds. Includes a battery status indicator.
- **Charging Contacts:** Located on the stem of each earbud, these connect to the pins inside the charging case.
- **Touch Control Area:** Located on the outer surface of each earbud for controlling playback and calls.

3.2 Technical Specifications

Feature	Specification
Bluetooth Version	6.0
Wireless Range	Up to 10 meters (approx. 33 feet)
Driver Size	13mm Dynamic Driver
Microphone	Dual-Mic with ENC (Environmental Noise Cancellation)
Battery Life (Earbuds)	Up to 7 hours playback (single charge)
Total Battery with Case	Up to 50 hours playback
Charging Time	Approximately 2 hours
Water & Sweat Resistance	IPX5 Rating
Weight (per earbud)	Approximately 5.2 grams
Impedance	16 Ohms
Sensitivity	110 dB

4. Use Guide

4.1 Charging the Earbuds and Case

1. Before first use, fully charge the charging case using the provided USB cable.
2. Place the earbuds correctly into their slots in the charging case. The LED indicator on the case will light up to show charging status.
3. A full charge for the case and earbuds takes approximately 2 hours.

Note: Use only the provided cable or a standard USB charging adapter. Do not use fast chargers that exceed standard specifications.

4.2 Wearing the Earbuds

Embrace the Freedom of Movement

Upgraded C-shaped bridge design
Easily Fits Various Ear Shapes, Ensuring
Secure and Comfortable Wear.



1. Identify the Left (L) and Right (R) earbuds.
2. Hold the earbud by the main body. Gently pull the ear hook to widen it slightly.
3. Hook the curved part over the top of your ear, allowing the speaker unit to rest comfortably in front of your ear canal, not inside it.
4. Adjust the hook until it feels secure and comfortable. The design is intended to be stable during movement.

The open-ear design allows you to hear ambient sounds for safety and lets you wear earrings or glasses comfortably.

4.3 Powering On & Bluetooth Pairing

The earbuds feature automatic pairing.

1. Remove both earbuds from the charging case. They will power on automatically and enter pairing mode.
2. On your smartphone, tablet, or computer, enable Bluetooth in the settings menu.
3. Look for "**King Lucky i121**" in the list of available devices and select it to connect.
4. Once paired successfully, you will hear a confirmation tone. The earbuds will typically reconnect automatically when removed from the case in future use.

4.4 Touch Controls

Tap the touch-sensitive area on the outer surface of either earbud to perform actions.

Action	Function
Tap Once	Play / Pause Audio Answer / End Call
Tap Twice	Next Track
Tap Three Times	Previous Track
Touch and Hold (2 seconds)	Reject Incoming Call Activate Voice Assistant (e.g., Siri, Google Assistant)

4.5 Making and Receiving Calls

- When a call comes in, tap once on either earbud to answer.
- To end a call, tap once.
- To reject a call, touch and hold for 2 seconds.
- The dual-microphone ENC system helps reduce background noise for clearer call quality on your end.

4.6 Care and Maintenance

- **Cleaning:** Wipe the earbuds and case with a soft, dry cloth. Do not use liquids or solvents.
- **Water Resistance:** The IPX5 rating protects against sweat and light rain. Do not submerge in water or use while showering or swimming.
- **Storage:** Always store the earbuds in the charging case when not in use to protect them and keep them charged.
- **Temperature:** Avoid exposing the product to extreme heat or cold.

5. Troubleshooting

Problem	Possible Solution
Earbuds won't power on	Place them in the charging case to ensure they have battery. Charge the case fully.
No sound from one/both earbuds	Check Bluetooth connection on your device. Ensure volume is turned up. Clean the speaker mesh gently.
Earbuds won't connect to device	Place both earbuds back in the case for 10 seconds, then remove to restart pairing. Delete "King Lucky i121" from your device's Bluetooth list and pair again.
Poor call quality reported	Ensure you are in a area with good Bluetooth signal. The ENC microphones work best when the earbuds are worn correctly.
Earbuds disconnect frequently	Move your Bluetooth source device closer (within 10 meters). Avoid areas with high wireless interference.
Charging case LED not lighting	Connect the case to a power source using the USB cable. The cable or power adapter may be faulty.

6. Compliance & Safety

- This device complies with Part 15 of the FCC Rules. Operation is subject to interference.
- Keep the product away from small children to prevent choking hazards.
- Do not disassemble, crush, or puncture the device. Do not expose the internal battery to fire or excessive heat.
- Use this device in a safe manner. Be aware of your surroundings, especially when using open-ear headphones near traffic or in situations where hearing ambient sound is critical.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.