


Main Unit Controls


Front Panel




Remote sensor
Power Indicator

POWER/MENU Button :


- Long Press for power off.
- Short Press for power on / quick menu.
- short press to select options ,or switch the items. Long press to confirm and enter into the items.


Press the  button to open the quick operation menu:




 : Turn off the TV.

P+/P- : Changes the channels.

 : Adjust the volume level.

 : Switch the input source items.

Back view controls and sockets




No.	Name	Description
1	DIGITAL AUDIO OUT	Coaxial digital audio input socket
2	USB2.0	USB port. Connector a USB Storage device for multimedia file playback.
3	LAN	Local area network (LAN) port. Connect a LAN cable to this port to connect to the Network.
4	HDMI	HDMI (High-Definition Multimedia Interface) input.
5	ANT	Connection of the external antenna.
6	AV IN	AV audio/video signal input.


Basic Operation

Turning on and off the TV

■ Turn on the TV

Plug the power cord into a suitable power point, then press the POWER () button, on the lower side of the back panel (or on the remote control, making sure to aim it at the sensor at the front of the TV);

■ Turn off the TV

Press the  button on the remote control to enter standby mode. To power down the TV completely, unplug the power cord from the mains socket.

Do not leave your set in standby mode for long periods of time. If you will not use the TV for a long time, it is recommended to unplug the set from the mains and aerial.

First Time Setup

If this is the first time you run the TV, the Initial Setup Menu will appear in the picture, and the items of this menu also exist in other menus, so you are able to change the values after you set them up.

Tips: Make sure that the antenna or cable TV system connection is made.

■ Set you desired language

Press the ▲/▼ buttons to select the Menu Language, and then press the OK button. Press the ► button to go to the next step.

■ End-User License Agreement

Select Accept and then press the ► button to accept the EULA and go to the next step.

Select View additional details and then press the OK button to read a detailed EULA.

Press the ◀ button to go to previous step.

■ Select your country

Press the buttons to select the country you are living in, and then press the OK button.

Press the ► button to go to the next step. Press the ◀ button to go to previous step.

■ Select your time zone

Press the buttons to select a time zone, and then press the OK button.

Press the ► button to go to the next step. Press the ◀ button to go to previous step.

■ Select your TV environment

Press the ▲/▼ buttons to select the Home Mode or Store Mode and then press the OK button.

- Home is the recommended setting to produce the best energy efficiency. If you want to set Store Mode, a message appears asking you to confirm your choice.

Press the ► button to go to the next step. Press the ◀ button to go to previous step.

■ Network connection (Wired or WIFI)

Press the ▲/▼ buttons to select “Wired” or “Wifi”, and wired or wireless network is enabled respectively. (For more details on connection, please refer to the “Network settings”.)

Select “Skip” and press OK to cancel the network setup and move to next step.

■ Select the antenna type

Press the buttons to select the tuning modes and then press the OK button. (For more detailed information, please refer to Channel menu → Auto Tuning).

Press the ► button to go to the next step. Press the ◀ button to go to previous step.

■ The TV starts Auto Tuning.

NOTE:

- If the TV doesn't receive any channels, please check your aerial connection or the country you selected, and then try an auto search again.
- If the TV just receives some of the channels, it means the aerial's reception isn't good enough and an antenna service is recommended.

Programme Selection

■ Using the ▲/▼ on the panel of TV or ^P▼ on the remote control.

Press P ▲ to increase channel number.

Press P ▼ to decrease channel number.

■ Using 0- 9 Digital Buttons.


You can select the channel number by pressing 0 to 9. Example:


To select - channel (e.g. Channel 5): Press 5.

To select -- channel (e.g. Channel 20): Press 2 and 0 in a short time.


Volume Adjustment

- Press the +/- on the panel of TV or +  - on the remote control to adjust the volume.

- If you want to switch the sound OFF, press the .

- You can release mute by pressing the  or increase the volume.

Changing the Input Source

1. You can select the input source by pressing the SOURCE () button on the remote control.
2. Press the arrow button to cycle through the input source, and press the OK button to confirm your choice.

Maintenance

Early malfunctions can be prevented. Careful and regular cleaning can extend the amount of time you will have your new TV. Be sure to turn the power off and unplug the power cord before you begin any cleaning.

Cleaning the screen

1. Here's a great way to keep the dust off your screen for a while. Wet a soft cloth in a mixture of lukewarm water and a little fabric softener or dish washing detergent. Wring the cloth until it's almost dry, and then used it to wipe the screen.
2. Make sure the excess water is off the screen, and then let it air-dry before you turn on your TV.

Cleaning the cabinet

To remove dirt or dust, wipe the cabinet with a soft, dry, lint-free cloth. Please be sure not to use a wet cloth.

Extended Absence

If you expect to leave your TV dormant for a long time (such as a vacation), it's a good idea to unplug the power cord to protect against possible damage from lightning or power surges.

Troubleshooting

Before contact the service technician, perform the following simple checks. If any program still persists, unplug the TV and calling for serving

PROBLEM	POSSIBLE SOLUTION
No sound and picture	<ul style="list-style-type: none"> - Check whether the main plug has been connected to a wall let. - Check whether you have pressed the POWER button on the front of TV set. - Check the picture contrast and brightness settings.
Normal picture but no sound	<ul style="list-style-type: none"> - Check the volume. - Sound muted? Press the MUTE button. - Try another channel, the problem may be with the broadcast. - Are the audio cables installed properly?
The remote control does not work	<ul style="list-style-type: none"> - Check to see if there any object between the product and remote control Causing obstruction. - Are batteries installed with correct polarity (+ to +, - to -)? - Correct remote operating mode set: TV, VCR etc.? - Install new batteries.
Power is suddenly turned off	<ul style="list-style-type: none"> - Is the sleep timer set? - Check the power control settings. Power interrupted. - No broadcast on station tuned with auto activated.
Picture appears slowly after switching on	<ul style="list-style-type: none"> - This is normal; the image is muted during the product startup process. Please contact your service center, if the picture has not appeared after five minutes.
TV freezes and remote function stop working	<ul style="list-style-type: none"> -The internet function might cause TV to freeze or stop responding to remote. - Unplug your TV from power for at least 1 minute. - Plug power back in and turn it on by pressing power button. - Please contact your service center if it still doesn't work.

<p>Poor reception , crackling sound or pixelating on screen</p>	<ul style="list-style-type: none"> - Make sure the antenna cable is plugged in properly. -Rescan the TV channels - Adjust antenna direction to make signal more stronger - Channel good quality antenna cables or socket
<p>HDMI has no picture or sound</p>	<p>Make sure TV is in HDMI mode, press menu then select option menu, go to HDMI EDID setting, change it to ENHANCED if it connect to a 4K device.</p> <p>Otherwise ENHANCED if it connect to a 4K device. Otherwise</p>

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

