

DRCM200 Mini Rice Cooker User Guide

Product Overview

DRCM200 MINI RICE COOKER

One Touch Cooking | 2 Cup Capacity | 200 Watts

Our Philosophy

We believe that taking small steps every day to live a healthier life can have a big impact and that the best path to wellness is to eat whole, natural foods. At Dash, we make products that make it easier for you to prepare and eat real food at home, so that you can feel your best. In the store, in your kitchen, and online we gives you the tools and the support to make delicious healthy meals. That's what living unprocessed is all about!

Important Safeguards

PLEASE READ AND SAVE THIS INSTRUCTION AND CARE MANUAL.

When using electrical appliances, basic safety precautions should be followed:

- Read all instructions.
- Remove all bags and packaging from appliance before use.
- Make sure the appliance is cleaned thoroughly before using.
- Ensure the Rice Cooker and power cord are completely dry before each use.
- Unplug the appliance when not in use and prior to cleaning.
- For maintenance other than cleaning, please contact StoreBound directly at 1-800-898-6970 from 7AM - 7PM PT Monday - Friday or by email at support@storebound.com.
- Only use the appliance on a stable, dry surface.
- Do not place the cord, plug, or unit near water or other liquids. Do not pour liquid into the body of the device.
- **WARNING: Hot steam!** Never place your hands or arms over the Steam Hole while the appliance is in use.
- Never leave appliance unattended when in use.
- Take special care when removing the Lid as escaping steam may cause personal injury.
- Do not touch hot surfaces with bare hands. Use handles or knobs. Use pot holders when removing the lid or handling the Rice Cooker.
- Allow appliance to cool completely before handling or cleaning.

- Never submerge the Rice Cooker body in water or any other liquid.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are provided with supervision and instruction.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use appliance outdoors or for commercial purposes.
- StoreBound shall not accept liability for damages caused by improper use of the appliance.

Parts & Features



Setting Up Your Rice Cooker

Before First Use

1. Remove all packaging material and stickers.
2. Gently wipe down all parts. Do not submerge the Body or Power Cord in water.

3. Wash Removable Pot, Lid, Measuring Scoop, and Mixing Paddle with warm, soapy water and dry thoroughly.
4. Do not use abrasive scrubbers, sponges, or chemical cleaners on the Removable Pot's non-stick surface.
5. Assemble the Rice Cooker by placing the Removable Pot inside the Body and covering with the Lid.

Using Your Rice Cooker

1. Remove the Pot from the Body.
2. Fill the Removable Pot with your ingredients.
Note for white rice: Use the included Measuring Scoop (not a standard cup). Scoop rice, rinse, then fill with water to the corresponding line inside the pot.
3. Place the Removable Pot into the Body and cover with the Lid.
4. Plug the Rice Cooker into an outlet. The Warm Indicator Light will turn on.
5. Press down the Cooking Switch to begin. The Cook Light Indicator will turn on.
6. When the Cooking Switch turns off, check if your food is done. The Warm Light will stay on to keep food warm until unplugged.
7. Use the Mixing Paddle or other non-metal utensils to serve. **Use caution. Appliance is hot.**

Grain Cooking Chart

GRAIN	DRY GRAIN	WATER
White Rice	1 cup	1¼ cups
Long Grain Brown Rice	1 cup	1½ cups
Short Grain Brown Rice	¾ cup	1½ cups
Quinoa	¾ cup	1½ cups water or broth
Sushi Rice	½ cup	¾ cup
Barley	½ cup	1½ cups
Oats (steel cut)	¾ cup	2 cups
Oats (rolled)	¾ cup	1¼ cups

Measurements are based on a standard measuring cup, not the included Measuring Scoop.

Cleaning & Maintenance

- Before cleaning, unplug the Rice Cooker and allow it to cool completely.
- Remove the Pot and wash in warm, soapy water. Never use abrasive or harsh cleaning products.
- For tough stains, soak the Pot in warm, soapy water for 10-15 minutes before cleaning.
- Wash the Lid, Measuring Scoop, and Mixing Paddle in warm, soapy water.
- Wipe the exterior with a slightly damp cloth. Dry thoroughly with a soft cloth.
- Dry all parts completely before storing in a cool, dry location.
- **WARNING:** Do not submerge the Rice Cooker Body in water. Do not use abrasive cleaners.

Customer Support

StoreBound

1-800-898-6970 | @unprocessyourfood | bydash.com

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

Document generated by [ManualsFile](#)