

CONTENTS

- IMPORTANT SAFETY INSTRUCTIONS
- INSTALLATION INSTRUCTIONS
- FILTERS AND ACCESSORIES
- REFRIGERATOR USE
- REFRIGERATOR FEATURES
- FREEZER FEATURES
- REFRIGERATOR CARE
- TROUBLESHOOTING
- WATER FILTER CERTIFICATIONS
- WARRANTY

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury when using your refrigerator, follow these basic precautions:

- Plug into a grounded 3 prong outlet.
- Do not remove ground prong.
- Do not use an adapter.
- Do not use an extension cord.
- Disconnect power before servicing.
- Replace all parts and panels before operating.
- Remove doors from your old refrigerator.
- Use nonflammable cleaner.
- Keep flammable materials and vapors, such as gasoline, away from refrigerator.
- Use two or more people to move and install refrigerator.
- Disconnect power before installing ice maker (on ice maker kit ready models only).
- Use a sturdy glass when dispensing ice (on some models).
- Do not hit the refrigerator glass doors (on some models).

SAVE THESE INSTRUCTIONS

State of California Proposition 65 Warnings:

WARNING: This product contains one or more chemicals known to the State of California to cause cancer.

WARNING: This product contains one or more chemicals known to the State of California to cause birth defects or other reproductive harm.

Proper Disposal of Your Refrigerator

Suffocation Hazard

Remove doors from your old refrigerator.

Failure to do so can result in death or brain damage.

IMPORTANT: Child entrapment and suffocation are not problems of the past. Junked or abandoned refrigerators are still dangerous even if they will sit for "just a few days." If you are getting rid of your old refrigerator, please follow these instructions to help prevent accidents.

Before You Throw Away Your Old Refrigerator or Freezer:

Take off the doors.

Leave the shelves in place so that children may not easily climb inside.

Important information to know about disposal of refrigerants:

Dispose of refrigerator in accordance with Federal and Local regulations.

Refrigerants must be evacuated by a licensed

EPA certified refrigerant technician in accordance with established procedures.

A. Ice maker

B. Air filter

C. Water filter

D. Door bins

E. Crispers

F. Pantry drawer

G. Freezer drawer

H. LED ramp-on lighting

I. In-Door-Ice

What's New Behind the Doors?

Your KitchenAid French Door Refrigerator comes equipped with various innovative storage and energy efficient features.

Energy and Normal Operating Sounds

Your new French Door Bottom Mount refrigerator has been designed to optimize energy efficiency, and better regulate temperatures to match cooling demand. You may notice that it operates differently than your previously owned refrigerator.

It is normal for the high-efficiency compressor to run for extended periods of time at varying speeds in order to consume only the energy necessary for optimum efficiency.

In addition, during various stages of the cooling cycle, you may hear normal operating sounds that are unfamiliar to you.

More Storage Space

The French Door Bottom Mount has the most fresh food storage space available, including a full-width, temperature controlled, pantry drawer perfect for storing veggie trays or party platters.

In-Door-Ice C"Ice Dispensing System

The ice storage bin located in the door provides an entire extra shelf of storage space, and the storage bin is removable for easy access to filtered ice.

Dual Evaporator (on some models)

The refrigerator compartment and freezer compartment have separate evaporators to provide fresh food and frozen food with separate climates.

The refrigerator stays cool and humid for the optimum storage of fresh foods while the freezer stays cold and dry. Humidity from the refrigerator does not mix with dry freezer air, so frost is controlled, which reduces freezer burn. Since no air is shared between the refrigerator and freezer, the transfer of food odors and tastes from the refrigerator to the freezer is eliminated.

Water Filter

Certified filter reduces chlorine taste and odor, particulates (class I), lead, and mercury. Replacing the water filter every 6 months ensures clean, filtered drinking water.

Air Filter

An air filter is 15 times more powerful than baking soda at reducing common food odors inside the refrigerator.

Produce Preserver (on some models)

Ethylene is a natural gas produced by fruits and vegetables to promote ripening. The Produce Preserver absorbs ethylene, to delay the over-ripening of fresh produce.

As a result, certain produce items will stay fresh longer.

Water Dispenser with Measured Fill

The measured fill feature allows you to dispense the desired amount of filtered water.

LED Lighting

The LED lights do not ever need to be replaced.

Door Alarm

A helpful alarm sounds when the refrigerator door or freezer drawer is left ajar.

Power Outage Indicator

If the power should go out while you are away from home, this indicator will let you know that the refrigerator has been without power.

Unpack the Refrigerator

Excessive Weight Hazard

Use two or more people to move and install refrigerator.

Failure to do so can result in back or other injury.

Remove the Packaging

Remove tape and glue residue from surfaces before turning on the refrigerator.

Rub a small amount of liquid dish soap over the adhesive with your fingers. Wipe with warm water and dry.

Do not use sharp instruments, rubbing alcohol, flammable fluids, or abrasive cleaners to remove tape or glue. These products can damage the surface of your refrigerator.

For more information, see "Refrigerator Safety."

Dispose of/recycle all packaging materials.

When Moving Your Refrigerator:

Your refrigerator is heavy. When moving the refrigerator for cleaning or service, be sure to cover the floor with cardboard or hardboard to avoid floor damage. Always pull the refrigerator straight out when moving it. Do not wiggle or "walk" the refrigerator when trying to move it, as floor damage could occur.

Clean Before Using

After you remove all of the packaging materials, clean the inside of your refrigerator before using it. See the cleaning instructions in "Refrigerator Care."

Important information to know about glass shelves

Do not clean glass shelves or covers with warm water when they are cold. Shelves and covers may break if exposed to sudden temperature changes or impact, such as bumping.

Tempered glass is designed to shatter into many small, pebble-size pieces. This is normal. Glass shelves and covers are heavy. Use both hands when removing them to avoid dropping.

Location Requirements

Explosion Hazard

Keep flammable materials and vapors, such as gasoline, away from refrigerator.

Failure to do so can result in death, explosion, or fire.

IMPORTANT: This refrigerator is designed for indoor, household use only.

To ensure proper ventilation for your refrigerator, allow for a 1/2" (1.25 cm) of space on each side and at the top. Allow for a 1" (2.54 cm) space behind the refrigerator.

If your refrigerator has an ice maker, allow extra space at the back for the water line connections.

When installing your refrigerator next to a fixed wall, leave a 33/4" (9.5 cm) minimum space between the refrigerator and wall to allow the door to swing open.

NOTE: This refrigerator is intended for use in a location where the temperature ranges from a minimum of 55°F (13°C) to a maximum of 110°F (43°C). The preferred room temperature range for optimum performance, which reduces electricity usage and provides superior cooling, is between 60°F (15°C) and 90°F (32°C). It is recommended that you do not install the refrigerator near a heat source, such as an oven or radiator.

33/4" (9.5 cm)

Remove and Replace Refrigerator Doors

NOTE: Measure the width of your door opening, to see whether or not you need to remove the refrigerator doors to move the refrigerator into your home. If door removal is necessary, see the following instructions.

IMPORTANT: If the refrigerator was previously installed and you are moving it out of the home, before you begin, turn the refrigerator control OFF. Unplug the refrigerator or disconnect power. Remove food and adjustable door or utility bins from doors.

Gather the required tools and read all instructions before removing doors.

TOOLS NEEDED: 3/16" hex key wrench and a #2 Phillips screwdriver

Electrical Shock Hazard

Disconnect power before removing doors.

Failure to do so can result in death or electrical shock.

Style Water Dispenser Tubing Connection

Electrical Shock Hazard

Disconnect power before removing doors.

Failure to do so can result in death or electrical shock.

Unplug refrigerator or disconnect power.

Keep the refrigerator doors closed until you are ready to lift them free from the cabinet.

NOTE: Provide additional support for the refrigerator door while the hinges are being removed.

Do not depend on the door gasket magnets to hold the door in place while you are working.

Using a Phillips screwdriver, remove the cover from the Top Hinge.

Using the 3/16" hex key wrench, remove the two internal hex head screws from the top hinge, and set aside.

NOTE: Do not remove the two locator screws. These screws will help you align the hinge when you replace the door.

Remove Left-Hand Refrigerator Door

IMPORTANT: The tubing and wiring for the water dispenser run through the left-hand door hinge, so they must be disconnected before removing the door.

Using a Phillips screwdriver, remove the cover from the top hinge.

A. Top hinge cover screw

B. Top hinge cover

Disconnect the water dispenser tubing located on top of the door hinge.

Style 1 - Press the outer ring against the face of the fitting and gently pull the dispenser tubing free.

NOTE: The water dispenser tubing remains attached to the left-hand refrigerator door.

Top hinge cover screw

Top hinge cover

Internal hex head screws

Top hinge A. Outer ring B. Face of fitting

Excessive Weight Hazard

Use two or more people to lift the refrigerator door.

Failure to do so can result in back or other injury.

Lift the refrigerator door from the bottom hinge pin. The top hinge will come away with the door.

Style 2 - Firmly pull up on the clasp. Then, pull the tubing out of the fitting.

NOTE: The water dispenser tubing remains attached to the left-hand refrigerator door.

Disconnect the wiring plug located on top of the door hinge.

Grasp each side of the wiring plug. With your left thumb, press down to release the catch and pull the sections of the plug apart.

NOTE: Do not remove the green, ground wire. It should remain attached to the door hinge.

Using the 3/16" hex key wrench, remove the two internal hex head screws from the top hinge, and set aside.

NOTES:

- Provide additional support for the refrigerator door while the hinges are being removed.

- Do not depend on the door gasket magnets to hold the door in place while you are working.
- Do not remove the two locator screws. These screws will help you align the hinge when you replace the door.
- Lift the refrigerator door from the bottom hinge pin. The top hinge will come away with the door.

NOTE: It may not be necessary to remove the bottom hinges and brake feet assemblies to move the refrigerator through doorway.

- Only if necessary, use a driver with a #2 square bit tip to remove the bottom hinges and a 3/8"nut driver to remove the brake feet screws.
- Replace Right-Hand Refrigerator Door
- Set the right-hand door onto the bottom hinge pin.
- Insert the top hinge pin into the open hole in the top of the refrigerator door.
- Using the two 3/16" internal hex head screws, fasten the hinge to the cabinet.
- Do not tighten the screws completely.
- Replace Left-Hand Refrigerator Door

IMPORTANT: Do not intertwine the water tubing and wiring bundles when reconnecting them.

- Set the left-hand door onto the bottom hinge pin.
- Using the two 3/16" internal hex head screws, fasten the hinge to the cabinet.
- Do not tighten the screws completely.

Reconnect the water dispenser tubing.

Style 1 - Insert the tubing into the fitting until it stops and the outer ring is touching the face of fitting.

Style 2 - Insert the tubing firmly into the fitting until it stops.

Close the clasp around the tubing. The clasp snaps into place between the fitting and the collar.

Reconnect the electrical wiring.

Push together the two sections of the wiring plug.

Final Steps

Completely tighten the four internal hex head screws (two on the right-hand door hinge and two on the left-hand door hinge).

Replace both top hinge covers.

A. Internal hex head screws

B. Ground wire (do not remove)

C. Locator screws (do not remove)

Remove and Replace Freezer Drawer Front

Depending on the width of your door opening, it may be necessary to remove the freezer drawer front to move the refrigerator into your home.

IMPORTANT:

- If the refrigerator was previously installed and you are moving it out of the home, before you begin, turn the refrigerator control OFF, and unplug the refrigerator or disconnect power.
- Remove food from the freezer drawer.
- Two people may be required to remove and replace the freezer drawer front.

Tool Needed: 1/4" hex driver

Remove Drawer Front

Open the freezer drawer to its full extension.

Remove the two screws at the top, inside the drawer front (one on the left-hand side and one on the right-hand side) that fasten the drawer front to the drawer glides.

Lift up on the drawer front to release the plastic studs from the drawer glide bracket slots.

Replace Drawer Front

Pull out the freezer drawer glides to their full extension.

Holding the drawer front by its sides, align the two plastic studs, located at the bottom, inside the drawer front, with the drawer glide bracket slots.

NOTE: It helps if one person holds the drawer glides steady while another person aligns the drawer front and inserts the studs into the slots.

A. Drawer front screw

B. Drawer front plastic stud

Replace and tighten the two screws at the top of the drawer front (one on the left-hand side and one on the right-hand side).

Final Steps

A. Drawer glide bracket slots

Slide the drawer glides back into the freezer.

Electrical Shock Hazard

Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

Plug into a grounded 3 prong outlet.

Reset the controls.

Return all removable door parts to doors and the food to refrigerator.

Electrical Shock Hazard

- Plug into a grounded 3 prong outlet.
- Do not remove ground prong.
- Do not use an adapter.
- Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

Before you move your refrigerator into its final location, it is important to make sure you have the proper electrical connection.

Recommended Grounding Method

A 115 volt, 60 Hz, AC only 15- or 20-amp fused, grounded electrical supply is required.

It is recommended that a separate circuit serving only your refrigerator be provided.

Use an outlet that cannot be turned off by a switch.

Do not use an extension cord.

NOTE: Before performing any type of installation, cleaning, or removing a light bulb, turn Cooling OFF, and then disconnect the refrigerator from the electrical source. When you have finished, reconnect the refrigerator to the electrical source and turn Cooling ON. See "Using the Control(s)."

Water Supply Requirements

A cold water supply with water pressure between 35 and 120 psi (241 and 827 kPa) is required to operate the water dispenser and ice maker. If you have questions about your water pressure, call a licensed, qualified plumber.

NOTE: If the water pressure is less than what is required, the flow of water from the water dispenser could decrease or ice cubes could be hollow or irregular shaped.

Reverse Osmosis Water Supply

IMPORTANT: The pressure of the water supply coming out of a reverse osmosis system going to the water inlet valve of the refrigerator needs to be between 35 and 120 psi (241 and 827 kPa).

If a reverse osmosis water filtration system is connected to your cold water supply, the water pressure to the reverse osmosis system needs to be a minimum of 40 to 60 psi (276 to 414 kPa).

Check to see whether the sediment filter in the reverse osmosis system is blocked.

Replace the filter if necessary.

Allow the storage tank on the reverse osmosis system to refill after heavy use. The tank capacity could be too small to keep up with the requirements of the refrigerator.

NOTE: Faucet mounted reverse osmosis systems are not recommended.

If your refrigerator has a water filter, it may further reduce the water pressure when used in conjunction with a reverse osmosis system.

Remove the water filter. See "Water Filtration System."

If you have questions about your water pressure, call a licensed, qualified plumber.

Connect the Water Supply

Read all directions before you begin.

IMPORTANT:

Plumbing shall be installed in accordance with the International Plumbing Code and any local codes and ordinances.

The gray water tubing on the back of the refrigerator (which is used to connect to the household water line) is a PEX (cross-linked polyethylene) tube. Copper and PEX tubing connections from the household water line to the refrigerator are acceptable, and will help avoid off-taste or odor in your ice or water. Check for leaks.

If PEX tubing is used instead of copper, we recommend the following Whirlpool Part Numbers: W10505928RP (7 ft [2.14 m] jacketed PEX).

RP (5 ft [1.52 m] PEX), or W10267701RP (25 ft [7.62 m] PEX).

Install tubing only in areas where temperatures will remain above freezing.

TOOLS NEEDED:

Gather the required tools and parts before starting installation. Flat-blade screwdriver

7/16" and 1/2" open-end wrenches or two adjustable wrenches

1/4" nut driver

NOTE: Do not use a piercing-type or 3/16" (4.76 mm) saddle valve which reduces water flow and clogs easier.

Connect to Water Line

IMPORTANT: If you turn the refrigerator on before the water is connected, turn the ice maker OFF.

Unplug refrigerator or disconnect power.

Turn OFF main water supply. Turn ON nearest faucet long enough to clear line of water.

Use a quarter-turn shutoff valve or the equivalent. served by a 1/2"household supply line.

NOTE: To allow sufficient water flow to the refrigerator. minimum 1/2"size household supply line is recommended.

A. Sleeve

B. Nut

C. Copper tubing (to refrigerator)

D. Household supply line

Now you are ready to connect the copper tubing to the shutoff valve. Use 1/4"(6.35 mm) OD soft copper tubing to connect the shutoff valve and the refrigerator.

Ensure that you have the proper length needed for the job. Be sure both ends of the copper tubing are cut square.

Slip compression sleeve and compression nut onto copper tubing as shown. Insert end of tubing into outlet end squarely as far as it will go. Screw compression nut onto outlet end with adjustable wrench.

Do not overtighten.

A. Compression sleeve

B. Compression nut

C. Copper tubing

Place the free end of the tubing into a container or sink. and turn on main water supply to flush out tubing until water is clear. Turn off shutoff valve on the water pipe.

NOTE: Always drain the water line before making the final connection to the inlet of the water valve. to avoid possible water valve malfunction.

Bend the copper tubing to meet the water line inlet. which is located on the back of the refrigerator cabinet as shown.

Leave a coil of copper tubing to allow the refrigerator to be pulled out of the cabinet or away from the wall for service.

Connect to Refrigerator

Remove plastic cap from water valve inlet port. Attach the copper tube to the valve inlet using a compression nut and sleeve as shown. Tighten the compression nut. Do not overtighten.

Confirm copper tubing is secure by pulling on copper tubing.

Create a service loop with the copper tubing. Avoid kinks when coiling the copper tubing. Secure copper tubing to refrigerator cabinet with a "P" clamp.

- A. Copper tubing
- B. "P" clamp
- C. Compression nut
- D. Compression sleeve

Turn on water supply to refrigerator and check for leaks.

Correct any leaks.

Unplug refrigerator or disconnect power.

Remove and discard the short, black plastic part from the end of the water line inlet.

Thread the nut onto the end of the tubing. Tighten the nut by hand. Then tighten it with a wrench two more turns. Do not overtighten.

NOTE: To avoid rattling, be sure the copper tubing does not touch the cabinet's side wall or other parts inside the cabinet.

- A. Household water line
- B. Nut (purchased)
- C. Ferrule (purchased)
- D. Refrigerator water tubing

Install the water supply tube clamp around the water supply line to reduce strain on the coupling.

Turn shutoff valve ON.

Check for leaks. Tighten any connections (including connections at the valve) or nuts that leak.

On some models, the ice maker is equipped with a built-in water strainer. If your water conditions require a second water strainer, install it in the 1/4"(6.35 mm) water line at either tube connection.

Obtain a water strainer from your appliance dealer.

Complete the Installation

Electrical Shock Hazard

Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

Plug into a grounded 3 prong outlet.

Flush the water system.



NOTE: Allow 24 hours to produce the first batch of ice. Discard the first three batches of ice produced.

Allow 3 days to completely fill the ice storage bin.

Installation and Removal

Parts Included: Door handles (2). Drawer handle(s) (1 or 2 depending on model). 1/8" hex key. spare setscrew(s)

NOTE: With the handles laying on a flat surface, the handles intended for the drawers are more curved. They will not mount flush against the doors.

Install Handles

NOTE: Handle mounting setscrews are preinstalled inside the handle.

Remove the handles from the packaging inside the refrigerator, and place them on a soft surface.

Open a refrigerator compartment door. On the closed door, place a handle onto the shoulder screws so that the setscrews are facing the adjacent door.

Firmly push the handle toward the door until the handle base is flush against the door.

While holding the handle, insert the short end of the hex key into the upper hole and slightly rotate the hex key until it is engaged in the setscrew.

A. Shoulder screws

B. Setscrews inside the handle

Using a clockwise motion, tighten the setscrew just until it begins to contact the shoulder screw. Do not fully tighten.

Repeat steps 4 and 5 to fasten the lower setscrew.

Once both setscrews have been partially tightened as instructed in the previous steps, fully tighten both setscrews.

IMPORTANT: When the screws feel tight, tighten them an additional quarter-turn.

The handle is not properly installed without this extra tightening.

Repeat steps 2 through 7 to install the other handle onto the adjacent refrigerator door.

With the drawer(s) closed, place the handle onto the shoulder screws so that the setscrews are facing down toward the floor.

A. Shoulder screw

B. Setscrews inside the handle

- Firmly push the handle toward the drawer until the handle base is flush against the drawer.

- Insert the short end of the hex key into the left-hand hole and slightly rotate the hex key until it is engaged in the setscrew.
- Using a left to right motion tighten the setscrew a quarter-turn at a time just until it begins to contact the shoulder screw. Do not fully tighten.
- Repeat steps 11 and 12 to fasten the right-hand setscrew to the shoulder screw.
- Once both setscrews have been partially tightened as instructed in the previous steps, fully tighten both setscrews.

IMPORTANT: When the screws feel tight, tighten them an additional quarter-turn.

The handle is not properly installed without this extra tightening.

- For some models, repeat steps 9 through 14 to install a handle on the second drawer.
- Save the hex key and all instructions.

Remove the Handles

While holding the handle, insert the short end of the hex key into a setscrew hole and slightly rotate the hex key until it is engaged in the setscrew.

Using a right to left motion loosen the setscrew a quarter-turn at a time.

Repeat steps 1 and 2 for the other setscrew.

Slowly pull the handle away from the door or drawer.

If necessary, use a Phillips screwdriver to remove the shoulder screws from the door.

The base grille covers the adjustable brake feet and roller assemblies located at the bottom of the refrigerator below the freezer drawer. Before making any adjustments, remove the base grille and move the refrigerator to its final location.

Tools Needed: 1/4"hex driver

Tools Provided: 1/8"hex key wrench

Remove the base grille. Grasp the grille firmly and pull it toward you. Open the freezer drawer to access the brake feet.

NOTE: To allow the refrigerator to roll easier, raise the brake feet by turning them counterclockwise.

The front rollers will be touching the floor.

Move the refrigerator to its final location.

Lower the brake feet, by turning them clockwise, until the rollers are off the floor and both brake feet are snug against the floor. This keeps the refrigerator from rolling forward when opening the refrigerator doors or freezer drawer.

IMPORTANT: If you need to make further adjustments involving the brake feet, you must turn both brake feet the same amount to keep the refrigerator level.

To Adjust the Cabinet Tilt:

Open the freezer drawer. Use a 1/4"hex driver to turn both brake feet clockwise the same amount. This will raise the front of the refrigerator.

It may take several turns to allow the doors to close easier.

NOTE: Having someone push against the top of the refrigerator takes some weight off the brake feet. This makes it easier to turn them.

Water Filtration system

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used on disinfected waters that may contain filterable cysts.

Install the Water Filter

Locate the accessory packet in the refrigerator and remove the water filter.

Take the water filter out of its packaging and remove the cover from the O-rings.

Be sure the O-rings are still in place after the cover is removed.

A. O-ring cover

B. O-rings

The water filter compartment is located in the right-hand side of the refrigerator ceiling. Push up on the compartment door to release the catch. then lower the door.

Align the arrow on the water filter label with the cutout notch in the filter housing and insert the filter into the housing.

Turn the filter clockwise 90 degrees (1/4turn). until it locks into the housing.

NOTE: If the filter is not correctly locked into the housing. the water dispenser will not operate.

Water will not flow from the dispenser.

While the compartment door is still open. lift the filter up into the compartment.

Then. close the filter compartment door completely.

Flush the water system.

IMPORTANT: If you do not flush the water system. you may experience dripping and/or decreased flow from the water dispenser.

The Water Filter Status Light

Press OPTIONS on the control panel to launch the Options menu.

Press OPTIONS. under Filter Status. again to display the percentage of filter life remaining (from 100% to 0%). Press ICE MODE to return to the Normal screen.

The water filter status lights will help you know when to change your water filter.

ORDER (yellow) - it is almost time to change the water filter.

While you are dispensing water. "Order Filter" will blink seven times and sound an alert tone three times.

REPLACE (red) - Replace the water filter. While you are dispensing water. "Replace Filter" will blink seven times and an alert tone will sound three times.

RESET the water filter status tracking feature. After you replace the disposable water filter with a new filter. closing the filter compartment door will automatically reset the filter status tracking feature.

NOTE: "Replace Filter" will remain illuminated if a filter is not installed or is installed incorrectly.

Replace the Water Filter

To purchase a replacement water filter. see "Accessories."

Replace the disposable water filter when indicated on the water filter status display or at least every 6 months.

If water flow to your dispenser or ice maker decreases noticeably. change the water filter sooner.

Locate the water filter compartment in the right-hand side of the refrigerator ceiling. Push up to release and lower the compartment door.

Turn the water filter counterclockwise (to the left). and pull it straight out of the compartment.

NOTE: There may be some water in the filter. Some spilling may occur. Use a towel to wipe up any spills.

Install the replacement water filter by following steps 2 through 7 in the "Install the Water Filter" section.

Install Air Filter (oH some modes)

An air filter is 15 times more powerful than baking soda at reducing common food odors inside the refrigerator.

On some models. your refrigerator's accessory packet includes an air filter. which must be installed prior to use.

Installing the Air Filter

Install the air filter behind the vented door. located on the rear wall near the top of the refrigerator compartment.

Remove the air filter from its packaging.

Lift open the vented door.

Snap the filter into place.

A. Air filter

Place the indicator face-down on a firm, flat surface.

Apply pressure to the bubble on the back of the indicator until the bubble pops to activate the indicator.

Lift open the vented air filter door. On some models, there are notches behind the door.

Models with notches:

With the indicator screen facing outward, slide the indicator down into the notches.

NOTE: The indicator will not easily slide into the notches if the bubble has not been popped. Close the air filter door, and check that the indicator is visible through the window in the door.

A. Status indicator window

B. Air filter status indicator

C. Notches

Models without notches:

Place the indicator somewhere it is easily visible - either inside the refrigerator, or elsewhere in your kitchen or home.

Replacing the Air Filter

The disposable air filter should be replaced every 6 months, when the status indicator has completely changed from white to red.

To order a replacement air filter, contact us. See "Accessories" in the User Guide.

Use and Care Guide or User Instructions for information on ordering.

Remove the used air filter by squeezing in on the side tabs.

Remove the used status indicator.

Install the new air filter and filter status indicator using the instructions in the previous sections.

Insta Produce Preserver (on some mode{s})

The produce preserver absorbs ethylene, to slow the ripening process of many produce items. As a result, certain produce items will stay fresh longer.

Ethylene production and sensitivity varies depending on the type of fruit or vegetable.

To preserve freshness, it is best to separate produce with sensitivity to ethylene from fruits that produce moderate to high amounts of ethylene.

CAUTION: IRRITANT

MAY IRRITATE EYES AND SKIN. DANGEROUS FUMES FORM WHEN MIXED WITH OTHER PRODUCTS.

Do not mix with cleaning products containing ammonia, bleach or acids. Do not get in eyes, on skin or clothing. Do not breathe dust. Keep out of reach of children.

FIRST AID TREATMENT: Contains potassium permanganate.

If swallowed, call a Poison Control Center or doctor immediately. Do not induce vomiting. If in eyes, rinse with water for 15 minutes. If on skin, rinse with water.

Find the Produce Preserver housing inside the refrigerator.

Open the housing by pulling up and out on the back.

Remove the Produce Preserver pouches from the packaging and place them into the housing.

NOTE: For best performance, always use two pouches.

Adhere the Produce Preserver housing to the back wall of the crisper drawer according to the instructions included in the package.

Installing the Status Indicator

The produce preserver comes with a status indicator, which should be activated and installed at the same time the pouches are installed.

Place the indicator face-down on a firm, flat surface.

Apply pressure to the bubble on the back of the indicator until the bubble pops, to activate the indicator.

Slide open the cap on the top of the produce preserver housing.

Place the indicator in the top of the housing, facing outward.

Slide the cap closed, and check that the indicator is visible through the rectangular hole in the cap.

NOTE: The cap will not easily close if the indicator's bubble has not been popped.

Replacing the Produce Preserver

The disposable pouches should be replaced every 6 months or when the status indicator changes completely from white to red.

To order replacements, contact us.

Remove the used pouches from the produce preserver housing.

Remove the used status indicator.

Install the replacement pouches and status indicator using the instructions in the previous sections.

The following accessories are available for your refrigerator.

To order an accessory, contact us and ask for the part number.

Opening and Closing Doors

- There are two refrigerator compartment doors. The doors can be opened and closed either separately or together.
- There is a vertically-hinged seal on the left refrigerator door.
- When the left side door is opened, the hinged seal automatically folds inward so that it is out of the way.
- When both doors are closed, the hinged seal automatically forms a seal between the two doors.

A. Hinged seal

Using the Controls

The controls are located above the external dispenser.

IMPORTANT: The display screen on the dispenser control panel will turn off automatically and enter "sleep" mode when the control buttons and dispenser paddles have not been used for 2 minutes or more. Press any control button to reactivate the display screen. The home screen will appear as shown.

Wait at least 24 hours between adjustments.

Recheck the temperatures before other adjustments are made.

View Temperature Set Points

Press and hold TEMPERATURE for 3 seconds to activate Temperature mode.

When Temperature mode is activated, press TEMPERATURE to toggle between the Refrigerator zone and the Freezer zone. The display will show the temperature set point of the selected compartment, as shown.

NOTE: When Temperature mode is activated, to view temperatures in degrees Celsius, press the LIGHT button, under Units. To return the display setting to Fahrenheit, press the LIGHT button again.

Recommended Refrigerator Temperature

Recommended Freezer Temperature

Viewing and Adjusting Temperature Set Points

For your convenience, your refrigerator and freezer temperature controls are set to the recommended set points at the factory.

When you first install your refrigerator, make sure the temperature controls are still set to the recommended set points. The recommended set points are 37°F (3°C) for the refrigerator and 0°F (-18°C) for the freezer.

IMPORTANT:

Wait 24 hours before you put food into the refrigerator.

If you add food before the refrigerator has cooled completely, your food may spoil.

NOTE: Adjusting the set points to a colder than recommended setting will not cool the compartments any faster.

If the temperature is too warm or too cold in the refrigerator or freezer, first check the air vents to be sure they are not blocked before adjusting the controls.

The recommended set points should be correct for normal household use. The controls are set correctly when milk or juice is as cold as you like and when ice cream is firm.

NOTE: Areas such as a garage or porch, may experience hotter or colder temperatures and higher humidity than inside the home. You may need to adjust the temperature away from the recommended set points to accommodate for these conditions.

Adjust Temperature Set Points

Refrigerator set point range: 33°F to 45°F (0°C to 7°C).

Freezer set point range: -5°F to 5°F (-21°C to -15°C).

Press and hold TEMPERATURE for 3 seconds to activate Temperature mode.

When Temperature mode is activated, press TEMPERATURE to select the Refrigerator zone. The display will show the temperature set point of the selected compartment, as shown.

Press LOCK, under plus, to raise the set point, or press OPTIONS, under minus, to lower the set point.

When you have finished adjusting the refrigerator set point, press TEMPERATURE to change the display to show the freezer set point. When the zone has been changed, "FREEZER" appears on the display screen.

Press LOCK, under plus, to raise the set point, or press OPTIONS, under minus, to lower the set point.

Save/Confirm Temperature Settings

When you have finished adjusting both the refrigerator and freezer set points, press MEASURED FILL "Confirm" to save the settings.

NOTE: To exit Temperature mode without saving changes, press the ICE MODE button under Back at any time, or allow about 60 seconds of inactivity. The temperature mode will turn off automatically and return to the normal screen.

When adjusting temperature set points, use the following chart as a guide:

REFRIGERATOR too cold REFRIGERATOR Setting 1° higher

FREEZER too cold FREEZER Setting 1° higher

Cooling On/Off

Your refrigerator and freezer will not cool when cooling is turned off.

To turn cooling off. press and hold the LOCK and MEASURED FILL buttons at the same time for 3 seconds.

When cooling is off. "Refrigeration Cooling is Off" will appear on the display screen as shown.

IMPORTANT: To avoid unintentionally locking the dispenser or changing other settings. be sure to press both buttons at exactly the same time.

A. Press LOCK and MEASURED FILL at the same time.

To turn cooling back on. press and hold LOCK and MEASURED FILL for 3 seconds again.

"Cooling is Off" will disappear from the display screen.

Options

Press the OPTIONS button to open the Options menu and select between Max Cool. Max Ice and Water Filter Status.

Press the ICE MODE button at any time to return to the Normal screen.

Max Cool

The Max Cool feature assists with periods of high refrigerator use. full grocery loads. or temporarily warm room temperatures.

To turn on the Max Cool feature. press the OPTIONS button to enter Options mode. then press the LOCK button. under Max Cool. to activate the feature. When the feature is on. the Max Cool icon will appear on the dispenser display screen.

The Max Cool feature will remain on for 24 hours unless manually turned off.

To manually turn off the Max Cool feature. press the OPTIONS button to enter Options mode (unless you are already in Options mode). then press LOCK again. When the feature has been turned off. the Max Cool icon will disappear from the dispenser display.

NOTE: Setting the freezer to a colder temperature may make some foods. such as ice cream. harder.

Max Ice

The Max Ice feature assists with temporary periods of heavy ice use by increasing ice production.

To turn on the Max Ice feature. press the OPTIONS button to enter Options mode. then press the TEMPERATURE button. under Max Ice. to activate the feature. When the feature is on. the Max Ice icon will appear on the dispenser display screen.

The Max Ice feature will remain on for 24 hours unless manually turned off.

To manually turn off the Max Ice feature. press the OPTIONS button to enter Options mode (unless you are already in Options mode). then press TEMPERATURE again. When the feature has been turned off. the Max Ice icon will disappear from the dispenser display.

Water Filter Status

Press FILTER STATUS to display the percentage of use remaining in the water filter (from 100% to 0%).

ALSO

The water filter status lights will let you know when to change your water filter.

ORDER FILTER (Yellow) - Order a replacement water filter.

REPLACE FILTER (Red) - Replace the water filter. Replacing the disposable water filter will automatically reset the water filter status tracking feature. See "Water Filtration System."

NOTE: REPLACE FILTER will remain illuminated if a filter is not installed or installed incorrectly.

Additional Features

Sabbath Mode

Sabbath Mode is designed for those whose religious observances require turning off the lights and dispensers.

In Sabbath Mode. the temperature set points remain unchanged. but the interior and dispenser lights turn off. all sounds and alarms. and the dispenser paddles are disabled.

To turn on Sabbath Mode. press and hold LIGHT and OPTIONS at the same time for 3 seconds.

When the feature turns on. "Sabbath Mode" will appear on the dispenser display.

To turn off Sabbath Mode. press and hold LIGHT and OPTIONS. at the same time. for 3 seconds.

The screen will display the settings as they were before Sabbath Mode was turned on. However. the Max Cool and Max Ice features. will remain off until they are selected again.

NOTES:

Turning "Cooling Off" will cancel Sabbath Mode

If a power outage occurs while in Sabbath Mode. Power Outage will not be indicated on the display no matter how long the power was out.

Vacation Mode

In Vacation Mode. the freezer will defrost less often to conserve energy.

To turn on Vacation Mode. press and hold TEMPERATURE and OPTIONS at the same time for 3 seconds.

When the feature turns on. "VAC" will appear on the dispenser display.

To turn off Vacation Mode. press and hold TEMPERATURE and OPTIONS at the same time. again. for 3 seconds.

The screen will display the settings as they were before Vacation Mode was turned on.

NOTES:

During the first hour after Vacation Mode is turned on. opening and closing the refrigerator door will not affect the setting. After 1 hour has passed. opening and closing the refrigerator door will turn off Vacation Mode.

While in Vacation Mode. if Max Ice. Max Cool or Sabbath Mode is turned on. it will cancel Vacation Mode.

Power Outage Indicator

The power outage indicator lets you know if the power supply to the refrigerator has been cut off and the freezer temperature has risen to 18°F (-8°C) or higher.

When power has been restored. "PO" repeatedly flashes on the control panel display. All other control and dispenser functions are disabled and "PO" will continue to blink until you acknowledge the power outage. Press the MEASURED FILL button to confirm.

The Power Outage "PO" will disappear. and the control panel will return to the Normal screen.

Door Ajar Alarm

The Door Ajar Alarm feature sounds an alarm when the refrigerator door(s) or freezer drawer is open for 5 minutes and cooling is turned on. The alarm will repeat every 2 minutes.

Close all doors and drawer to turn it off. The feature then resets and will reactivate when either door is left open again for 5 minutes.

NOTE: To mute the audible alarm while keeping the doors open. such as while cleaning the inside of the refrigerator. press any button on the control panel. The alarm sound will be temporarily turned off. but the Door Ajar icon will still be displayed on the dispenser control panel.

Disabling Sounds

To turn off control and dispenser sounds. press and hold ICE MODE and MEASURED FILL at the same time for 3 seconds.

All normal operating tones are disabled.

Only alert tones will be audible.

To turn all sounds back on. press and hold ICE and MEASURED FILL at the same time for 3 seconds again.

Showroom Hode

This mode is used only when the refrigerator is on display in a retail store. If you unintentionally turn on Showroom mode, the words "Showroom Mode" will light up on the display. Exit Showroom mode by pressing and holding LIGHT and LOCK at the same time for 3 seconds.

WaVer and Ice Dispensers

IMPORTANT:

Allow 3 hours for the refrigerator to cool down and chill water.

Allow 24 hours to produce the first batch of ice. Discard the first three batches of ice produced.

The dispensing system will not operate when either the refrigerator door or freezer drawer is open.

Flush the Water System

Air in the water dispensing system can cause the water dispenser to drip. After connecting the refrigerator to a water source or replacing the water filter, flush the water system.

Flushing the water dispensing system, forces air from the water line and filter and prepares the water filter for use. Additional flushing may be required in some households.

NOTE: As air is cleared from the system, water may spurt out of the dispenser.

Using a sturdy container, depress and hold the water dispenser paddle for 5 seconds.

Release the dispenser paddle for 5 seconds.

Repeat steps 1 and 2 until water begins to flow.

Once water begins to flow, continue depressing and releasing the dispenser pad (5 seconds on, 5 seconds off) until a total of 3 gal. (12 L) has been dispensed.

Calibrate Measured Fill

Household water pressure may affect the accuracy of the Measured Fill feature. So, for optimum performance of your water dispenser, you must first calibrate Measured Fill.

IMPORTANT: Flush the water system before calibrating Measured Fill.

Place a sturdy measuring cup (1 cup [237 mL] size) on the dispenser tray centered in front of the water dispenser paddle.

NOTE: Depending on your model, a measuring cup may be provided.

A. Water dispenser paddle B. Measuring cup (1 cup)

Press and hold the OPTIONS and LOCK buttons at the same time for 3 seconds. The words "Back" and "1 Cup" will appear on the display screen. Also, the Calibrate Measured Fill icon will illuminate and remain lit while the Measured Fill feature is being calibrated.

NOTE: You may press ICE MODE "Back" at any time to exit calibration mode. The Calibrate Measured Fill icon will turn off.

Press and release the water dispenser paddle, as needed, to dispense water to the 1 cup fill line.

NOTE: If overfilling or spilling occurs. discard the water and press ICE MODE "Back" to restart the calibration process.

When 1 cup of water has been correctly dispensed into the measuring cup. press the MEASURED FILL button under the word "Confirm" to confirm the calibration.

A. 1 cup of water

When Measured Fill calibration has been confirmed the icons will disappear and the display will return to the home screen.

The Water Dispenser

IMPORTANT:

Dispense at least 1 qt (1 L) of water every week to maintain fresh supply.

If the flow of water from the dispenser decreases. it could be caused by low water pressure.

With the water filter removed. dispense 1 cup (237 mL) of water. If 1 cup (237 mL) of water is dispensed in 8 seconds or less. the water pressure to the refrigerator meets the minimum requirement.

If it takes longer than 8 seconds to dispense 1 cup (237 mL) of water. the water pressure to the refrigerator is lower than recommended.

See "Water Supply Requirements" and "Troubleshooting" for suggestions.

To Dispense Water Standard:

Press a sturdy glass against the dispenser paddle.

Remove the glass to stop dispensing

To Dispense Water Measured Fill:

Measured Fill allows you to dispense a specified amount of water with the touch of a few buttons.

NOTE: The amount of water you select will be dispensed.

Make sure the container is empty and that it can hold the entire volume.

If ice is in the container. you may need to adjust your selection.

Press MEASURED FILL to turn the feature on. When the feature is on. the Measured Fill screen appears on the display.

Press ICE MODE. under Back. to manually turn off the Measured Fill feature and return to the home screen.

NOTE: The dispenser will automatically turn off Measured Fill after 1 minute of inactivity. When Measured Fill is turned off. any changes you have made will be lost and all defaults will be restored.

You can dispense water by the ounce, cup, or liter. The default unit is ounces. To switch to cups or liters, press the LIGHT button under Units.

Default, minimum, and maximum volumes are listed in the following chart:

Units Default Minimum Maximum

Liters 0.25 0.05 4.00

Press the LOCK (+) and OPTIONS (-) buttons to adjust the volume as desired.

The LOCK button increases the volume, and the OPTIONS button lowers the volume.

NOTES:

When increasing or decreasing the dispense volumes, if an adjustment button (-/+) is held for approximately 10 seconds or longer the control may stop responding.

Release the button for approximately 2 seconds and then continue making the adjustment.

Most coffee cups (commonly 4 to 6 oz [118 to 177 mL] per cup) are not the same size as a measuring cup (8 oz [237 mL]). You may need to adjust the volume to avoid unintentionally overfilling coffee cups.

To dispense water, press a sturdy glass against the water dispenser lever OR place the glass below the water dispenser and press the MEASURED FILL button.

NOTE: While dispensing water, the digital display will count down how much water remains to be dispensed, according to the volume you selected.

The flow of water will automatically stop once the desired volume has been dispensed.

To stop dispensing before the selected volume has been dispensed, remove the glass from the dispenser lever OR press the MEASURED FILL button a second time.

NOTE: If you stop dispensing before the desired volume has been dispensed, the digital display will continue to show how much water remains to be dispensed.

The display will turn off after 1 minute of inactivity.

To select a new volume or start dispensing the same volume again, you must first finish dispensing the selected volume, or turn off the Measured Fill feature (either by waiting 1 minute so it will automatically turn off or by pressing ICE MODE to manually turn it off) and then turn it back on.

The Ice Dispenser

Ice dispenses from the ice maker storage bin. To turn off the ice maker, see "Ice Maker and Storage Bin."

The dispenser may continue to make noise and ice may continue to dispense for several seconds after releasing the dispenser button or paddle.

IMPORTANT: If the ice cubes are hollow or have an irregular shape, it could be because of low water pressure. See "Water Supply Requirements."

To Clean the Ice Dispenser Chute:

Humidity causes ice to naturally clump together.

Ice particles can build up until the ice dispenser chute becomes blocked.

If ice is not dispensed regularly, it may be necessary to empty the ice storage bin and clean the ice delivery chute, the ice storage bin and the area beneath the storage bin every 2 weeks.

If necessary, remove the ice clogging the storage bin and delivery chute, using a plastic utensil.

Clean the ice delivery chute and the bottom of the ice storage bin using a warm, damp cloth and dry thoroughly.

To Dispense Ice:

Cut Hazard

Use a sturdy glass when dispensing ice.

Failure to do so can result in cuts.

IMPORTANT: You do not need to apply a lot of pressure to the paddle to activate the ice dispenser. Pressing hard will not make the ice dispense faster or in greater quantities.

Press ICE MODE to select cubed ice (default) or crushed ice.

The display screen indicates which type of ice is selected.

CRUSHED CUBED

Press a sturdy glass against the dispenser paddle.

Remove the glass to stop dispensing.

Hold the glass close to the dispenser opening so ice does not fall outside of the glass.

NOTE: When changing from crushed to cubed, a few ounces of crushed ice will be dispensed along with the first cubes.

The Dispenser Drip Tray

There is an insert in the dispenser drip tray. The insert can be removed from the drip tray to carry to the sink to empty or clean.

Push down on the rear edge of the insert to tilt up the front edge for easy removal.

A. Dispenser tray insert

The Dispenser Light When you use the dispenser, the light will automatically turn on.

To turn on the light when you are not dispensing:

Press LIGHT to toggle through the following choices in a continuous loop:

OFF (default): The dispenser light is off.

ON: The dispenser light is on at 100% brightness

DIM: The dispenser light is on at 50% brightness

The dispenser lights are LEDs that cannot be changed.

If it appears that your dispenser lights are not working, see "Troubleshooting" for more information.

The Dispenser Lock

The dispenser can be disabled for easy cleaning or to avoid unintentional dispensing by small children and pets.

NOTE: The lock feature does not shut off power to the refrigerator, to the ice maker, or to the dispenser light. It simply deactivates the controls and dispenser levers. To turn off the ice maker, see "Ice Maker and Storage Bin."

Press and hold LOCK for 3 seconds to lock the dispenser.

Press and hold LOCK for 3 seconds to unlock the dispenser.

The display screen indicates when the dispenser is locked.

LOCKED UNLOCKED

Ice Maker and Ice Storage Bin (on some models)

IMPORTANT: To avoid low ice production and poor quality ice, flush the water system before turning on the ice maker. See "Water Dispenser."

Allow 24 hours to produce the first batch of ice. Discard the first three batches of ice produced.

Allow 2 to 3 days for the storage bin to fill completely following installation.

The quality of your ice will be only as good as the quality of the water supplied to your ice maker. Avoid connecting the ice maker to a softened water supply. Water softener chemicals (such as salt) can damage parts of the ice maker and lead to poor quality ice. If a softened water supply cannot be avoided, make sure the water softener is operating properly and is well maintained.

If the ice in the storage bin clumps together, break up ice using a plastic utensil and discard.

Do not use anything sharp to break up the ice. This can cause damage to the ice bin and the dispenser mechanism.

Do not store anything in the ice storage bin.

Ice Production Rate

The ice maker should produce approximately 3 lbs (1.4 kg) of ice per day under normal operation.

To increase ice production, select the increased ice production feature from the Options menu on the control panel. See "Using the Control(s)."

Style I - Ice Maker in the Refrigerator (on some models)

The ice maker is located on the left-hand side of the refrigerator compartment ceiling.

Ice cubes are ejected into the ice storage bin. located on the left-hand refrigerator door.

Turn the Ice Maker On/Off

Push up on the latch on the left-hand side of the ice compartment to open the door.

A. Ice compartment door latch

Turn on the ice maker by moving the switch to the (left) ON position.

NOTES:

To manually turn off the ice maker. move the control to the OFF (right) position.

Your ice maker has an automatic shutoff. The sensor will automatically stop ice production if the storage bin is full. if the door is open or the storage bin is removed. The control will remain in the ON (left) position.

A. Ice storage bin release latch

Close the ice compartment door.

Remove and Replace the Ice Storage Bin

Remove the ice storage bin by inserting your fingers into the hole at the base of the bin and squeezing the latch to release the bin from the compartment.

Lift the storage bin up and pull it straight out.

Replace the storage bin inside the ice compartment and push down to make sure it is firmly in place.

Style 2 - Ice Maker in the Freezer (on some models)

Turn the Ice Maker On/Off

To turn the ice maker ON. simply lower the wire shutoff arm.

To manually turn the ice maker OFF. lift the wire shutoff arm to the OFF (arm up) position and listen for the click.

NOTE: Your ice maker has an automatic shutoff.

As ice is made. the ice cubes will fill the ice storage bin and the ice cubes will raise the wire shutoff arm to the OFF (arm up) position.

Do not force the wire shutoff arm up or down.

NOTE: Turn off the ice maker before removing the ice storage bin to serve ice or to clean the bin. This will keep the ice cubes from dropping out of the ice maker and into the freezer compartment.

After replacing the ice storage bin. turn on the ice maker.

Do not clean glass shelves or covers with warm water when they are cold. Shelves and covers may break if exposed to sudden temperature changes or impact. such as bumping.

Tempered glass is designed to shatter into many small, pebble-size pieces. This is normal. Glass shelves and covers are heavy. Use both hands when removing them to avoid dropping.

Refrigerator Shelves

The shelves in your refrigerator are adjustable to meet your individual storage needs.

Storing similar food items together in your refrigerator and adjusting the shelves to fit different heights of items will make finding the exact item you want easier. It will also reduce the amount of time the refrigerator door is open, and save energy.

Shelves and Shelf Frames

To remove and replace a shelf/shelf frame:

Remove the shelf/frame by tilting it up at the front and lifting it out of the shelf supports.

Replace the shelf/frame by guiding the rear shelf hooks into the shelf supports.

Tilt the front of the shelf up until rear shelf hooks drop into the shelf supports.

Lower the front of the shelf and make sure that the shelf is in position.

Tuck Away Shelf (on some models)

To remove and replace a shelf/shelf frame:

Remove the shelf/frame by tilting it up at the front and lifting it out of the shelf supports.

Replace the shelf/frame by guiding the rear shelf hooks into the shelf supports.

Tilt the front of the shelf up until rear shelf hooks drop into the shelf supports.

Lower the front of the shelf and make sure that the shelf is in position.

To retract and extend the front section of the shelf:

To retract the front-section of the shelf, slightly lift up on the front edge and push the adjustable portion of the shelf back toward the rear of the refrigerator.

Extend the front of the shelf by pulling the retracted portion of the shelf outward until it is fully extended.

WiRe Rack (on some models)

Under one shelf, there are brackets installed to the supports (one bracket on each support).

The wine rack rests in these brackets.

To remove and replace the wine rack:

Remove the wine rack by lifting it up off the brackets.

Press the right-hand side of the rack inward until it is free of its bracket.

Lower the right-hand side slightly and disengage the left-hand side from its bracket.

Replace the wine rack by inserting the left-hand side into its bracket.

Press inward on the right-hand side until it will slide past the bracket edge and set it into its bracket.

Crisper and Crisper Cover

The humidity level in the crisper drawers is automatically regulated. so there is no humidity control.

To remove and replace a crisper drawer:

Remove the drawer by pulling it open halfway. Then. lift up on the drawer to remove it completely.

NOTE: If you unintentionally pull open the drawer to the drawer stop. it will lock in place and you will not be able to lift the drawer up and out.

Replace a drawer by placing it on the slide rails and pushing it back into position past the drawer stop.

To remove the crisper(s) cover:

Remove crisper(s).

Holding the glass insert firmly with one hand. press up in center of glass insert until it rises above the plastic frame.

Gently slide the glass insert forward to remove.

Lift the cover frame up and remove it.

To replace crisper(s) cover:

Fit back of cover frame into supports on side walls of the refrigerator and lower the front of the cover frame into place.

Slide rear of glass insert into cover frame and lower front into place.

Temperature Controlled Drawer (on some models)

The full-width. temperature-controlled drawer can be used to store large deli trays. fresh meat. beverages or other items that you want to store at a specific temperature.

NOTE: Do not place leafy vegetables in the temperature controlled drawer. Colder temperatures could damage leafy produce.

Preset Temperature Control

IMPORTANT: The control is for this drawer only. It will not affect the temperature of. or turn off cooling to the refrigerator or freezer compartments.

For your convenience. temperatures have been preset for the optimum storage of fresh meat. party trays. deli and wine.

Press PRESET to toggle among the following four temperature settings.

Each icon will light up. in turn. and the preset temperature will display:

Fresh Meat 32°F (0°C)

Party 36°F (2°C)

Deli (default setting) - 39°F (4°C)

Wine 41 °F (5°C)

NOTE: If no button is pressed, the control will revert to Deli, the default setting as shown.

Custom Temperature Control

Allows you to select the optimum temperature, within the temperature range of the drawer, for your storage needs.

The temperature range for the drawer is 32°F (0°C) to 41°F (5°C).

Press (+) or (-) to increase or decrease the temperature by 1 degree.

NOTES:

If you adjust the temperature to a non-preset temperature, the word "custom" will light up. If you adjust the temperature to a preset temperature, the preset food icon will light up.

If you try to select a temperature outside the temperature range of the drawer, the temperature display will not change.

Drawer Removal and Replacement

To remove the drawer:

Push the drawer completely closed.

Lift up the front of the drawer and pull it straight out.

To replace the drawer:

Push the metal glide rails to the rear of the refrigerator.

Place the drawer onto the glide rails. While tilting the rear of the drawer upward, slide the drawer toward the rear of the refrigerator.

Drawer Divider

To remove the divider:

Lift the front of the divider and lift the divider out.

To replace the divider: q.

Position the divider so that the features on the bottom of the divider align with the matching features in the drawer.

Lower the divider into place.

Meat Storage Guide

Store most meat in original wrapping as long as it is airtight and moisture-proof.

Rewrap if necessary. See the following chart for storage times. When storing meat longer than the times given, freeze the meat.

Fresh fish or shellfish . use same day as purchased

Chicken, ground beef, variety meats (liver) .

Leftovers Cover leftovers with plastic wrap, aluminum foil, or plastic containers with tight lids.

To remove and replace the bins:

Remove the bin by lifting it up and pulling it straight out.

Replace the bin by sliding it in above the desired support and pushing it down until it stops.

Pizza Pocket and Drawer Divider

The drawer divider is not removable.

For storage flexibility, the divider can be moved a few inches to either side allowing you to store larger items in one section of the freezer drawer.

Explosion Hazard

Use nonflammable cleaner.

Failure to do so can result in death, explosion, or fire.

Style 2 - Stainless Steel **IMPORTANT:**

Damage to stainless steel finish due to improper use of cleaning products, or using non-recommended cleaning products, is not covered under the warranty.

Soft, clean cloth Abrasive cloths

Paper towels or newsprint

Steel-wool pads

Both the refrigerator and freezer sections defrost automatically.

However, clean both sections about once a month to avoid buildup of odors. Wipe up spills immediately.

Exterior Cleaning

Please see the exterior cleaning information specific to your model.

Style I - Smooth Door

IMPORTANT: Damage to smooth finish due to improper use of cleaning products, or using non-recommended cleaning products, is not covered under the warranty. Sharp or blunt instruments will mar the finish.

Soft, clean cloth Abrasive cloths

Paper towels or newsprint

Steel-wool pads

NOTE: Paper towels scratch and may dull the clear coat of the painted door. To avoid possible damage use only soft clean clothes to polish and wipe the door.

For heavy soil. ONLY a stainless steel cleaner designed for appliances.

To order the cleaner. see "Accessories."

Stainless steel cleaner is for stainless steel parts only! Do not allow the Stainless Steel Cleaner and Polish to come into contact with any plastic parts such as the trim pieces, dispenser covers or door gaskets.

NOTES:

If unintentional contact does occur, clean plastic part with a sponge and mild detergent in warm water. Dry thoroughly with a soft cloth.

Just because a cleaner is a liquid does not mean it is nonabrasive.

Many liquid cleansers formulated to be gentle on tile and smooth surfaces still damage stainless steel.

Citric acid permanently discolors stainless steel. To avoid damaging the finish of your stainless steel refrigerator:

Do not allow these substances to remain on the finish

Mustard Citrus-based sauces

Tomato juice Citrus-based products

Marinara sauce

Interior Cleaning

Unplug refrigerator or disconnect power.

Hand wash, rinse, and dry removable parts and interior surfaces thoroughly.

Use a clean sponge or soft cloth and a mild detergent in warm water.

NOTE: Do not use abrasive or harsh cleaners such as window sprays, scouring cleansers, flammable fluids, cleaning waxes, concentrated detergents, bleaches or cleansers containing petroleum products on plastic parts, interior and door liners or gaskets.

Plug in refrigerator or reconnect power.

Condenser Cleaning

There is no need for routine condenser cleaning in normal home operating environments.

If the environment is particularly greasy or dusty, or there is significant pet traffic in the home, the condenser should be cleaned every 2 to 3 months to ensure maximum efficiency.

If you need to clean the condenser:

Unplug refrigerator or disconnect power.

Remove the base grille.

Use a vacuum cleaner with a soft brush to clean the grille, the open areas behind the grille and the front surface area of the condenser.

Replace the base grille when finished.

Plug in refrigerator or reconnect power.

The lights in both the refrigerator and freezer compartments are LEDs which do not need to be replaced.

If the lights do not illuminate when the door or drawer is opened, call for assistance or service. In the U.S.A. call 1-800-253-1301.

In Canada call 1-800-807-6777.

Vacation and Ovin Care

Vacations

If You Choose to Leave the Refrigerator On While You're Away:

Use up any perishables and freeze other items.

If your refrigerator has an automatic ice maker, and is connected to the household water supply, turn off the water supply to the refrigerator.

Property damage can occur if the water supply is not turned off.

If you have an automatic ice maker, turn off the ice maker.

NOTE: Depending on your model, raise the wire shutoff arm to OFF (up) position, or press the switch to OFF.

Empty the ice bin.

If You Choose to Turn Off the Refrigerator Before You Leave:

Remove all food from the refrigerator.

If your refrigerator has an automatic ice maker:

Turn off the water supply to the ice maker at least one day ahead of time.

When the last load of ice drops, raise the wire shutoff arm to the OFF (up) position or press the switch to OFF, depending on your model.

Turn off the Temperature control(s). See "Using the Control(s)."

Clean refrigerator, wipe it, and dry well.

Tape rubber or wood blocks to the tops of both doors to prop them open far enough for air to get in. This stops odor and mold from building up.

Hoving

When you are moving your refrigerator to a new home, follow these steps to prepare it for the move.

If your refrigerator has an automatic ice maker:

Turn off the water supply to the ice maker at least one day ahead of time.

Disconnect the water line from the back of the refrigerator.

When the last load of ice drops, raise the wire shutoff arm to the OFF (up) position or press the switch to OFF, depending on your model.

Remove all food from the refrigerator and pack all frozen food in dry ice.

Empty the ice bin.

Turn off the Temperature control(s).

Unplug refrigerator.

Clean, wipe, and dry thoroughly.

Take out all removable parts, wrap them well, and tape them together so they don't shift and rattle during the move.

Depending on the model, raise the front of the refrigerator so it rolls more easily OR raise the leveling screws so they don't scrape the floor. See "Adjust the Door(s)" or "Door Closing and Door Alignment."

Tape the doors closed and tape the power cord to the back of the refrigerator.

When you get to your new home, put everything back and refer to the "Installation Instructions" section for preparation instructions.

Also, if your refrigerator has an automatic ice maker, remember to reconnect the water supply to the refrigerator.

First try the solutions suggested here. If you need further assistance or more recommendations that may help you avoid a service call, refer to the warranty page in this manual and scan the code with your mobile device, or visit <http://kitchenaid.custhelp.com>.

In Canada, visit www.kitchenaid.ca (website may not be compatible with some mobile devices).

Contact us by mail with any questions or concerns at the address below: In the U.S.A.:

KitchenAid Brand Home Appliances Customer eXperience Center 553 Benson Road Benton Harbor, MI 49022-2692

Please include a daytime phone number in your correspondence.

In Canada:

KitchenAid Brand Home Appliances Customer eXperience Centre 200 - 6750 Century Ave.

Mississauga.

Ontario L5N 0B7

Electrical Shock Hazard

Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

The refrigerator will not operate. Check electrical supply. Plug the power cord into a grounded 3 prong outlet.

Do not use an extension cord.

Make sure there is power to the outlet. Plug in a lamp to see if the outlet is working.

Reset a tripped circuit breaker. Replace any blown fuses.

NOTE: If problems continue, contact an electrician.

Check controls. Make sure the controls are turned on. See "Using the Control(s)."

New installation. Allow 24 hours following installation for the refrigerator to cool completely.

NOTE: Adjusting the temperature controls to the coldest setting will not cool either compartment more quickly.

Refrigerator control is in Showroom. If the refrigerator is in Showroom mode, cooling is turned off mode (on some models) and "Showroom" will be illuminated on the control panel. See "Using the Control(s)" for more information.

The motor seems to run. High efficiency compressor and fans. Larger, more efficient refrigerators run longer at lower, more energy efficient speeds.

The room or outdoor temperature is high. It is normal for the refrigerator to work longer under these hot conditions.

For optimum performance, place the refrigerator in an indoor, temperature controlled environment.

A large amount of warm food has been recently added. Warm food will cause the refrigerator to run longer until the air cools to the desired temperature.

The door(s) are opened too frequently. Warm air entering the refrigerator causes it to run more, or for too long.

Open the door less often.

The refrigerator door or freezer drawer is ajar. Make sure the refrigerator is level. See "Door Closing and is ajar."

Door Alignment." Keep food and containers from blocking the door.

The refrigerator control is set too cold.

Adjust the refrigerator control to a less cold setting until the refrigerator temperature is as desired.

The door or drawer gasket is dirty.

Clean or change the gasket. Leaks in the door seal will cause worn, or cracked, the refrigerator to run longer in order to maintain desired temperatures.

The lights do not work Your refrigerator is equipped with LED. If there is power to the refrigerator and the lights do not lighting which does not need to be illuminate when a door or drawer is opened. call for service replaced, or assistance.

The dispenser light is set to OFF. On some models, the dispenser light will operate only when a dispenser paddle is pressed. If you want the dispenser light to stay on continuously, see "Water and Ice Dispensers."

Doors have been open longer than Close the doors and drawer to reset, and open to resume 10 minutes lighted task.

Pantry Temperature The refrigerator is in Cooling Off mode. Exit Cooling Off mode. See "Using the Control(s)." Control not lit/ unresponsive The refrigerator controls' initialization. Unplug the refrigerator, wait 5 seconds.

Plug in the process did not complete refrigerator, and wait 30 seconds before opening any of the successfully, refrigerator doors or touching the control panel.

To listen to normal refrigerator sounds, go to the Product Help/FAQ section of the brand website and search for "normal sounds."

The refrigerator seems The compressor in your new refrigerator regulates noisy temperature more efficiently while using less energy, and Below are listed some normal operates quietly. Due to this reduction in operating noise you sounds with explanations, may notice unfamiliar noises that are normal.

Sound of the compressor High-efficiency compressor and fans Larger, more efficient refrigerators run running longer than expected longer at lower, more energy efficient speeds.

Pulsating/Whirring Fans/compressor adjusting to optimize performance during This is normal, normal compressor operation

Popping Contraction/expansion of inside walls, especially during This is normal, initial cool-down

Hissing/Dripping Flow of refrigerant, or flow of oil in the compressor This is normal.

Vibration The refrigerator may not be steady Adjust the leveling screws and lower the leveling foot firmly against the floor. See "Door Closing and Door Alignment."

Rattling/Banging Movement of the water lines against the refrigerator cabinet.

Move excess water line away from the or of items placed on top of the refrigerator cabinet refrigerator cabinet or fasten excess tubing to the cabinet. See "Connecting the Water. or remove items from the top of the refrigerator.

Sizzling Water dripping on the heater during defrost cycle This is normal.

Water running/Gurgling May be heard when ice melts during the defrost cycle and This is normal. water runs into the drain pan

Buzzing and Clicking Heard when the water valve opens and closes to dispense If the refrigerator is connected to a water and/or fill the ice maker. water line. this is normal.

If the refrigerator is not connected to a water line. turn OFF the ice maker.

Repetitive Clicking Dual evaporator valve regulating the cooling operation You may hear rapid repetitive clicking sounds as the unit switches from cooling one compartment to cooling the other. This sound is normal.

Creaking/Cracking/Grinding May be heard as ice is being ejected from the ice maker This is normal. mold

Clatter May be heard when the ice falls into the ice storage bin This is normal.

Temperature and Moisture

Temperature is too warm The refrigerator has just been Allow 24 hours following installation for the refrigerator to installed. cool completely.

Cooling is turned off.

Turn on cooling.

The controls are not set correctly for Adjust the controls a setting colder. Check the temperature in the surrounding conditions.

24 hours. See "Using the Control(s)."

The door(s) are opened often or not Allows warm air to enter refrigerator.

Minimize door openings closed completely. and keep doors fully closed.

A large load of food was recently Allow several hours for refrigerator to return to normal added. temperature.

Temperature is too cold in The refrigerator air vent(s) are blocked.

If the air vent located in the top. left. rear corner of the the refrigerator/crisper refrigerator compartment is blocked by items placed directly in front of it. the refrigerator will get too cold. Move items away from the air vent.

The controls are not set correctly for Adjust the controls a setting warmer. Check the temperature the surrounding conditions. in 24 hours. See "Using the Control(s)."

The ice storage bin is not in the See "Ice Maker and Ice Storage Bin." correct position.

Temperature is too cold in The control is not set correctly for the Adjust the temperature setting.
See "Temperature Controlled the pantry drawers items stored in drawer.

Drawer" in the "Refrigerator Features" section.

There is interior moisture The room is humid A humid environment contributes to moisture buildup.
buildup

NOTE: Some moisture The door(s) are opened often or not Allows humid air to enter the
refrigerator.

Minimize door closed completely. openings and close doors completely. buildup is normal The door
is blocked open Move food packages away from door.

A bin or shelf is in the way Push bin or shelf back into the correct position.

Storing liquid in open containers This adds humidity to the refrigerator interior. Keep all containers
tightly covered.

There is frost/ice buildup in The drawer is opened often or left Minimize drawer openings and close
drawer completely after the freezer compartment open. use.

Poor door seal Ensure door seals are making full contact with the refrigerator cabinet to allow for
an adequate seal.

Temperature controls are not set See "Using the Control(s)" for recommended temperature
correctly settings.

Ice and Water

The ice maker is not producing ice or is not producing enough ice

The refrigerator is not connected to a Connect refrigerator to water supply and turn water shutoff
water supply or the water supply valve fully open. shutoff valve is not turned on.

There is a kink in the water source line.

A kink in the line can reduce water flow. Straighten the water source line.

The ice maker is not turned on.

Make sure the ice maker is on. See "Ice Maker and Ice Storage Bin."

The refrigerator has just been Wait 24 hours after ice maker installation for ice production installed.
to begin. Wait 3 days for full ice production.

The refrigerator door is not closed Close the door firmly. If it does not close completely. see
completely. "The doors will not close completely."

A large amount of ice was recently Allow sufficient time for ice maker to produce more ice. See
removed. "Ice Maker and Ice Storage Bin" for ice production rates.

An ice cube is jammed in the ice Remove ice from the ejector arm with a plastic utensil. maker
ejector arm.

A water filter is installed on the Remove the water filter and operate the ice maker. If ice refrigerator. volume improves. then the filter may be clogged or incorrectly installed.

Replace filter or reinstall it correctly.

A reverse osmosis water filtration This can decrease water pressure. See "Water Supply system is connected to your cold Requirements." water supply.

The ice cubes are hollow or The water shutoff valve is not fully Turn the water shutoff valve fully open. small open.

NOTE: This is an indication There is a kink in the water source line.

A kink in the line can reduce water flow. Straighten the water of low water pressure. source line.

A water filter is installed on the Remove filter and operate ice maker. If ice quality improves. refrigerator. then the filter may be clogged or incorrectly installed.

Replace filter or reinstall it correctly.

A reverse osmosis water filtration This can decrease water pressure. See "Water Supply system is connected to your cold Requirements." water supply.

Questions remain regarding water Call a licensed. qualified plumber. pressure.

Off-taste. odor or gray Newly installed refrigerator requires Flush the water system.

See "Water and Ice Dispensers" for color in the ice or water flush of water system. water system flushing instructions.

Recently installed or replaced Discard the ice and wash the ice storage bin. Flush the water plumbing connections.

New plumbing system with 3 gal. (12 L) of water. Allow 24 hours for the ice connections can cause discolored or maker to make new ice. and discard the first 3 batches of ice off-flavored ice and water. produced.

Using a water supply connection type It is recommended to use copper tubing or Whirlpool supply other than recommended. line. Part Number RP. See "Connect to Water Line."

The ice has been stored too long.

Discard ice. Wash ice storage bin. Allow 24 hours for ice maker to make new ice.

The water has been stored too long.

Dispense at least 1 qt (1 L) of water per week to maintain fresh supply.

Odor from stored food has transferred Use airtight. moisture proof packaging to store food. to the ice.

There are minerals (such as sulfur) in A water filter may need to be installed to remove the the water. minerals.

There is a water filter installed on the Gray or dark discoloration in ice may indicate that the water refrigerator. filtration system needs additional flushing. Flush the water system after installing and before using a new water filter.

See "Water and Ice Dispensers" for water filter flushing instructions.

The water filter needs to be replaced.

Replace the disposable water filter at least every 6 months or when indicated.

The water and ice The refrigerator is not connected to a Connect the refrigerator to the water supply and turn the dispenser will not water supply or the water supply water shutoff valve fully open. operate properly shutoff valve is not turned on.

There is a kink in the water source line A kink in the water line can reduce water flow from the water dispenser and result in hollow or irregular shaped ice.

Straighten the water source line.

The refrigerator has just been Flush and fill the water system.

The water pressure to the house is not The water pressure to the house determines the flow from at or above 35 psi (241 kPa). the dispenser.

See "Water Supply Requirements."

A reverse osmosis water filtration A reverse osmosis water filtration system can decrease water system is connected to your cold pressure.

The water filter may be clogged.

Remove the water filter and operate dispenser.

If water flow increases. your filter is clogged and needs to be replaced.

The water filter is installed incorrectly Remove the water filter and reinstall. See "Water Filtration System."

The refrigerator door or freezer drawer Close the door or drawer firmly. If it does not close is not closed completely. see "The doors will not close completely."

The refrigerator doors were recently Make sure the water dispenser wire/tube assembly has been removed. properly reconnected at the top of the refrigerator door.

Ice is clogged in the ice storage bin or Remove the ice clogging the storage bin and delivery chute. ice is blocking the ice delivery chute. using a plastic utensil if necessary. Clean the ice delivery chute and the bottom of the ice storage bin using a warm. damp cloth. then dry both thoroughly.

To avoid clogging and to maintain a fresh supply of ice. empty the storage bin and clean both the storage bin and delivery chute every 2 weeks.

The ice dispenser jams Crushed ice is blocking the ice Switch from crushed ice to cubed ice to clear the ice while dispensing crushed delivery chute. dispenser. Then switch back to crushed ice. ice

Water is leaking or dripping The glass was not held under the Hold the glass under the dispenser 2 to 3 seconds after from the dispenser system dispenser long enough. releasing the dispenser lever.

NOTE: A few drops of water after dispensing is normal.

Water continues to drip The refrigerator has just been Flushing the water system removes the air from the lines from the dispenser beyond installed. which causes the water dispenser to drip. Flush the water the first few drops. system.

The water filter was recently installed Flushing the water system removes the air from the lines or replaced. which causes the water dispenser to drip. Flush the water system.

Water is leaking from the The water line connections were not See "Connecting the Water." back of the refrigerator fully tightened.

Recently removed the doors and did See "Refrigerator Doors and Drawer." not fully tighten water line connection

Water from the dispenser is Water from the dispenser is chilled to This is normal. warm 50°F (10°C).

The refrigerator has just been Allow 24 hours after installation for the water supply to cool installed. completely.

A large amount of water was recently Allow 3 hours for the water supply to cool completely. dispensed.

Water has not been recently The first glass of water may not be cool. Discard the first dispensed. glass of water dispensed.

The refrigerator is not connected to a Make sure the refrigerator is connected to a cold water pipe. cold water pipe.

Use nonflammable cleaner.

Failure to do so can result in death. explosion. or fire.

To view an animation showing how to adjust and align the doors. refer to the Product Help/FAQ section of the brand website and search for "door closing and door alignment."

The doors will not close The door is blocked open.

Move food packages away from door. completely A bin or shelf is in the way.

Push bin or shelf back into the correct position.

Recently installed Remove all packaging materials.

The doors are difficult to The door gaskets are dirty or sticky.

Clean gaskets and contact surfaces with mild soap and open warm water. Rinse and dry with soft cloth.

The doors appear to be The doors need to be aligned. or the See "Refrigerator Leveling. Door Closing and Alignment." uneven refrigerator needs to be leveled.

The refrigerator is unsteady The refrigerator brake feet are not Remove the base grille. Turn both brake feet (one on each or it rolls forward when snug against the floor side) clockwise. the same amount. until they are snug against opening and closing doors the floor

Test Parameters: pH = 7.5 + 0.5 unless otherwise noted.

Flow = 0.43 gpm (1.6 Lpm).

Pressure = 60 psig (413.7 kPa).

Temp. = 68°F to 71.6°F (20°C to 22°C).

Rated service capacity = 200 gallons (757 liters). It is important that operational. maintenance. and filter replacement requirements be carried out for the product to perform as advertised.

Property damage can occur if all instructions are not followed.

Use replacement filter P6RFWB2.

2014 suggested retail price of \$39.99 U.S.A./\$49.99 Canada.

Prices are subject to change without notice.

Style 1 - When Order Filter is illuminated yellow. order a new filter. When Replace Filter is illuminated red. it is recommended that you replace the filter.

Style 2 - Press OPTIONS or SETTINGS and select Filter Status to check the status of your water filter. When the filter status shows remaining. order a new filter.

When the filter status shows remaining. it is recommended that you replace the filter.

Style 3 - Press FILTER STATUS to check the status of your water filter. When the filter status shows 10% remaining. order a new filter. When the filter status shows remaining. it is recommended that you replace the filter.

After changing the water filter. flush the water system.

See "Water and Ice Dispensers" or "Water Dispenser" in the User Instructions or User Guide.

These contaminants are not necessarily in your water supply.

While testing was performed under standard laboratory conditions. actual performance may vary.

The product is for cold water use only. The water system must be installed in compliance with state and local laws and regulations.

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

Systems certified for cyst reduction may be used on disinfected waters that may contain filterable cysts. Refer to the "Warranty" section (in the User Instructions or User Guide) for the Manufacturer's name, address and telephone number.

Refer to the "Warranty" section (in the User Instructions or User Guide) for the Manufacturer's limited warranty.

Application Guidelines/Water Supply Parameters

Water Supply City or Well Water Pressure 30 - 120 psi (207 - 827 kPa) Water Temperature 33° - 100°F (0.6 ° - 37.8°C) Service Flow Rate 0.43 gpm (1.6 Lpm) @ 60 psi

+Class I particle size: >0.5 to <1 um

+Test requirement is at least 100,000 particles/mL of AC Fine Test Dust. †Based on the use of *Cryptosporidium parvum* oocysts ††Fibers greater than 10 um in length

NSF is a registered trademark of NSF International.

KITCHENAID® REFRIGERATION LIMITED WARRANTY

ATTACH YOUR RECEIPT HERE.

PROOF OF PURCHASE IS REQUIRED TO OBTAIN WARRANTY SERVICE.

Please have the following information available when you call the Customer eXperience Center:

Name, address and telephone number Model number and serial number

A clear, detailed description of the problem Proof of purchase including dealer or retailer name and address

IF YOU NEED SERVICE:

Before contacting us to arrange service, please determine whether your product requires repair.

Some questions can be addressed without service.

Please take a few minutes to review the Troubleshooting or Problem Solver section of the Use and Care Guide, scan the QR code on the right to access additional resources, or visit <http://kitchenaid.custhelp.com>.

All warranty service is provided exclusively by our authorized KitchenAid Service Providers.

LIMITED WARRANTY

For one year from the date of purchase, when this major appliance is installed, operated and maintained according to instructions attached to or furnished with the product.

KitchenAid brand of Whirlpool Corporation or Whirlpool Canada LP (hereafter "KitchenAid") will pay for Factory Specified Replacement Parts and repair labor to correct defects in materials or workmanship that existed when this major appliance was purchased. or at its sole discretion replace the product.

In the event of product replacement. your appliance will be warranted for the remaining term of the original unit's warranty period.

SECOND THROUGH FIFTH YEAR LIMITED WARRANTY ON CAVITY LINER AND SEALED REFRIGERATION SYSTEM In the second through fifth years from the date of purchase. when this major appliance is installed. operated and maintained according to the instructions attached to or furnished with the product.

KitchenAid brand will pay for factory specified replacement parts and repair labor for the following components to correct non-cosmetic defects in materials and workmanship in this part that prevent function of the refrigerator and that existed when this major appliance was purchased:

Refrigerator/freezer cavity liner if the part cracks due to defective materials or workmanship.

Sealed Refrigeration system (includes compressor. evaporator. condenser. dryer and connecting tubing).

SIXTH THROUGH TENTH YEAR LIMITED WARRANTY (SEALED REFRIGERATION SYSTEM ONLY LABOR NOT INCLUDED) In the sixth through tenth year from the date of purchase. when this major appliance is installed. operated and maintained according to instructions attached to or furnished with the product.

KitchenAid brand will pay for factory specified replacement parts for the following components to correct defects in materials or workmanship in the sealed refrigeration system (includes compressor. evaporator. condenser. dryer and connecting tubing) that existed when this major appliance was purchased.

YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR AS PROVIDED HEREIN.

Service must be provided by a KitchenAid designated service company.

This limited warranty is valid only in the United States or Canada and applies only when the major appliance is used in the country in which it was purchased.

This limited warranty is effective from the date of original consumer purchase.

Proof of original purchase date is required to obtain service under this limited warranty.

Commercial. non-residential or multiple-family use. or use inconsistent with published user. operator or installation instructions.

In-home Instruction on how to use your product

Service to correct improper product maintenance or installation. installation not in accordance with electrical or plumbing codes or correction of household electrical or plumbing (i.e. house wiring, fuses or water inlet hoses).

Consumable parts (i.e. light bulbs, batteries, air or water filters, preservation solutions, etc.).

Damage from accident, misuse, abuse, fire, floods, acts of God or use with products not approved by KitchenAid.

Repairs to parts or systems to correct product damage or defects caused by unauthorized service, alteration or modification of the appliance.

Cosmetic damage including scratches, dents, chips, and other damage to appliance finishes unless such damage results from defects in materials and workmanship and is reported to KitchenAid within 30 days.

Discoloration, rust or oxidation of surfaces resulting from caustic or corrosive environments including but not limited to high salt concentrations, high moisture or humidity or exposure to chemicals.

Food or medicine loss due to product failure.

Pick-up or delivery.

This product is intended for in-home repair.

Travel or transportation expenses for service in remote locations where an authorized KitchenAid servicer is not available.

Removal or reinstallation of inaccessible appliances or built-in fixtures (i.e. trim, decorative panels, flooring, cabinetry, islands, countertops, drywall, etc.) that interfere with servicing, removal or replacement of the product.

Service or parts for appliances with original model/serial numbers removed, altered or not easily determined.

The cost of repair or replacement under these excluded circumstances shall be borne by the customer.

DISCLAIMER OF IMPLIED WARRANTIES

IMPLIED WARRANTIES.

INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW. Some states and provinces do not allow limitations on the duration of implied warranties of merchantability or fitness, so this limitation may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state or province to province.

DISCLAIMER OF REPRESENTATIONS OUTSIDE OF WARRANTY

KitchenAid makes no representations about the quality, durability, or need for service or repair of this major appliance other than the representations contained in this warranty.

If you want a longer or more comprehensive warranty than the limited warranty that comes with this major appliance, you should ask KitchenAid or your retailer about buying an extended warranty.

LIMITATION OF REMEDIES; EXCLUSION OF INCIDENTAL AND CONSEQUENTIAL DAMAGES
YOUR SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE
PRODUCT REPAIR AS PROVIDED HEREIN.

KITCHENAID SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states and provinces do not allow the exclusion or limitation of incidental or consequential damages, so these limitations and exclusions may not apply to you.

This warranty gives you specific legal rights, and you also may have other rights that vary from state to state or province to province.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.