


Parts and Features


BEFORE FIRST USE : Remove all literature and packing material from inside the ice cream maker. Clean freezer bowl, mixing paddle, and cover in warm, soapy water. Thoroughly rinse and dry all parts. **DO NOT** immerse motor/base in water. To clean, wipe with a damp cloth.




How to Make Ice Cream

NOTE: ALWAYS freeze freezer bowl in freezer and chill prepared mixture in refrigerator before churning.

Freezer Temperature	Minimum Time for Freezer Bowl to Freeze
-22°F (-30°C)	8 to 9 hours
13°F (-25°C)	12 to 13 hours
0°F (-18°C)	20 to 22 hours




Place freezer bowl in freezer according to chart.




Prepare mixture and chill in the refrigerator.


NOTE: Do not use more than 1 quart (4 cups/946 ml) of recipe mixture. Ice cream needs room to expand.




Place freezer bowl onto motor/ base immediately after it is removed from freezer.




Place mixing paddle in freezer bowl.



Place cover onto base, aligning tabs with slots on base.



Plug into outlet.




Press switch to ON (I).



Immediately pour chilled mixture into unit through the cover opening.


NOTE: To allow mixture to expand to 1 1/2 quarts (6 cups/ 1420 ml) while churning, do not use more than 4 cups (946 ml) of recipe mixture in ice cream maker at a time.

NOTE: Use immediately when removed from the freezer. The bowl starts to defrost as soon as it is removed from the freezer.




Ice cream will be ready in 20 to 40 minutes, depending on the recipe and the amount in the freezer bowl. Check the consistency of the mixture after 20 minutes. When you like the consistency, press switch to OFF (O), and the ice cream is ready to eat.

NOTE: If freezer bowl repeatedly reverses, the mixture is ready.



Unplug from outlet.



Remove cover. Ice cream has finished processing and is ready to eat. If storing, transfer to an airtight container and store in freezer. If you would like a firmer ice cream, store in the freezer for at least 2 hours.

Tips for Best Results

- During the churning process, you can add finely chopped or pureed ingredients, such as chocolate, raisins, and nuts, through the opening in the cover after ice cream has churned for at least 15 minutes or when mixture is thick and has started to freeze. Alcohol should not be added until near the end of the process since it significantly slows down the freezing process.
- The machine will run for 20 to 40 minutes. Do not turn ice cream maker off during this time. The mixture may freeze to the walls and prevent the bowl from turning. See Troubleshooting if your unit did not make ice cream in minutes.
- The finished result is a soft, spoonable ice cream. Homemade ice cream will not be the same consistency as hard, store-bought ice cream.
- Ice cream tastes best when fresh. It will begin to lose its fresh taste after 1 to 2 weeks in the freezer.




- Keep the freezer bowl in the freezer so that you can make ice cream, chill wine, or serve ice cubes at any time.
- For best results, the freezer bowl must be frozen thoroughly. Make sure to set your freezer at the coldest setting temperature should not be more than 0°F [-18°C]).
- Firmness of ice cream depends on variables such as the recipe used, room temperature, freezer temperature, and temperature of ingredients before churning.
- Some recipes require the mixture to be precooked. Make the recipe at least one day ahead and chill in the refrigerator overnight. This will allow the mixture to cool completely and increase volume. Base mixture may not freeze if it is not thoroughly chilled.
- Do not remove freezer bowl from the freezer until ready to use.
- Do not puncture or heat the freezer bowl.
- To allow mixture to expand to 1 1/2 quarts (6 cups/1420 ml) while churning, do not use more than 1 quart (4 cups/ ml) of recipe mixture at a time.

Care and Cleaning

⚠ WARNING


Electrical Shock Hazard. Disconnect power before cleaning. Do not immerse motor or cord in any liquid.



Wipe motor/base with a damp cloth. Do not immerse in water or other liquid.

⚠ WARNING

Shock Hazard. Disconnect power before cleaning. Do not immerse motor or cord in any liquid.



Wash cover, mixing paddle, and freezer bowl in sink.



Troubleshooting

PROBLEM	PROBABLE CAUSE/SOLUTION
<p>Ice cream is not firm enough or ice cream maker is still running after 60 minutes.</p>	<ul style="list-style-type: none"> • The freezer bowl was not in the freezer long enough (preferably overnight). • The freezer is not cold enough. Ice cream sets at 10° to 14°F (-12° to -10°C). Lower freezer temperature setting. • Too much mixture was put in freezer bowl. Maximum fill is 1 quart (946 ml). • Ingredients are warm or at room temperature. Prechill liquid ingredients. • The freezer bowl was left at room temperature for more than 5 minutes before use. • The freezer door was opened and closed too many times during the freezing process. • The freezer bowl has a thick coating of ice on the walls. After washing, dry completely prior to placing back in freezer.
<p>Ice cream maker stops churning before ice cream is ready.</p>	<ul style="list-style-type: none"> • Mix-in ingredients, such as chocolate chips or chopped nuts, added too soon. Wait until ice cream has churned for at least 15 minutes or until mixture is thick and has started to freeze. • The mix-in ingredients are too large, causing the paddle to jam. Prechop nuts or other ingredients. • Too large a quantity of mix-in ingredients have been added. Add one cup or less of mix-in ingredients.

Recipes

NOTE:

- ALWAYS freeze freezer bowl in freezer and chill prepared mixture in refrigerator before churning.
- To allow mixture to expand to 1 1/2 quarts (6 cups/1420 ml) while churning, do not use more than 1 quart (4 cups/946 ml) of recipe mixture in ice cream maker at a time.

Old-Fashioned Vanilla Ice Cream

- 3/4 cup (177 ml) sugar



- 1/8 teaspoon (0.6 ml) salt
- 1 3/4 cups (414 ml) whole milk
- 2 large eggs, beaten
- 1 1/2 cups (355 ml) heavy whipping cream
- 1 teaspoon (5 ml) vanilla extract

1. In heavy saucepan, combine sugar, salt, and milk. Cook over medium heat, stirring occasionally until mixture is steaming. Reduce heat to low.
2. In medium bowl, slightly beat eggs. Slowly whisk half of the hot mixture into the eggs and pour back into saucepan. Cook over medium-low heat until slightly thick, about 3 minutes. Remove from heat and refrigerate until chilled or overnight.
3. When ready to make ice cream, stir heavy cream and vanilla into the chilled custard mixture.
4. Start ice cream maker and pour mixture through hole in lid.
5. Churn for 20–40 minutes or until desired consistency.

Easy Vanilla Ice Cream

- 2 cups (473 ml) half 'n half
- 1 cup (237 ml) heavy whipping cream
- 1 1/2 teaspoons (7.5 ml) vanilla
- 1/2 cup (118 ml) sugar

1. Combine all ingredients in bowl. Mix well.
2. Start ice cream maker and pour mixture through hole in lid.
3. Churn for 20–40 minutes or until desired consistency.

Variations: Add mix-ins, such as chocolate chips or chopped nuts, after ice cream has churned for at least 15 minutes or when mixture is thick and has started to freeze.

Chocolate Ice Cream

- 2 cups (473 ml) heavy whipping cream
- 1 cup (237 ml) whole milk
- 1/2 cup (118 ml) sugar
- 1/4 cup (59 ml) cocoa powder
- 1 teaspoon (5 ml) vanilla

1. Combine sugar and cocoa in small bowl.
2. In saucepan over medium heat, warm cream and milk.
3. When cream and milk mixture is warm, whisk in sugar and cocoa mixture and vanilla. Whisk until sugar is dissolved and mixture is well-combined.

4. Chill in refrigerator overnight.
5. When ready to make ice cream, start ice cream maker and pour mixture through hole in lid.
6. Churn for 20–40 minutes or until desired consistency.

Strawberry Sorbet

1/2 cup (118 ml) sugar

1 cup (237 ml) water

4 cups (946 ml) fresh or thawed frozen strawberries

1 tablespoon (15 ml) lemon juice

1. Combine sugar and water in heavy saucepan. Bring to a boil. Reduce heat to low and simmer until all sugar is dissolved.
2. Remove from heat; place in refrigerator and cool completely.
3. Puree strawberries; then add lemon juice and sugar water.
4. Start ice cream maker and pour mixture through hole in lid.
5. Churn for 20–40 minutes or until desired consistency.

Peaches and Cream Ice Cream

- 1 cup (237 ml) chopped fresh or frozen peaches
- 1/2 cup (118 ml) sugar
- 2 cups (473 ml) heavy whipping cream
- 1/2 cup (118 ml) whole milk
- 2 teaspoons (10 ml) vanilla

1. Combine peaches with 1/4 cup (59 ml) of sugar. Let stand for 1 hour.
2. Place mixture in food processor and pulse until peaches are coarsely chopped.
3. Add remaining 1/4 cup (59 ml) sugar, cream, milk, and vanilla to the peach mixture.
4. Start ice cream maker and pour mixture through hole in lid.
5. Churn for 20 –40 minutes or until desired consistency.

Cappuccino Gelato

- 2 cups (473 ml) half 'n half
- 1 cup (237 ml) heavy whipping cream
- 1/2 cup (118 ml) sugar
- 1 teaspoon (5 ml) vanilla
- 2 tablespoons (30 ml) instant espresso or coffee powder

- 1/8 teaspoon (0.6 ml) cinnamon

1. In saucepan over medium heat, warm half 'n half and cream.
2. When cream and milk mixture is warm, whisk in sugar, vanilla, coffee powder, and cinnamon. Whisk until sugar and coffee are dissolved and mixture is well-combined.
3. Chill in refrigerator overnight.
4. When ready to make ice cream, start ice cream maker and pour mixture through hole in lid.
5. Churn for 20–40 minutes or until desired consistency.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.