

PACKAGE CONTENTS




Sound Bar



Remote Control
with 2x AAA Batteries



Power Cable



Stereo RCA to
3.5mm Audio Cable
with Adapter




Digital Optical
Cable




User Manual


CONTROLS & CONNECTIONS



Top of Sound Bar



FIRST-TIME SETUP



Optional: Use the included RCA adapter to connect to your TV if needed.

* Not all TVs have the audio outputs shown. To connect the sound bar directly to your other devices (Blu-ray player, game system, etc.) see your device's user manual.

When using the digital input, if there is no audio,

- try setting the TV output to PCM, or
- connecting directly to your Blu-ray or other source.

DO NOT connect to Video Input R/L. Look for audio port OUT.

2. Connect the power cable to the sound bar AC IN as shown. Plug the power cable into an electrical outlet.

3. Remove the battery cover by gently sliding it away from the remote.

4. Insert the included batteries and gently slide the battery cover back into place.

When needed, VIZIO recommends replacing the batteries that came with this remote with two, new Duracell 'AAA' alkaline batteries.

5. Turn on your TV and sound bar. The sound bar will automatically begin searching for an active input.*

The LED indicator on the front of the sound bar will begin cycling through inputs until an audio source is detected.**

Tip: Pressing the INPUT button will stop the auto detect function.


You can press the INPUT button to switch between audio sources. For example, if you connected your TV to Optical, set the sound bar to Optical.

*Occurs only during first-time set up.


**Auto detect function only occurs once when the sound bar is first powered on. To enable this feature again, you must do a Factory Reset (see the Using Button Combinations section for more information) or press and hold the INPUT button for 3 seconds.



USING THE REMOTE




For the best sound experience, position the sound bar as shown. The sound bar should be close to ear level.



LED INDICATOR

The LED and speakers will react differently for each function.



LED Indicator is located here.

- **Input The LED will blink a different color for each input.**

Press the INPUT button on the remote to cycle through the available inputs. Specific inputs will show a different LED color:

- AUX In: Green
- Digital Optical: Red
- Bluetooth: Blue
- USB In - USB

Press and hold the INPUT button on the remote control for 3 seconds to enable the auto input detect function.

- **Bluetooth Pairing The LED will blink blue when searching and turn solid once a device is paired successfully.**

Press and hold the button on the remote. The sound bar will announce that it "searching." It will be discoverable for 15 minutes. You can now search for the sound bar (VIZIO SB2020n) using your Bluetooth device. The sound bar will power down if no device is found.

Note: Set your Bluetooth device into pairing mode prior to the sound bar.

- **DTS TruVolume On/Off A high tone double beep: On, Low tone double beep: Off**

Press the TVOL button to enable/disable TruVolume.

When enabled (On), TruVolume provides a consistent and comfortable volume level for a more enjoyable listening experience.

- **Virtual:X On/Off High tone double beep: On , Low tone double beep: Off**

Press the VRT:X button to enable/disable Virtual:X. When enabled (On), all inputs will produce a virtual sound technology that simulates the effect of having overhead sound. When disabled (Off), all sources will playback in stereo.

- **Mute If muted, the LED indicator will slowly pulse.**

Press the Mute button to mute/unmute the sound bar

- **Equalizer Mode A voice notification will announce EQ modes as they are changed.**

Press the EQ button to cycle through equalizer settings: Movie, Music, Dialogue, and Game. Note: Movie mode is on by default.

- **Treble Levels High tone double beep: Max level, Medium tone single beep: Mid level, Low tone double beep: Minimum level**

Press the TREBLE button then press the Next/Previous button to increase/ decrease the treble level.

Note: Mid level is the default setting.

- **Bass Levels High tone double beep: Max level ; Medium tone single beep: Mid level ; Low tone double beep: Minimum level**

Press the BASS button then press the Next/Previous button to increase/ decrease the bass level.

Note: Mid level is the default setting.

If a subwoofer is connected, adjusting the bass level will also adjust the subwoofer level. Consult your subwoofer's user manual for additional adjustments that may optimize your listening experience.

- **Night Mode On/Off High tone double beep: On ; Low tone double beep: Off**

Press the NIGHT button to enable/disable Night Mode. When enabled (On), the bass level will be lowered on the sound bar. If an external subwoofer is connected, bass level will also be lowered.

Note: Night mode will be OFF the next time the sound bar is turned on.

Using Button Combinations

There are other functions that are triggered by different button combinations on the sound bar.

- **Factory Reset LED will flash 3 times.**

Reset the sound bar to the factory default settings. To perform a Factory Reset, Press and Hold the Bluetooth () and Volume Down (—) buttons for 5 seconds.

Note: This will erase all settings and preferences that you have set

- **VIZIO TV Remote Control High tone double beep: On; Low tone double beep: Off**

Enable/disable the use of a VIZIO TV remote control to power on and adjust the volume of the sound bar. To enable/disable this function, Press and Hold the Power () and Volume Up (+) buttons for 5 seconds.

- **Eco Power Mode High tone double beep: On; Low tone double beep: Off**


When the Eco Power mode setting is enabled, the sound bar will automatically power down after a period of inactivity. When disabled, the sound bar will remain powered on until you turn it off. To enable/disable this function, Press and Hold the Power () and Volume Down (—) buttons for 5 seconds.

Note: Eco Power Mode setting is OFF by default.

BLUETOOTH PAIRING

To pair the sound bar with a Bluetooth device:

1. Press and hold the Bluetooth button on the sound bar or remote control for five (5) seconds or select the Bluetooth button on the remote. When the sound bar is in Bluetooth Pairing Mode, the LED Indicator on the front display panel will turn blue and start blinking. Once the device is paired, the LED Indicators will stop blinking.
2. You can now search for the sound bar (VIZIO SB2020) using your Bluetooth device. For more information, refer to the user documentation that came with the device.
3. Play audio from your Bluetooth device. Volume can be controlled on your source device and the sound bar.



Using Bluetooth Mode

Your sound bar supports music streaming from devices with Bluetooth capability. (Device compatibility will vary, see your device's documentation for more information.)

- Once you have paired your source device to the sound bar your device should remain paired (within range).
- If the source is changed back to Bluetooth, any paired Bluetooth device will reconnect automatically.
- If the input is changed, the Bluetooth device will disconnect (will stay connected if Auto VA BT is on).

Maximizing Signal

A Bluetooth signal has a range of up to 30 feet. Keep in mind that Bluetooth is a compressed audio format, so streamed music may lose some integrity when compared to a wired connection.


Try the following if your sound quality is less than optimal:

- If you hear any break-up or disconnect while streaming music from your device, move the source device closer to the sound bar.
- Be sure that there are no solid obstructions in the line-of-sight between the sound bar and the source device.
- Other wireless devices can affect Bluetooth range, including wireless security cameras, wireless video baby monitors, cordless phones, and microwave ovens. Turning off or moving these devices may improve Bluetooth range.

Your sound bar is not equipped with a microphone, so it cannot operate as a hands-free device for a smartphone.

Reduce the volume levels on your device and on the sound bar before pressing Play. High volume levels can damage your hearing.

ADVANCED SETUP



Help & Troubleshooting

There is no power.

- Press the POWER button on the remote control or on the top of your sound bar.
- Ensure the power cord is securely connected.
- Plug a different device into the electrical outlet to verify that the outlet is working correctly.

There is no sound.

- Increase the volume. Press VOLUME UP on the remote control or on the top of your sound bar.
- Press MUTE on the remote to ensure the sound bar is not muted.
- Press INPUT on the remote or on the top of your sound bar to select a different input source.
- When using the Digital Optical input, if there is no audio: (A) try setting the TV output to PCM or (B) connect directly to your Blu-ray/other source, some TVs do not pass through digital audio.
- On digital inputs, the input LEDs will flash rapidly if an unsupported format is present. Set the source to output PCM.
- Your TV may be set to variable audio output. Confirm that the audio output setting is set to FIXED or STANDARD, not VARIABLE. Consult your TV's user manual for more detailed information.
- If using Bluetooth, ensure that the volume on your source device is turned up and that the device is not muted.

I hear buzzing or humming.

- Ensure all cables and wires are securely connected.
- Connect a different source device (TV, Blu-ray player, etc) to see if the buzzing persists. If it does not, the problem may be with the original device.
- Connect your device to a different input on the sound bar.

The remote isn't working.

- Replace the remote batteries with new ones.
- Point the remote directly at the center of the sound bar when pressing a button.
- If using a Bluetooth connection, some of the buttons on the remote may not be supported by the streaming application.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.