



Product Diagram


Robot




Bottom View



Docking Station



Remote Control



Operating and Programming

Notes Before Cleaning


WARNING: Do not use DEEBOT on wet surfaces or surfaces with standing water.




Before using the product on a rug with tasseled edges, please fold the rug edges under.



Tidy up the area to be cleaned by putting furniture, such as chairs, in their proper place.




It may be necessary to place a physical barrier at the edge of a drop to stop the unit from falling over the edge.




Remove power cords and small objects from the floor that the robot could be obstructed by.

Preparation

1. Remove Protective Strip




2. Docking Station Placement




3. Install Side Brushes



4. Power ON



5. Charge DEEBOT




Note: When DEEBOT completes the cleaning cycle or when battery power gets low, DEEBOT automatically returns to the Docking Station to recharge itself.


Selecting Cleaning Mode

1. AUTO Cleaning Mode


A **Programmed Cleaning Pattern** (optimized for hard floors) will be selected by default.




2. Return to Docking Station



3. Edge Cleaning Mode



4. Spot Cleaning Mode (Less than 3 minutes)



5. Continuous Cleaning

DEEBOT automatically navigates itself back to the Docking Station to power up when low on battery. Once recharged, it will return to finish cleaning where it left off.

All the functions mentioned above can be enabled on the App. Download ECOVACS App to access more features, including Max Mode, Scheduled Cleaning, etc.




Q ECOVACS HOME



☑ iOS 9.0 or later ☑ Android 4.0 or later

Pause, Wake Up, Power Off

1. Pause




Note: The robot's Control Panel stops glowing after the robot is paused for a few minutes. Press the AUTO Mode Button on DEEBOT to wake up the robot.


2. Wake Up



Press the AUTO button on DEEBOT to wake it up



2. Power OFF






Note: When DEEBOT is not working, it is recommended to keep it switched ON and charging.

Maintenance

Before performing cleaning and maintenance tasks on DEEBOT, turn the robot OFF and unplug the Docking Station.

Dust Bin and Filters


Dust Bin




Main Brush and Side Brushes

Note: A Multi-Function Cleaning Tool is provided for easy maintenance. Handle with care, this cleaning tool has sharp edges.


Main Brush




1.




2.



3.




4.




5.


Side Brushes



1.




2.




3.

Other Components



Note: Before cleaning the robot's Charging Contacts and Docking Station Pins, turn the robot OFF and unplug the Docking Station.



Regular Maintenance

To keep DEEBOT running at peak performance, perform maintenance tasks and replace parts with the following frequencies:

Robot Part	Maintenance Frequency	Replacement Frequency
Side Brush	Once every 2 weeks	Every 3-6 months
Main Brush	Once per week	Every 6-12 months
Sponge Filter/ High Efficiency Filter	Once per week	Every 3-6 months
Universal Wheel Anti-Drop Sensors Bumper Charging Contacts Docking Station Pins	Once per week	/

A multi-function Cleaning Tool is provided for easy maintenance. Handle with care, this cleaning tool has sharp edges.

Note: ECOVACS manufactures various replacement parts and fittings. Please contact Customer Service for more information on replacement parts.

Indicator Light and Alarm Sounds

DEEBOT will tell you something is wrong with an alarm indicator light and sounds. More detailed support is available through the ECOVACS App and online website.

Indicator Light

Scenario	Indicator Light
The robot is cleaning	AUTO Mode Button glows a solid WHITE
The robot is charging	AUTO Mode Button flashes WHITE
The robot has low battery	AUTO Mode Button glows a solid RED
The robot has a problem	AUTO Mode Button flashes RED
Programmed Cleaning Pattern is enabled	Cleaning Mode Switch Indicator lights up

Troubleshooting



Malfunction	Possible Causes	Solutions
DEEBOT is not charging.	DEEBOT is not switched ON.	Switch ON DEEBOT.
	DEEBOT has not connected to the Docking Station.	Be sure that the robot's Charging Cord have connected to the Docking Station.
	The battery is completely discharged.	Re-activate the battery. Switch ON DEEBOT. Place DEEBOT on the Docking Station. Turn the robot on by hand, remove after charging for 3 minutes. Repeat 3 times; then charge normally.
DEEBOT cannot return to the Docking Station.	The Docking Station is not correctly placed.	Refer to Section 3.2 to correctly place the Docking Station.
DEEBOT gets stuck while working and stops.	DEEBOT is tangled with something on the floor (electrical wires, curtains, carpet fringing, etc.).	DEEBOT will try various ways to free itself. If it is unsuccessful, manually remove the obstacles and restart.
DEEBOT returns to the Docking Station before it has finished cleaning.	When the battery gets low, DEEBOT automatically switches to Return to Charger Mode and returns to the Docking Station to recharge itself.	This is normal. No solution necessary.
	Working time varies according to floor surface, room complexity and the Cleaning Mode selected.	This is normal. No solution necessary.
DEEBOT does not clean automatically at the scheduled time.	Time Scheduling function is cancelled.	Program DEEBOT to clean at specific times using the ECOVACS App.
	The Continued Cleaning function is turned ON and DEEBOT has just finished cleaning the scheduled cleaning area.	This is normal. No solution necessary.



	DEEBOT is switched OFF.	Switch ON DEEBOT.
	The robot's battery is low.	Keep DEEBOT switched ON and connect it to the Docking Station to make sure it has a full battery to work at any time.
	The robot's Suction Intake is blocked and/or there is debris stuck in its components.	Power OFF DEEBOT, clean the Dust Intake, invert the robot. Clean the robot's Suction Intake, Side Brushes and the Main Brush as described in Section 4.
DEEBOT does not clean the whole area.	The cleaning area is not tidy.	Remove small objects from the floor and tidy up the cleaning area before DEEBOT starts cleaning.
DEEBOT is not able to connect to the home Wi-Fi network.	Incorrect home Wi-Fi username or password entered.	Enter the correct home Wi-Fi username and password.
	DEEBOT is not within range of your home Wi-Fi signal.	Make sure DEEBOT is within range of your home Wi-Fi signal.
	Network setup started before DEEBOT was ready.	Turn ON Power Switch. Press the RESET Button for 3 seconds. DEEBOT is ready for network setup when it plays a musical note and its Wi-Fi Indicator light flashes slowly.
	Your smartphone's operating system needs to be updated.	Update your smartphone's operating system. The ECOVACS App runs on iOS 9.0 and above, Android 4.0 and above.

Warning

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.

