



## HELLO DREAM PC! REMOVING PROTECTIVE FOAM

Before you begin, you must remove the protective packing foam before turning on your system




**Note:** Some cases may have plastic film on the side panel. You can remove these.

Unscrew the screws from the left side panel and remove the panel



Carefully and gently remove the protective packing foam from inside the system




**Note:** Depending on system build. there may be more cables.  
Check that the cables were not disconnected during shipping

## CONNECT

### CONNECTIVITY 101 - DISPLAY AND PERIPHERALS

Connect your display, peripherals, and more, for the ultimate gaming experience.




**Note:** Different video cards have different connectivities  
Connect your display only to the video card installed as shown


## POWER

### LET THERE BE LIGHT ! POWER ON YOUR PC

Connect the power cable to the back of your system. Make sure the power supply is switched on.




Plug-in the power cord and switch on the power supply before hitting the power button



Power on the system by pressing the power button (location of button may vary)

**Note:** Ports may vary depending on your motherboard



Connect your peripherals shown on the diagram above

## ACTIVE ALMOST THERE! ACTIVATING WINDOWS PRODUCT KEY

Find the Windows Product Key sticker on the side or back of your computer and copy the code exactly.

We recommend taking a picture. (Some systems may not require this step)

**Note:** In some instances, your system is pre-activated by iPower and will not require a product key to be entered

## FAQ

### Where is my Windows Product key sticker?

For most systems the Windows Product Key sticker is located on the side of your PC. For some systems, it may be placed on the back. Some systems do not require a product key to be entered for activation, and are pre-activated by iBUYPOWER. During your first boot experience, Windows will ask for your product key if it is required

### Why did my computer come with extra cables and extra discs?

All extra accessories are supplied in the event that you would like to add more devices or peripherals to your computer. Extra discs are provided to assist with reinstalling Windows and/or the necessary drivers. These should only need to be used when reformatting your system, as all necessary drivers will have been installed during assembly.

### I can hear my system boot up, but the screen is blank.

This may be caused by your monitor being plugged into the wrong video port. The monitor should be connected to the video card (horizontal port underneath the audio ports) as opposed to the motherboard (vertical port near the top of the PC). Also, be sure that your monitor is set to the correct input (HDMI, DVI, etc.).

### **When I start the computer. I see “No Boot Device Found.”**

Check that all cables are properly connected as they may have come loose during shipping. If all cables are properly connected and the problem persists. your computer may be trying to boot to the wrong disk drive.

#### **Warning**

This content is compiled from multiple sources and is provided for reference purposes only. It may not be complete or fully applicable to all situations. If you are unable to resolve your issue, please contact the product manufacturer or an authorized service provider for official support.