

 A Phoenix Mecano Company	Issue Department: Bedding Division	Date:	2025-4-16
	System Instruction	Author:	Alexandria
Instruction of RF7421		Edition:	1.1
		Page 1 of 5	

Instruction of RF7421



REMOTE CONTROL

Figure 1 button ofremoteItem



 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2025-4-16
	System Instruction	Author:	Alexandria
Instruction of RF7421		Edition:	1.1
		Page 2 of 5	

1.1 AntiSnore button 1

Press the ANTI SNORE button, and the bed will move to the ANTI SNORE position.

1.2 LIGHT button 2

Click this button to turn on/off lighting.

1.3 TV button 3

Press this button to recline the bed to the position.

1.4 ZeroG button 4

Press the zeroG button, and the bed will move to the zeroG position. Hold the zeroG button for 5 seconds until the backlight blinks, and the control box will set the current position as the zeroG position.

1.5 TV button 5

Press the TV button, and the bed will move to the TV position. Hold the TV button for 5 seconds until the backlight blinks, and the control box will set the current position as the TV position.

1.6 M1 button 6

Click M1 button, the bed moves to M1 position, press and hold it for 5s until backlight flashes, the control box set the current position as M1 position.

1.7 Child Lock button 7

Press and hold CHILD LOCK button for 5s until backlight flashes, then the lock/unlock is complete.

1.8 M2 button 8

Press the M2 button, and the bed will move to the M2 position. Hold the M2 button for 5 seconds until the backlight blinks, and the control box will set the current position as the M2 position.

1.9 HEAD UP button 9

press and hold this button, head actuator moves out, stop when released.

1.10 FOOT UP button 10

press and hold this button, foot actuator moves out, stop when released.

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2025-4-16
	System Instruction	Author:	Alexandria
Instruction of RF7421		Edition:	1.1
		Page 3 of 5	

1.11 HEAD DOWN button 11

press and hold this button, head actuator moves in, stop when released.

1.12 FOOT DOWN button 12

press and hold this button, foot actuator moves in, stop when released.

1.13 FLAT button 13

Press this button to recline the bed to a flat position.

1.14 Head and Foot UP button 14

press and hold this button, head+foot actuator moves in, stop when released.

1.15 Head and Foot Down button 15

press and hold this button, head + foot actuator moves in, stop when released.

1.19 ON/OFF button 16

Click here to turn the massage on or off.

1.17 MASSAGE TIMER button 17

When the massage function is activated, press the button to switch the massage duration (10-20-30min-Off).

1.18 UNDER BED LIGHT button 18

click this button to turn on/off under bed lighting.

1.16 HEAD MASSAGE button 19

Click here to select the head massage intensity up.

1.20 MODE button 20

Click here to select the massage mode.

1.21 FOOT MASSAGE button 21

Click here to select Foot Massage.

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2025-4-16
	System Instruction	Author:	Alexandria
Instruction of RF7421		Edition:	1.1
		Page 4 of 5	

1.1 Matching Code button 9 and button 11

Press and hold this key to perform the pairing code operation.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2025-4-16
	System Instruction	Author:	Alexandria
Instruction of RF7421		Edition:	1.1
		Page 5 of 5	

ISED Statement

- English: This device contains licence-exempt transmitter(s)/receiver(s) that

comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).
Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

- French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont

conformes aux CNR exempts de licence d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé.

Cet équipement doit être installé et utilisé avec une distance minimale de 0 cm entre le radiateur et votre corps.