


# Electronic Hand Sink with AC Adapter

## INSTALLATION INSTRUCTIONS

### CAUTION

INSPECT CONTENTS IMMEDIATELY AND FILE CLAIM WITH DELIVERING CARRIER FOR ANY DAMAGE. **SAVE YOUR BOX AND ALL PACKING MATERIALS.** YOU ARE RESPONSIBLE FOR DAMAGE TO YOUR UNIT IF RETURNED IMPROPERLY PACKED.




### Parts List

item#	description
1	Electronic eye faucet
2	Faucet control box
3	Water Tempering (or "Mixing") Valve
4	AC Adapter
5	Sensor Cable
6	S/S Hose with blue stripe
7	S/S Hose with red stripe
8	S/S Hose (mixed)

### Before assembly...

1. Flush all water lines until water runs clear before connecting faucet to supply stops.
2. Avoid surroundings with bright lights, highly reflective surfaces, and sunlight which can affect the sensor's performance.
3. Make sure the tee-shaped fitting with the filter is installed onto the control box (see illustration at right).
4. Remove and discard the protective cap over the sensor connection on top of the control box. Only remove lower cap if using the AC adapter.



### Step 1 - Mount faucet body onto sink.

(Refer to *fig. 1*)

- a. Carefully thread sensor cable through hole in backsplash.
- b. Affix faucet onto backsplash, using plumbers' putty (not included) between backsplash and faucet body.
- c. Install faucet washer, being careful to not pinch the sensor cable.
- d. Install faucet nut and tighten while ensuring faucet body is level. Wipe away excess plumber's putty.




fig. 1

(continued on Page 2)


# Electronic Hand Sink with AC Adapter

## INSTALLATION INSTRUCTIONS

### Step 2 - Connect elbow and supply hose.

(Refer to *fig. 2*)

- Wrap Teflon tape (not included) around threaded stem of faucet body, and attach NPSM 90-degree plumbing elbow onto threaded stem.
- Attach 30" hose from elbow to fitting on top of control box.




*fig. 2*

### Step 3 - Connect water supply.

(Refer to *fig. 3*)

- Attach water tempering valve to bottom of tee at faucet control box assembly.
- Attach water supply hose (from back of faucet) to top of control box.
- Connect supply hoses (hot = hose with red stripe, cold = hose with blue stripe) from the plumbing stops to the water tempering valve.
- Mount faucet control box to wall (hardware not included) near sink.




*fig. 3*

### Step 4 - Connect wiring to control box. Plug in power supply.

(Refer to *fig. 4*)

- Plug sensor eye cable into connector on top of control box.
- Plug power adapter into connector on bottom of control box.
- Plug power adapter into 120V electrical power supply outlet. If wire between faucet and power adapter is too long, coil the excess wire and secure it so that it does not contact any surface or object below it.



*fig. 4*

### Step 5 - Check for leaks.

***IF THERE IS A LEAK, UNPLUG POWER ADAPTER FROM THE WALL BEFORE TENDING TO LEAK.***

Installation is complete.

(End)

(continued on Page 3)

# Electronic Hand Sink with AC Adapter

## OPERATING INSTRUCTIONS

### OPERATION

1. Place hands under spout. Water will flow as long as the user's hands remain within sensor range.
2. Clean filter every month.
3. Keep electronic eye cover clean.
4. Red flashing in the electronic eye indicates low batteries. Replace with four (4) "AA" alkaline batteries. Fresh batteries should last 400,000 on/off cycles.
5. Solid red light and no water flow indicates batteries are dead.
6. When used with the optional AC adapter, the faucet will automatically switch to AC power and conserve its battery power.

### SPECIFICATIONS

Max running time: 30-seconds while hands are in sensor range or On/Off button pressed

Response time: 0.3-seconds

Sensing range: 3/4" (19mm) to 6-11/16" (169.9mm)

Power source: AC/DC

Low battery indicator: Flashing red LED

### SENSOR RANGE SETUP

The sensor range is preset at the factory during assembly but can be further adjusted using the steps below.

1. The sensor range is adjustable from 3/4" (19mm) to 6-11/16" (169.9mm). If there is a disruption of power, the sensor range is saved and will revert to the last saved setting when restored.
2. Faucet sensor range is set by using the On/Off button on the front of the control module. Do not attempt to open the control module box.
3. Push and hold the On/Off button; water will flow. After holding the button 5 to 7 seconds, the water flow will stop and the red LED in the sensor lens (on the front of the faucet body) will turn on solid.
4. Release the On/Off button. The red LED will turn off signaling that the sensor is ready for set-up for the next 15 seconds.
5. Hold your hand still in front of the sensor at the desired sensor distance. The red LED will flash roughly 5 times then remain on for 2 seconds indicating the new range has been set.
6. If step 5 is not done within 15 seconds, the red LED will blink quickly then stop indicating the sensor range has NOT been changed. Start over at step 3 to change the sensor range.

### BATTERY REPLACEMENT

1. Your sensor faucet requires four (4) AA alkaline batteries. If AC adapter is used, unplug it from its power source.
2. Remove the battery cover's three (3) screws and pull cover away from the control box.
3. Remove the old batteries.
4. Install the new AA batteries, making sure that the + and - ends are facing the correct direction. Return the battery cover to its spot and tighten screws. If the AC adapter is to be used, plug it in at this time.
5. With the disconnection of power, the sensor range is saved and will revert to the last setting when power is restored.

(continued on back page) 

# Electronic Hand Sink with AC Adapter

## FAQ

### FREQUENTLY ASKED QUESTIONS

**Q. Can I operate the faucet manually, without using the electronic eye?**

A. Yes. Press the ON/OFF button and water will start flowing. To turn water off, press ON/OFF button again. If you forget to turn the water off, the faucet will automatically turn it off after 30 seconds.

**Q. What is the optimal sensing distance?**

A. Just in front of the water stream on the side towards the user.

**Q. Does the electronic eye require special maintenance?**

A. For the sensor to function, the electronic eye must be clean. Use only mild soap and water. Wipe with a soft cloth.

**Q. How often should I clean the filter?**

A. Depending on the quality of the water in your area, every 4 to 12 weeks.

**Q. Why doesn't the water shut itself off after I have moved my hands away from the electronic eye?**

A. Sensor range could be too long. User may have to adjust sensor range.

**Q. No water comes out of the faucet and the red LED stays on. What is the problem?**

A. Replace the batteries.

(End)



• 100 Industrial Boulevard, Clayton, Delaware 19938-8903 U.S.A.  
• Phone: 302/653-3000 • 800/441-8440 • Fax: 302/653-2065  
• [www.eaglegrp.com](http://www.eaglegrp.com) • [www.eaglegrpnews.com](http://www.eaglegrpnews.com) • [www.eaglemhc.com](http://www.eaglemhc.com)

Eagle Foodservice Equipment, Eagle MHC, and SpecFAB® are divisions of Eagle Group. ©2022 by the Eagle Group