




Contents

CE & FCC	1
Safety Information	4
Battery Installation	6
Bind The Product	7
Basic Parameters	8
After-Sales Service	9

CE & FCC

FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the

— 1 —

receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

EU regulatory conformance:

RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20mW specified in EN62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation (1999/519/EC).

CE DCC

Hereby, Shenzhen USEER Robotics Co.,Ltd declares that the radio equipment type PF5 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.petgugu.com

— 2 —

Manufacturer information

Company name: Shenzhen USEER Robotics Co.,Ltd

Address: Building 2, Fashion Brand Industrial Park, E'Bu Town, Shenzhen-Shanwei
Special Cooperation Zone, Shenzhen, Guangdong, China

Operation temperature: 0-40 C

Operation frequency (Max power)

Bluetooth: 2402-2480 (**dBm)

Safety Information

* Before using the device, please read the following precautions to ensure optimal performance and prevent potential hazards.

1. All accessories of this device are not edible. Please prevent children from ingesting them accidentally.
2. The device and its accessories may contain small parts. Keep the device and its accessories out of reach of children to avoid unintentional damage or ingestion of small parts, which may lead to choking or other dangers.
3. Use the device within the temperature range of 0°C to 40°C and store it and its accessories within the temperature range of -10°C to +45°C. Operating the device in excessively high or low temperatures may result in malfunctions.
4. Avoid intentionally submerging, soaking, or exposing the device and its accessories to prolonged water, rain, or moisture to prevent device malfunctions.
5. Keep the device and its batteries away from heat sources, high temperatures, and direct sunlight. Do not throw the device or batteries into fire, crush or modify the device, insert foreign objects into it, or immerse it in hot water or other liquids to prevent battery leakage, overheating, fire, or explosion.
6. Do not modify the device or replace its accessories without authorization. When replacing the battery, use the same model (CR2032) and capacity, and observe the correct polarity. Using the wrong battery type may pose a risk of fire or electric shock.

— 4 —

7. Place batteries out of the reach of children and avoid swallowing them. If a battery is ingested or inserted into the body, seek medical attention immediately. Ingesting a battery may cause severe chemical burns within two hours, leading to serious injury or death.
8. In very dry environments, the product is more prone to static electricity. To minimize the risk of static discharge, avoid using the device in extremely dry conditions or touch grounded, unpainted metal objects before use.
9. When it is necessary to discard or dispose of the device, follow local regulations for proper disposal of the device, batteries, and other accessories. Do not treat them as household waste, as improper disposal may result in battery explosions.

Scannen Sie den QR-Code, um das Online-Handbuch auf Deutsch zu erhalten.

Scannez le QR code pour obtenir le manuel en ligne en français.

Scansiona il codice QR per ottenere il manuale online in italiano.

Escanee el código QR para obtener el manual en línea en español.

コードをスキャンして、日本語のオンライン マニュアルを取得します。

扫描二维码获取在线中文说明书。

Battery Installation

To install or replace the battery:

1. Place the product with the battery cover facing upwards in the palm of your hand, align the rear cover tab with the groove on the battery cover, then rotate counterclockwise and release after rotating. (Hold with both palms and rotate counterclockwise, then release after rotation is complete.)
2. Remove the back cover.
3. Insert the CR2032 battery into the device with the positive side (+) facing up.
4. Place the battery back cover on the product.
5. Place the product with the battery cover facing upwards in the palm of your hand, align the rear cover tab with the groove on the battery cover, then rotate clockwise until the rotation is complete. (Hold with both palms and rotate clockwise until the rotation is complete.)

Note: Please use the correct model of battery. Replacing with an incorrect battery may pose a risk of fire and electric shock.

— 6 —

Bind The Product

Attention:

1. This product only supports binding with petgugu water dispensers or feeders version V1.1 and above. Please confirm the version of the water dispenser or feeder before binding.
2. If there are multiple water dispensers or feeders under the same APP account, it is only necessary to bind one of the devices.
3. Any one of the following binding methods can be chosen for binding.

Regular Binding:

1. Please confirm that the product has been started normally.
2. Place the product next to the water dispenser or feeder connected to the APP for pairing, and open the Petgugu APP.
3. Scoop some water from the water dispenser or take some pet food from the feeder's food bowl.
4. Wait for the Petgugu APP to detect the data and pop up the binding prompt. Follow the binding instructions to complete the binding.



* If the binding steps are correct, and the version of the water dispenser feeder is V1.1, but the binding fails, you can restart the product or the water dispenser feeder and try binding again.

— 7 —

Scan to Bind:

1. Open the product battery cover.
2. Open the petgugu APP, click on '+ Add Device' on the 'Devices' page to enter the device adding page.
3. Click to add recognizer, enter the scanning code interface.
4. Scan the QR code engraved inside the product battery compartment, then follow the instructions on the page to bind.

Basic Parameters

Product Name: Pet Identity Recognizer	
Product Model: PF5	
Battery Model: CR2032 Button Battery	
Battery Life: 3 Months	
Main Materials: ABS, Zinc Alloy	
Operating Temperature: 0°C ~ 40°C	
Operating Humidity: 10% ~ 90%RH	
Net Weight: 13.5g / 20g	
Product Size: 30x30x10mm / 30x30x15mm	

After-Sales Service

Purchase Information

User Name _____

User Contact Number _____

User Mailing Address and Postal Code _____

Date of Purchase _____

Maintenance Records

Maintenance Center Name _____

Maintenance Center Phone Number _____

Date on Which The Device Was Sent in For Repair _____

Cause of Malfunction _____

Description of Malfunction During Initial Repair Request _____

Proof of Refund _____

Signature of Maintenance Personnel _____

Seal/Stamp of Maintenance Center _____

— 9 —

Scenarios That Are Not Covered By Warranty:

1. Damage caused by improper use, maintenance, or storage by the consumer.
2. Damage resulting from self-disassembly or disassembly by unauthorized personnel.
3. Damage caused by force majeure such as natural disasters.
4. Product malfunctions or damage due to accidents or human factors. (unauthorized modifications, liquid intrusion, scratches, collisions, compression, etc.)

Service Policy Notes:

1. If a purchased product exhibits quality issues upon unboxing, please contact the seller.
2. We provide lifetime maintenance services, but products that are beyond the warranty coverage period would require payment of corresponding fees based on the service or parts rendered.
3. For products with valid quality issues, the shipping costs will be borne by the manufacturer. If the problems are non-quality-related, then the buyer will be responsible for the shipping costs.
4. When sending the machine for replacement or repair, please kindly send the machine together with 3 the receipt attached. If gifts or invoices were provided, do include them in the return shipment.

— 10 —

Service And Support

✉ Email: service@petgugu.com


🌐 Website: www.petgugu.com

  AAA-YYYYYY

— 11 —

平面印刷品基本技术要求	
深圳市云视机器人有限公司	
设计：	日期:2024.04.16
尺寸:106×106mm	材质:105g 双铜纸过光油
页数:14p	印刷颜色：CMYK
比例:1:1	装订方式:正反印刷/风琴折/R角
物料名称	PF5说明书（英文）
产品型号	PF5
物料编号	
版次	V02（2024.04.24）
变更记录：	

此页为预览以及基本信息及印刷要求，不印刷。



petgugu

PF5 Identity Recognizer
User Manual

Please read this manual carefully and keep it properly before
using the product.

Contents

CE & FCC	1
Safety Information	4
Battery Installation	6
Bind The Product	7
Basic Parameters	8
After-Sales Service	9

CE & FCC

FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the

receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

EU regulatory conformance:

RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20mW specified in EN62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation (1999/519/EC).

CE DOC

Hereby, Shenzhen USEER Robotics Co.,Ltd declares that the radio equipment type PF5 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.petgugu.com

Manufacturer information
Company name: Shenzhen USEER Robotics Co.,Ltd
Address: Building 2, Fashion Brand Industrial Park, E'Bu Town, Shenzhen-Shanwei Special Cooperation Zone, Shenzhen, Guangdong, China

Operation temperature: 0~40 C
Operation frequency (Max power)
Bluetooth: 2402-2480 (**dBm)

Safety Information

* Before using the device, please read the following precautions to ensure optimal performance and prevent potential hazards.

1. All accessories of this device are not edible. Please prevent children from ingesting them accidentally.
2. The device and its accessories may contain small parts. Keep the device and its accessories out of reach of children to avoid unintentional damage or ingestion of small parts, which may lead to choking or other dangers.
3. Use the device within the temperature range of 0°C to 40°C and store it and its accessories within the temperature range of -10°C to +45°C. Operating the device in excessively high or low temperatures may result in malfunctions.
4. Avoid intentionally submerging, soaking, or exposing the device and its accessories to prolonged water, rain, or moisture to prevent device malfunctions.
5. Keep the device and its batteries away from heat sources, high temperatures, and direct sunlight. Do not throw the device or batteries into fire, crush or modify the device, insert foreign objects into it, or immerse it in hot water or other liquids to prevent battery leakage, overheating, fire, or explosion.
6. Do not modify the device or replace its accessories without authorization. When replacing the battery, use the same model (CR2032) and capacity, and observe the correct polarity. Using the wrong battery type may pose a risk of fire or electric shock.

7. Place batteries out of the reach of children and avoid swallowing them. If a battery is ingested or inserted into the body, seek medical attention immediately. Ingesting a battery may cause severe chemical burns within two hours, leading to serious injury or death.
8. In very dry environments, the product is more prone to static electricity. To minimize the risk of static discharge, avoid using the device in extremely dry conditions or touch grounded, unpainted metal objects before use.
9. When it is necessary to discard or dispose of the device, follow local regulations for proper disposal of the device, batteries, and other accessories. Do not treat them as household waste, as improper disposal may result in battery explosions.



Scannen Sie den QR-Code, um das Online-Handbuch auf Deutsch zu erhalten.
Scannez le QR code pour obtenir le manuel en ligne en français.
Scansiona il codice QR per ottenere il manuale online in italiano.
Escanee el código QR para obtener el manual en línea en español.
コードをスキャンして、日本語のオンライン マニュアルを取得します。
扫描二维码获取在线中文说明书。

Battery Installation

To install or replace the battery:

- Place the product with the battery cover facing upwards in the palm of your hand, align the rear cover tab with the groove on the battery cover, then rotate counterclockwise and release after rotating. (Hold with both palms and rotate counterclockwise, then release after rotation is complete.)
- Remove the back cover.
- Insert the CR2032 battery into the device with the positive side (+) facing up.
- Place the battery back cover on the product.
- Place the product with the battery cover facing upwards in the palm of your hand, align the rear cover tab with the groove on the battery cover, then rotate clockwise until the rotation is complete. (Hold with both palms and rotate clockwise until the rotation is complete.)

Note: Please use the correct model of battery. Replacing with an incorrect battery may pose a risk of fire and electric shock.

Bind The Product

Attention:

- This product only supports binding with petgugu water dispensers or feeders version V1.1 and above. Please confirm the version of the water dispenser or feeder before binding.
- If there are multiple water dispensers or feeders under the same APP account, it is only necessary to bind one of the devices.
- Any one of the following binding methods can be chosen for binding.

Regular Binding:

- Please confirm that the product has been started normally.
- Place the product next to the water dispenser or feeder connected to the APP for pairing, and open the Petgugu APP.
- Scoop some water from the water dispenser or take some pet food from the feeder's food bowl.
- Wait for the Petgugu APP to detect the data and pop up the binding prompt. Follow the binding instructions to complete the binding.

* If the binding steps are correct, and the version of the water dispenser feeder is V1.1, but the binding fails, you can restart the product or the water dispenser feeder and try binding again.

Scan to Bind:

- Open the product battery cover.
- Open the petgugu APP, click on '+ Add Device' on the 'Devices' page to enter the device adding page.
- Click to add recognizer, enter the scanning code interface.
- Scan the QR code engraved inside the product battery compartment, then follow the instructions on the page to bind.

Basic Parameters

Product Name: Pet Identity Recognizer

Product Model: PF5

Battery Model: CR2032 Button Battery

Battery Life: 3 Months


Main Materials: ABS, Zinc Alloy

Operating Temperature: 0°C ~ 40°C

Operating Humidity: 10% ~ 90%RH

Net Weight: 13.5g / 20g

Product Size: 30x30x10mm / 30x30x15mm



After-Sales Service

Purchase Information

User Name _____

User Contact Number _____

User Mailing Address and Postal Code _____

Date of Purchase _____

Maintenance Records

Maintenance Center Name _____

Maintenance Center Phone Number _____

Date on Which The Device Was Sent in For Fepair _____

Cause of Malfunction _____

Description of Malfunction During Initial Repair Request _____

Proof of Refund _____

Signature of Maintenance Personnel _____

Seal/Stamp of Maintenance Center _____

Scenarios That Are Not Covered By Warranty:

- Damage caused by improper use, maintenance, or storage by the consumer.
- Damage resulting from self-disassembly or disassembly by unauthorized personnel.
- Damage caused by force majeure such as natural disasters.
- Product malfunctions or damage due to accidents or human factors. (unauthorized modifications, liquid intrusion, scratches, collisions, compression, etc.)

Service Policy Notes:

- If a purchased product exhibits quality issues upon unboxing, please contact the seller.
- We provide lifetime maintenance services, but products that are beyond the warranty coverage period would require payment of corresponding fees based on the service or parts rendered.
- For products with valid quality issues, the shipping costs will be borne by the manufacturer. If the problems are non-quality-related, then the buyer will be responsible for the shipping costs.
- When sending the machine for replacement or repair, please kindly send the machine together with 3 the receipt attached. If gifts or invoices were provided, do include them in the return shipment.

Service And Support

✉ Email: service@petgugu.com

🌐 Website: www.petgugu.com

