


Wireless Microphone



USER MANUAL

Product Introduction

Dear user, thank you for choosing to use our wireless lavalier microphone. This manual will provide you with clear usage guidelines to help you quickly get started and fully utilize the product's functions. This product consists of three parts: microphone, receiver, and charging case. It can provide professional level recording and live streaming output, plug and play, without the need for an app, and can be used for online live streaming, video VLOG shooting, program interviews, interview recording, video teaching and other scenarios.



Charging Case




Microphone



Receiver

Microphone-Button



Multi-function Button

Power on/off – Long press

Noise reduction mode – Single click

Reverb mode – Double click

Silent mode – Three click

Microphone-Indicator light




Indicator Light

- Blue light slow flashing - Pairing
- Blue light steady on - Paired
- Green light steady on - Charging
- Green light off - Fully charged
- Red light flashing - Low battery
- Red light steady on - muted

Ai Long blue light on- noise reduction on

↑↑↓ Long blue light on -Reverb on

Receiver-Button



Power Button

Long press for 2 seconds to power on

Long press for 2 seconds to power off


Double-Click to Lock Pairing

Dial Wheel

Rotate downwards to increase the volume

Rotate upwards to decrease the volume


Receiver-Indicator light



Connection Light

Blue light stays on: Paired

Blue light slow blinking: Pairing in progress



Microphone Volume Light

Level 1 •

Level 2 • •

Level 3 • • •

Level 4 • • • •

Receiver Battery Light

• • • • —25%

• • • • —50%

• • • • —75%

• • • • —100%


Charging Case

Battery Light

- • • • — 25%
- • • • — 50%
- • • • — 75%
- • • • — 100%



Charging port



Usage Method

1. Take out the microphone and receiver; they will automatically pair when powered on. (The devices are ready to use when the indicator lights on both the microphone and receiver remain steadily lit.)

