



# ION HYPE XL QUICKSTART GUIDE V1.0 (ENGLISH)

## 1 GETTING STARTED

SCAN FOR FULL USER MANUAL

## 2 Plug IN TO FULLY CHARGE PRODUCT BEFORE USE, AND THEN POWER ON

Change Time: 15 hours charge time (based on 200mAh power adapter). Battery Capacity: 1700mAh/7.1V. Battery life: 10-15 hours. For normal charging, power off the speaker after charging.

Note: Adapter not included.

IONAUDIO.COM/SUPPORT For articles, videos, web and chat support.

IONAUDIO.COM/WARRANTY For complete warranty information.

Package Contents: Hype XL • USB-C to USB-C Charging Cable (2.5ft / 78 cm) • Quickstart Guide



## GUIA DE INICIO RAPIDO (ESPAÑOL)

## 2 CONECTE EL PRODUCTO PARA CARGARLO POR COMPLETO ANTES DE SU USO Y LUEGO ENCENDALO

Contenido del paquete: Hype XL • Cable de carga USB-C • Guía de inicio rápido.

Note: Adaptador no incluido.

IONAUDIO.COM/SUPPORT Para artículos, videos, sitios web y soporte por chat.

IONAUDIO.COM/WARRANTY Para información completa sobre la garantía.

## 1 PARA COMENZAR

## 3 ION SOUND CONTROL™ APP

Conéctese a la aplicación ION SOUND CONTROL™ para una experiencia más dinámica.

- Descargue la app de ION SOUND CONTROL™ desde la tienda de aplicaciones de su dispositivo.
- Conecte su dispositivo a su dispositivo móvil.
- Conecte su dispositivo a su dispositivo móvil.

## ESCANEAR PARA LA GUÍA DEL USUARIO



## 1 PARA COMENZAR

## 4 CREO SU EXPERIENCIA DE SONIDO

Note: Press and hold the SOURCE button to switch between modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## ESCANEAR PARA LA GUÍA DEL USUARIO



## 1 PARA COMENZAR

## 4 CREO SU EXPERIENCIA DE SONIDO

Note: Press and hold the SOURCE button to switch between modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## ESCANEAR PARA LA GUÍA DEL USUARIO



## 1 PARA COMENZAR

## 4 CREO SU EXPERIENCIA DE SONIDO

Note: Press and hold the SOURCE button to switch between modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## ESCANEAR PARA LA GUÍA DEL USUARIO



## 1 PARA COMENZAR

## 4 CREO SU EXPERIENCIA DE SONIDO

## 4 CREATE YOUR SOUND EXPERIENCE

Note: Press and hold the SOURCE button to switch between modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## BLUETOOTH

- Turn on Bluetooth mode.
- Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## AUX IN

- Press and hold the POWER button to power on Hype XL.
- Connect your device to the AUX port to listen to music. Press and hold the PLAY/PAUSE button to increase or decrease the volume.

## USE PLAYBACK

- Press and hold the POWER button to power on Hype XL.
- Connect your device to the USB port to listen to music. Press and hold the PLAY/PAUSE button to increase or decrease the volume.

## USB CHARGING

- Connect your smartphone, tablet, or other device to the USB-A port using a charging cable.

## BLUETOOTH

- Encienda Hype XL por modo Bluetooth.
- Presione y mantenga presionado el botón de fuente para conectarse a un dispositivo Bluetooth, presione y mantenga presionado el botón de reproducción/pausa para desconectarse de un dispositivo Bluetooth.

## AUX ENTRADA

- Presione y mantenga presionado el botón de encendido de Hype XL.
- Conecte su dispositivo al puerto AUX para cambiar automáticamente al modo AUX.

## REPRODUCCIÓN USB

- Encienda Hype XL.
- Conecte su dispositivo USB al puerto USB para cambiar automáticamente al modo USB.

## CARGA USB

- Conecte su smartphone, tablet u otro dispositivo al puerto USB usando un cable de carga.

## 5 CUSTOMIZE YOUR SOUND EXPERIENCE

Note: Press and hold the SOURCE button to switch between light modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## LIGHT MODES

- Press and hold the SOURCE button to switch between light modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## LINKING MULTIPLE SPEAKERS

- Turn on Bluetooth mode.
- Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## HANDS-FREE CALLING

- Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## VOICE ASSISTANT

- Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## 5 PERSONAL SU EXPERIENCIA DE SONIDO

Note: Press and hold the SOURCE button to switch between light modes. Bluetooth mode: Press and hold the SOURCE button to connect to a smartphone, press and hold the PLAY/PAUSE button to disconnect from the smartphone and return to the Bluetooth pairing mode.

## MODOS DE ILUMINACIÓN

- Presione y mantenga presionado el botón de fuente para conectarse a un dispositivo Bluetooth, presione y mantenga presionado el botón de reproducción/pausa para desconectarse de un dispositivo Bluetooth.

## VINCULACIÓN DE VARIOS ALTAVOCES

- Encienda Hype XL por modo Bluetooth.
- Presione y mantenga presionado el botón de fuente para conectarse a un dispositivo Bluetooth, presione y mantenga presionado el botón de reproducción/pausa para desconectarse de un dispositivo Bluetooth.

## LLAMADAS MANOS LIBRES

- Presione y mantenga presionado el botón de encendido de Hype XL.
- Conecte su dispositivo al puerto AUX para cambiar automáticamente al modo AUX.

## ASISTENTE DE VOZ

- Presione y mantenga presionado el botón de fuente para conectarse a un dispositivo Bluetooth, presione y mantenga presionado el botón de reproducción/pausa para desconectarse de un dispositivo Bluetooth.

## Important Safety Instructions (English)

- Read and keep these instructions, their warnings and follow instructions.
- Warning of application: Please refer to user information (e.g. manual) for application.
- Do not use the device in wet or damp conditions.
- Do not use the device in areas with high humidity or high temperature.
- Do not use the device in areas with high voltage or high current.
- Do not use the device in areas with high magnetic field.
- Do not use the device in areas with high electromagnetic interference.
- Do not use the device in areas with high radio frequency interference.
- Do not use the device in areas with high power density.
- Do not use the device in areas with high temperature.
- Do not use the device in areas with high humidity.
- Do not use the device in areas with high dust.
- Do not use the device in areas with high salt.
- Do not use the device in areas with high acid.
- Do not use the device in areas with high alkali.
- Do not use the device in areas with high oil.
- Do not use the device in areas with high grease.
- Do not use the device in areas with high dirt.
- Do not use the device in areas with high debris.
- Do not use the device in areas with high liquid.
- Do not use the device in areas with high gas.
- Do not use the device in areas with high smoke.
- Do not use the device in areas with high steam.
- Do not use the device in areas with high heat.
- Do not use the device in areas with high cold.
- Do not use the device in areas with high shock.
- Do not use the device in areas with high vibration.
- Do not use the device in areas with high pressure.
- Do not use the device in areas with high vacuum.
- Do not use the device in areas with high radiation.
- Do not use the device in areas with high noise.
- Do not use the device in areas with high light.
- Do not use the device in areas with high sound.
- Do not use the device in areas with high pressure.
- Do not use the device in areas with high vacuum.
- Do not use the device in areas with high radiation.
- Do not use the device in areas with high noise.
- Do not use the device in areas with high light.
- Do not use the device in areas with high sound.

## Instrucciones importantes de seguridad (Español)

- Lea y conserve estas instrucciones. Preste atención a las advertencias y siga todas las instrucciones.
- Advertencia de aplicación: Antes de utilizar el producto, consulte toda la información importante como la lista de advertencias, respuestas, etc. en el manual del usuario o el propietario.
- Evite utilizar el producto en áreas con alta humedad o alta temperatura.
- Evite utilizar el producto en áreas con alta tensión o alta corriente.
- Evite utilizar el producto en áreas con alto campo magnético.
- Evite utilizar el producto en áreas con alta interferencia electromagnética.
- Evite utilizar el producto en áreas con alta densidad de radiofrecuencia.
- Evite utilizar el producto en áreas con alta potencia.
- Evite utilizar el producto en áreas con alta temperatura.
- Evite utilizar el producto en áreas con alta humedad.
- Evite utilizar el producto en áreas con alta suciedad.
- Evite utilizar el producto en áreas con alta sal.
- Evite utilizar el producto en áreas con alta acidez.
- Evite utilizar el producto en áreas con alta alcalinidad.
- Evite utilizar el producto en áreas con alta grasa.
- Evite utilizar el producto en áreas con alta suciedad.
- Evite utilizar el producto en áreas con alta basura.
- Evite utilizar el producto en áreas con alta humedad.
- Evite utilizar el producto en áreas con alta gas.
- Evite utilizar el producto en áreas con alta humo.
- Evite utilizar el producto en áreas con alta calor.
- Evite utilizar el producto en áreas con alta frío.
- Evite utilizar el producto en áreas con alta choque.
- Evite utilizar el producto en áreas con alta vibración.
- Evite utilizar el producto en áreas con alta presión.
- Evite utilizar el producto en áreas con alta vacío.
- Evite utilizar el producto en áreas con alta radiación.
- Evite utilizar el producto en áreas con alta ruido.
- Evite utilizar el producto en áreas con alta luz.
- Evite utilizar el producto en áreas con alta sonido.
- Evite utilizar el producto en áreas con alta presión.
- Evite utilizar el producto en áreas con alta vacío.
- Evite utilizar el producto en áreas con alta radiación.
- Evite utilizar el producto en áreas con alta ruido.
- Evite utilizar el producto en áreas con alta luz.
- Evite utilizar el producto en áreas con alta sonido.

## NOTICE CONCERNING FCC REGULATIONS

The equipment generates noise and can radiate radio frequency energy. And it may interfere with other equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, which means that it can cause interference with other equipment. When using only shielded cables, the equipment will not cause interference with other equipment. When using unshielded cables, the equipment may cause interference with other equipment. If you experience interference, you may need to take the following steps: 1. Reorient the equipment. 2. Increase the distance between the equipment and the other equipment. 3. Use shielded cables. 4. Use a different power outlet. 5. Use a different power cord. 6. Use a different extension cord. 7. Use a different surge protector. 8. Use a different filter. 9. Use a different antenna. 10. Use a different cable. 11. Use a different connector. 12. Use a different adapter. 13. Use a different plug. 14. Use a different socket. 15. Use a different outlet. 16. Use a different circuit. 17. Use a different breaker. 18. Use a different fuse. 19. Use a different switch. 20. Use a different device. 21. Use a different component. 22. Use a different part. 23. Use a different accessory. 24. Use a different option. 25. Use a different feature. 26. Use a different function. 27. Use a different mode. 28. Use a different setting. 29. Use a different option. 30. Use a different feature. 31. Use a different function. 32. Use a different mode. 33. Use a different setting. 34. Use a different option. 35. Use a different feature. 36. Use a different function. 37. Use a different mode. 38. Use a different setting. 39. Use a different option. 40. Use a different feature. 41. Use a different function. 42. Use a different mode. 43. Use a different setting. 44. Use a different option. 45. Use a different feature. 46. Use a different function. 47. Use a different mode. 48. Use a different setting. 49. Use a different option. 50. Use a different feature. 51. Use a different function. 52. Use a different mode. 53. Use a different setting. 54. Use a different option. 55. Use a different feature. 56. Use a different function. 57. Use a different mode. 58. Use a different setting. 59. Use a different option. 60. Use a different feature. 61. Use a different function. 62. Use a different mode. 63. Use a different setting. 64. Use a different option. 65. Use a different feature. 66. Use a different function. 67. Use a different mode. 68. Use a different setting. 69. Use a different option. 70. Use a different feature. 71. Use a different function. 72. Use a different mode. 73. Use a different setting. 74. Use a different option. 75. Use a different feature. 76. Use a different function. 77. Use a different mode. 78. Use a different setting. 79. Use a different option. 80. Use a different feature. 81. Use a different function. 82. Use a different mode. 83. Use a different setting. 84. Use a different option. 85. Use a different feature. 86. Use a different function. 87. Use a different mode. 88. Use a different setting. 89. Use a different option. 90. Use a different feature. 91. Use a different function. 92. Use a different mode. 93. Use a different setting. 94. Use a different option. 95. Use a different feature. 96. Use a different function. 97. Use a different mode. 98. Use a different setting. 99. Use a different option. 100. Use a different feature. 101. Use a different function. 102. Use a different mode. 103. Use a different setting. 104. Use a different option. 105. Use a different feature. 106. Use a different function. 107. Use a different mode. 108. Use a different setting. 109. Use a different option. 110. Use a different feature. 111. Use a different function. 112. Use a different mode. 113. Use a different setting. 114. Use a different option. 115. Use a different feature. 116. Use a different function. 117. Use a different mode. 118. Use a different setting. 119. Use a different option. 120. Use a different feature. 121. Use a different function. 122. Use a different mode. 123. Use a different setting. 124. Use a different option. 125. Use a different feature. 126. Use a different function. 127. Use a different mode. 128. Use a different setting. 129. Use a different option. 130. Use a different feature. 131. Use a different function. 132. Use a different mode. 133. Use a different setting. 134. Use a different option. 135. Use a different feature. 136. Use a different function. 137. Use a different mode. 138. Use a different setting. 139. Use a different option. 140. Use a different feature. 141. Use a different function. 142. Use a different mode. 143. Use a different setting. 144. Use a different option. 145. Use a different feature. 146. Use a different function. 147. Use a different mode. 148. Use a different setting. 149. Use a different option. 150. Use a different feature. 151. Use a different function. 152. Use a different mode. 153. Use a different setting. 154. Use a different option. 155. Use a different feature. 156. Use a different function. 157. Use a different mode. 158. Use a different setting. 159. Use a different option. 160. Use a different feature. 161. Use a different function. 162. Use a different mode. 163. Use a different setting. 164. Use a different option. 165. Use a different feature. 166. Use a different function. 167. Use a different mode. 168. Use a different setting. 169. Use a different option. 170. Use a different feature. 171. Use a different function. 172. Use a different mode. 173. Use a different setting. 174. Use a different option. 175. Use a different feature. 176. Use a different function. 177. Use a different mode. 178. Use a different setting. 179. Use a different option. 180. Use a different feature. 181. Use a different function. 182. Use a different mode. 183. Use a different setting. 184. Use a different option. 185. Use a different feature. 186. Use a different function. 187. Use a different mode. 188. Use a different setting. 189. Use a different option. 190. Use a different feature. 191. Use a different function. 192. Use a different mode. 193. Use a different setting. 194. Use a different option. 195. Use a different feature. 196. Use a different function. 197. Use a different mode. 198. Use a different setting. 199. Use a different option. 200. Use a different feature. 201. Use a different function. 202. Use a different mode. 203. Use a different setting. 204. Use a different option. 205. Use a different feature. 206. Use a different function. 207. Use a different mode. 208. Use a different setting. 209. Use a different option. 210. Use a different feature. 211. Use a different function. 212. Use a different mode. 213. Use a different setting. 214. Use a different option. 215. Use a different feature. 216. Use a different function. 217. Use a different mode. 218. Use a different setting. 219. Use a different option. 220. Use a different feature. 221. Use a different function. 222. Use a different mode. 223. Use a different setting. 224. Use a different option. 225. Use a different feature. 226. Use a different function. 227. Use a different mode. 228. Use a different setting. 229. Use a different option. 230. Use a different feature. 231. Use a different function. 232. Use a different mode. 233. Use a different setting. 234. Use a different option. 235. Use a different feature. 236. Use a different function. 237. Use a different mode. 238. Use a different setting. 239. Use a different option. 240. Use a different feature. 241. Use a different function. 242. Use a different mode. 243. Use a different setting. 244. Use a different option. 245. Use a different feature. 246. Use a different function. 247. Use a different mode. 248. Use a different setting. 249. Use a different option. 250. Use a different feature. 251. Use a different function. 252. Use a different mode. 253. Use a different setting. 254. Use a different option. 255. Use a different feature. 256. Use a different function. 257. Use a different mode. 258. Use a different setting. 259. Use a different option. 260. Use a different feature. 261. Use a different function. 262. Use a different mode. 263. Use a different setting. 264. Use a different option. 265. Use a different feature. 266. Use a different function. 267. Use a different mode. 268. Use a different setting. 269. Use a different option. 270. Use a different feature. 271. Use a different function. 272. Use a different mode. 273. Use a different setting. 274. Use a different option. 275. Use a different feature. 276. Use a different function. 277. Use a different mode. 278. Use a different setting. 279. Use a different option. 280. Use a different feature. 281. Use a different function. 282. Use a different mode. 283. Use a different setting. 284. Use a different option. 285. Use a different feature. 286. Use a different function. 287. Use a different mode. 288. Use a different setting. 289. Use a different option. 290. Use a different feature. 291. Use a different function. 292. Use a different mode. 293. Use a different setting. 294. Use a different option. 295. Use a different feature. 296. Use a different function. 297. Use a different mode. 298. Use a different setting. 299. Use a different option. 300. Use a different feature. 301. Use a different function. 302. Use a different mode. 303. Use a different setting. 304. Use a different option. 305. Use a different feature. 306. Use a different function. 307. Use a different mode. 308. Use a different setting. 309. Use a different option. 310. Use a different feature. 311. Use a different function. 312. Use a different mode. 313. Use a different setting. 314. Use a different option. 315. Use a different feature. 316. Use a different function. 317. Use a different mode. 318. Use a different setting. 319. Use a different option. 320. Use a different feature. 321. Use a different function. 322. Use a different mode. 323. Use a different setting. 324. Use a different option. 325. Use a different feature. 326. Use a different function. 327. Use a different mode. 328. Use a different setting. 329. Use a different option. 330. Use a different feature. 331. Use a different function. 332. Use a different mode. 333. Use a different setting. 334. Use a different option. 335. Use a different feature. 336. Use a different function. 337. Use a different mode. 338. Use a different setting. 339. Use a different option. 340. Use a different feature. 341. Use a different function. 342. Use a different mode. 343. Use a different setting. 344. Use a different option. 345. Use a different feature. 346. Use a different function. 347. Use a different mode. 348. Use a different setting. 349. Use a different option. 350. Use a different feature. 351. Use a different function. 352. Use a different mode. 353. Use a different setting. 354. Use a different option. 355. Use a different feature. 356. Use a different function. 357. Use a different mode. 358. Use a different setting. 359. Use a different option. 360. Use a different feature. 361. Use a different function. 362. Use a different mode. 363. Use a different setting. 364. Use a different option. 365. Use a different feature. 366. Use a different function. 367. Use a different mode. 368. Use a different setting. 369. Use a different option. 370. Use a different feature. 371. Use a different function. 372. Use a different mode. 373. Use a different setting. 374. Use a different option. 375. Use a different feature. 376. Use a different function. 377. Use a different mode. 378. Use a different setting. 379. Use a different option. 380. Use a different feature. 381. Use a different function. 382. Use a different mode. 383. Use a different setting. 384. Use a different option. 385. Use a different feature. 386. Use a different function. 387. Use a different mode. 388. Use a different setting. 389. Use a different option. 390. Use a different feature. 391. Use a different function. 392. Use a different mode. 393. Use a different setting. 394. Use a different option. 395. Use a different feature. 396. Use a different function. 397. Use a different mode. 398. Use a different setting. 399. Use a different option. 400. Use a different feature. 401. Use a different function. 402. Use a different mode. 403. Use a different setting. 404. Use a different option. 405. Use a different feature. 406. Use a different function. 407. Use a different mode. 408. Use a different setting. 409. Use a different option. 410. Use a different feature. 411. Use a different function. 412. Use a different mode. 413. Use a different setting. 414. Use a different option. 415. Use a different feature. 416. Use a different function. 417. Use a different mode. 418. Use a different setting. 419. Use a different option. 420. Use a different feature. 421. Use a different function. 422. Use a different mode. 423. Use a different setting. 424. Use a different option. 425. Use a different feature. 426. Use a different function. 427. Use a different mode. 428. Use a different setting. 429. Use a different option. 430. Use a different feature. 431. Use a different function. 432. Use a different mode. 433. Use a different setting. 434. Use a different option. 435. Use a different feature. 436. Use a different function. 437. Use a different mode. 438. Use a different setting. 439. Use a different option. 440. Use a different feature. 441. Use a different function. 442. Use a different mode. 443. Use a different setting. 444. Use a different option. 445. Use a different feature. 446. Use a different function. 447. Use a different mode. 448. Use a different setting. 449. Use a different option. 450. Use a different feature. 451. Use a different function. 452. Use a different mode. 453. Use a different setting. 454. Use a different option. 455. Use a different feature. 456. Use a different function. 457. Use a different mode. 458. Use a different setting. 459. Use a different option. 460. Use a different feature. 461. Use a different function. 462. Use a different mode. 463. Use a different setting. 464. Use a different option. 465. Use a different feature. 466. Use a different function. 467. Use a different mode. 468. Use a different setting. 469. Use a different option. 470. Use a different feature. 471. Use a different function. 472. Use a different mode. 473. Use a different setting. 474. Use a different option. 475. Use a different feature. 476. Use a different function. 477. Use a different mode. 478. Use a different setting. 479. Use a different option. 480. Use a different feature. 481. Use a different function. 482. Use a different mode. 483. Use a different setting. 484. Use a different option. 485. Use a different feature. 486. Use a different function. 487. Use a different mode. 488. Use a different setting. 489. Use a different option. 490. Use a different feature. 491. Use a different function. 492. Use a different mode. 493. Use a different setting. 494. Use a different option. 495. Use a different feature. 496. Use a different function. 497. Use a different mode. 498. Use a different setting. 499. Use a different option. 500. Use a different feature. 501. Use a different function. 502. Use a different mode. 503. Use a different setting. 504. Use a different option. 505. Use a different feature. 506. Use a different function. 507. Use a different mode. 508. Use a different setting. 509. Use a different option. 510. Use a different feature. 511. Use a different function. 512. Use a different mode. 513. Use a different setting. 514. Use a different option. 515. Use a different feature. 516. Use a different function. 517. Use a different mode. 518. Use a different setting. 519. Use a different option. 520. Use a different feature. 521. Use a different function. 522. Use a different mode. 523. Use a different setting. 524. Use a different option. 525. Use a different feature. 526. Use a different function. 527. Use a different mode. 528. Use a different setting. 529. Use a different option. 530. Use a different feature. 531. Use a different function. 532. Use a different mode. 533. Use a different setting. 534. Use a different option. 535. Use a different feature. 536. Use a different function. 537. Use a different mode. 538. Use a different setting. 539. Use a different option. 540. Use a different feature. 541. Use a different function. 542. Use a different mode. 543. Use a different setting. 544. Use a different option. 545. Use a different feature. 546. Use a different function. 547. Use a different mode. 548. Use a different setting. 549. Use a different option. 550. Use a different feature. 551. Use a different function. 552. Use a different mode. 553. Use a different setting. 554. Use a different option. 555. Use a different feature. 556. Use a different function. 557. Use a different mode. 558. Use a different setting. 559. Use a different option. 560. Use a different feature. 561. Use a different function. 562. Use a different mode. 563. Use a different setting. 564. Use a different option. 565. Use a different feature. 566. Use a different function. 567. Use a different mode. 568. Use a different setting. 569. Use a different option. 570. Use a different feature. 571. Use a different function. 572. Use a different mode. 573. Use a different setting. 574. Use a different option. 575. Use a different feature. 576. Use a different function. 577. Use a different mode. 578. Use a different setting. 579. Use a different option. 580. Use a different feature. 581. Use a different function. 582. Use a different mode. 583. Use a different setting. 584. Use a different option. 585. Use a different feature. 586. Use a different function. 587. Use a different mode. 588. Use a different setting. 589. Use a different option. 590. Use a different feature. 591. Use a different function. 592. Use a different mode. 593. Use a different setting. 594. Use a different option. 595. Use a different feature. 596. Use a different function. 597. Use a different mode. 598. Use a different setting. 599. Use a different option. 600. Use a different feature. 601. Use a different function. 602. Use a different mode. 603. Use a different setting. 604. Use a different option. 605. Use a different feature. 606. Use a different function. 607. Use a different mode. 608. Use a different setting. 609. Use a different option. 610. Use a different feature. 611. Use a different function. 612. Use a different mode. 613. Use a different setting. 614. Use a different option. 615. Use a different feature. 616. Use a different function. 617. Use a different mode. 618. Use a different setting. 619. Use a different option. 620. Use a different feature. 621. Use a different function. 622. Use a different mode. 623. Use a different setting. 624. Use a different option. 625. Use a different feature. 626. Use a different function. 627. Use a different mode. 628. Use a different setting. 629. Use a different option. 630. Use a different feature. 631. Use a different function. 632. Use a different mode. 633. Use a different setting. 634. Use a different option. 635. Use a different feature. 636. Use a different function. 637. Use a different mode. 638. Use a different setting. 639. Use a different option. 640. Use a different feature. 641. Use a different function. 642. Use a different mode. 643. Use a different setting. 644. Use a different option. 645. Use a different feature. 646. Use a different function. 647. Use a different mode. 648. Use a different setting. 649. Use a different option. 650. Use a different feature. 651. Use a different function. 652. Use a different mode. 653. Use a different setting. 654. Use a different option. 655. Use a different feature. 656. Use a