


NOVA RC RITRO CHASE Manual

INSTRUCTIONS & BATTERY INSTALLATION:

car

Turn the car upside down.
Remove the battery cover using a Phillips screwdriver.
Unlatch the 2 locking tabs.
Insert 4 × 1.5V AA batteries.
Ensure batteries match the (+ / -) markings.
Reattach the battery cover with screw.

Bottom View



controller

Turn the controller upside down.
Remove the battery cover using a Phillips screwdriver.
Insert 2 × 1.5V AA batteries.
Match the (+ / -) markings.
Reattach the battery cover with the screw.

Bottom View



1

POWER ON

Turn the car ON by the switch located on the underside.
Turn the controller ON by the button located in center on the top.

2

CONTROLS

Left Control - Forward / Backward
Right Control - Turn Left / Right

3

READY FOR THE BIG HAUL

Place on flat surface and let 'em fly! Create your own exciting chase scenes.

IMPORTANT BATTERY WARNINGS:

- Use only fresh AA (1.5V) batteries.
- DO NOT mix old and new batteries.
- DO NOT mix alkaline, standard (carbon zinc), or rechargeable (nickel-cadmium) batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the unit before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the unit.
- The supply terminals are not to be short-circuited.
- Check that all contact surfaces are clean and bright before installing batteries.
- Remove batteries if the toy is not used for a long period of time.
- DO NOT immerse toy in water.
- DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.

Retain packaging for future reference; contains important information.

© 2026 LITTLE KIDS, INC.
1015 NEWMAN AVENUE,
SEEKONK, MA 02771

ALL RIGHTS RESERVED.

PRODUCT STYLES & COLORS MAY VARY.

MADE IN CHINA.

#802

 Little Kids®

www.littlekidsinc.com • 1-800-545-5437



FC



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.