

# nuwave®

## PIC® Flex

Precision Induction Cooktop

Master Your Pic Flex



Scan the code to find recipes,  
how-to videos and more!

Owner's Manual



### Questions or Concerns?

Customer Service: [support@nuwavenow.com](mailto:support@nuwavenow.com)

1-888-502-7805

Mon-Fri 7:30am-4:30pm CST

# THANK YOU!

Congratulations on your Nuwave® purchase. We know there are many options available and sincerely appreciate the trust you have placed in us.

For the last 30 years, we have committed to introducing products that promote healthy living at affordable prices. By combining the highest quality designs with cutting edge technology, we have always strived to blend feature, function, and innovation into every product we make. We hope you will agree.



## Register Today!

Use your smartphone or device to **scan the QR code** located on the back of your unit to register your product, or **visit [Nuwaren.com/register](https://www.nuwaren.com/register)**.

### Connect with Us!



#Nuwaren

Visit [Nuwaren.com](https://www.nuwaren.com) to see other great products and accessories.

# TABLE OF CONTENTS

<b>Recipe Book QR Code</b> .....	<b>3</b>
<b>Safeguards &amp; Information</b> .....	<b>4–6</b>
Electrical Information.....	5
FCC Information.....	6
<b>Parts &amp; Accessories</b> .....	<b>7</b>
<b>Primary Controls</b> .....	<b>8</b>
<b>PIC Flex Features</b> .....	<b>9</b>
<b>Cooking Functions</b> .....	<b>10–11</b>
<b>Care and Maintenance</b> .....	<b>12</b>
<b>Trouble Shooting Guide</b> .....	<b>13</b>
<b>Limited Warranty</b> .....	<b>14-15</b>

# SAFEGUARDS & INFORMATION

ALWAYS KEEP THIS MANUAL HANDY FOR FUTURE REFERENCE.

## IMPORTANT SAFEGUARDS

1. Read all instructions.
2. **DO NOT** touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord, plugs, or the unit, in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. **DO NOT** operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Any service for examination, repair, or adjustment, must be done by Nuwave LLC or authorized by manufacturer for repair.
7. The use of accessory attachments is not recommended by the appliance manufacturer may cause injuries.
8. **DO NOT** use outdoors.
9. **DO NOT** let cord hang over edge of table or counter, or touch hot surfaces.
10. **DO NOT** place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. **ALWAYS** attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
13. **DO NOT** use appliance for other than intended use.
14. Save these Instructions.

15. **DO NOT** cook on broken cook-top – if cook-top should break, cleaning solutions and spillovers may penetrate the broken cook-top and create a risk of electric shock.
16. Clean Cook-Top with Caution – If a wet sponge or cloth is used to wipe spills on a hot cooking area, be careful to avoid steam burn, some cleaners can produce noxious fumes if applied to a hot surface.

## ADDITIONAL SAFEGUARDS

17. For household use only.
18. **NEVER** use the cooktop in proximity of open fires or other heat sources, on flammable surfaces (e.g., tablecloth, carpet, etc.), close to any flammable materials, heating units, or in wet areas.
19. **NEVER** put the PIC against the wall or other appliances. There should be at least 3 inches of free space for the back, sides, and the top of the PIC.
20. Unplug the PIC from outlet when not in use and before cleaning. Allow the PIC to cool before cleaning or putting anything on the surface.
21. Place the cooktop on a stable, level, non-metallic surface.
22. **DO NOT** place devices or objects that are sensitive to magnetic fields on top of or next to the PIC, e.g., credit cards, cellphones, radios, TVs, etc.
23. Prior to connecting the PIC, confirm that the voltage needs indicated in this manual correspond to the voltage supply in your home. A wrong connection may lead to the PIC’s damage and possible injury to persons.
24. If a lot of smoke is escaping from the air vent during operation, unplug the PIC immediately and email Customer Service.

# SAFEGUARDS & INFORMATION

ALWAYS KEEP THIS MANUAL HANDY FOR FUTURE REFERENCE.



## CAUTION

In case of malfunction, immediately unplug the PIC and contact Nuwave's Customer Service Department.



## NOTICE

This appliance is intended for normal household use. It is not intended to be used in environments such as staff kitchens/cafeterias of shops, offices, farms, or other work environments, nor is it intended to be used by clients in hotels, motels, bed and breakfasts, and non-residential environments.

## Electrical Information

A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. If a longer detachable power-supply cord or extension cord is used:

1. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
2. The longer cord should be arranged so that it will not drape over the countertop or tabletop where it could be pulled on or tripped over unintentionally. The PIC should be operated on a separate electrical outlet from other operating appliances due to wattage limitations. The appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. **DO NOT** attempt to modify the plug in any way.

SEE CARE & MAINTENANCE BEFORE USE

THE FAILURE TO FOLLOW THESE SAFEGUARDS AND INSTRUCTIONS IS A MISUSE OF YOUR PIC THAT CAN VOID YOUR WARRANTY AND CREATE THE RISK OF SERIOUS INJURY.

# SAFEGUARDS & INFORMATION

## IMPORTANT - FCC Information:

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a consumer ISM equipment, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

The device complies with part 18 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

## WARNING

Electric shock hazard. Use with adequate electrical system. **DO NOT** use if cord or plug is damaged.

## WARNING

### For individuals with pacemakers:

1. This appliance emits an electromagnetic field that is strongest within two feet of the cooking surface.
2. Scientific tests have proven inconclusive as to whether the electrical field will disrupt the function of a pacemaker. Please consult your doctor or medical professional for guidance before use.


## WARNING

**DO NOT** place the unit on or near a hot gas burner, electric burner, or in a heated oven or on a stovetop.

## NOTICE


It is perfectly normal for your new unit to produce a heated plastic smell when used for the first time. This will go away after the first few uses.

# PARTS & ACCESSORIES



**PIC Flex**

Part #: 30537



**Display Panel**

Part #: 33005



**Feet**

Part #: PDA3

## Induction-Ready Cookware

Induction technology is based on a magnetic field distributing heat through ferrous (iron-based, magnetic) metal. Some cookware is made of naturally magnetic metals (such as pure iron), while others are rendered magnetic by “sandwiching” a thin layer of a ferrous metal within the base. Examples of compatible cookware include:

- All Nuwave Cookware, including Nuwave **Duralon® Blue Ceramic Non-Stick Cookware** and the **Pro-Smart™ Stainless Steel Cookware**.
- Enameled iron and steel
- Stainless-steel with a magnetic base

## Incompatible cookware includes:

- Copper
- Glass
- Aluminum
- Pottery-type vessels

## Checking Induction Compatibility


There are three simple ways to check if your existing pots and pans, or future cookware purchases, are compatible with the PIC Flex:

1. A magnet is typically a great indicator. If it sticks to the bottom of a piece of cookware, this typically means the pot or pan is induction ready. However, sometimes a cooking vessel’s magnetic properties are not strong enough to work efficiently with the PIC Flex.
2. Place a small amount of water in a pot or pan and place it on the PIC Flex while operating. If it is induction compatible, water will begin to boil.
3. An induction-ready symbol may be printed on the bottom of the cookware.



The Induction Ready symbol printed on most induction-compatible cookware.

# PRIMARY CONTROLS



Preset Temperatures			
Press Button	Temperature	Panel Display	Examples
LOW	100°F	100°F	Warm
MED LOW	175°F	175°F	Simmer
MED	275°F	275°F	Steam
MED HIGH	375°F	375°F	Stir/Deep-Fry
HIGH	425°F	425°F	Boil/Saute
MAX/SEAR	500°F	SEAR	Sear

The minimum is 100°F while the maximum temperature reaches 500°F.

**Easy Start**  
The PIC Flex™ is preset to cook on **SEAR** (500°F) for 1 hour. Turn it on, and you will see “SEAR” on the display, showing that the unit is on but the program is clear. Place an induction-ready pot on the PIC to begin cooking.

This default setting is adjustable before or during the cooking cycle. Press one of the preset temperature buttons (**LOW, MED LOW, MED, MED HIGH, HIGH, or MAX/SEAR**) or press **-** or **+** to decrease or increase the cooking temperature.

**⚠ CAUTION**

**While the PIC<sup>®</sup> Flex™ is in operation, do not touch the cooking surface as it may become very hot, leading to the risk of burns. The cooktop may retain residual heat after cookware has been removed.**



# PIC® FLEX FEATURES




- 1 Heat Source:** Electromagnetic coils located below the glass surface generate heat within the induction-ready cookware.
- 2 Surface:** The Nuwave PIC Flex's heat-resistant glass surface stays cool to the touch and cleans easily with the simple wipe of a damp cloth.
- 3 Control Panel with LED Display:** Easy-to-read control panel to operate the PIC.
- 4 Ventilation:** Air vents coupled with the internal fan underneath the unit allow any heat generated by the unit to escape, preventing heat transfer to the cooking surface and ensuring efficient performance.
- 5 Fan:** Located underneath the unit, allows any heat generated by the unit to escape.

## INDUCTION COOKING


The heating surface is located inside the thicker silver ring. The minimum diameter of acceptable cookware is 3 inches. Always place cookware in the center of the heating circle. You may use pans measuring up to the 10-inch width of the PIC Flex, but heat will transfer more slowly to the outer edges. Not recommended for pans larger than 10 inches.

# COOKING FUNCTIONS

## Getting Started


1. Press **START** to begin cooking at the default temperature 375°F for 1 hour. 
- Temperature and Time (see Setting Cooking Time below) can be adjusted by pressing - or +.


## Watts

 There are 3 wattages, 600W, 900W and the default wattage 1300 watts.

1. To change the wattage, press **WATTS** once. The light will illuminate above 600, indicating that the PIC Flex Plus is now set to 600 watts.
2. Continue pressing **WATTS** until your selection is reached.
3. Press **WATTS** once more and the light above 1300 will illuminate, indicating that the PIC Flex is now set to the default 1300 watts.

## Start

 The PIC Flex is preset to cook on **MED/HIGH** (375°F) for 1 hour.

1. Place an induction-ready pot on the PIC Flex.
2. Set the cooking temperature and time.
3. Press **START** to begin the cooking cycle.
4. When the cooking has finished, will beep three times and “0” will display.
- The PIC Flex will automatically stop cooking once time has expired, beep three times and display “0”.
- The display will always show the current cooking temperature.
- To display the remaining cook time, press **TIME** and a countdown will appear.
- The maximum cooking time is 99 hours and 60 minutes.

**Note:** “0” will appear on the control panel when the program is clear or the power is on with no set temperature. See Pause/Clear Function for more information.

## Setting Temperature



This appliance is preset to cook on Med/High (375°F).

1. Select the desired temperature on the control panel then press **START**. The temperature range will be displayed.
2. To raise or lower the temperature in 10-degree increments press + or -.

*Refer to Panel Display Chart on page 8 for preset temperatures.*

## °F to °C


The PIC Flex is set to default to Fahrenheit (°F).

Prog



1. To switch the display to Celsius (C), press **PROG**, followed by -. Press - again to convert to Celsius.
2. To return to Fahrenheit press - once more.
3. To exit from the F/C conversion option press **PAUSE/CLEAR** until “0” is displayed.

## Setting Cooking Time

 1. To change the time, press **TIME** and the last “0” on the right side will flash.

2. Press the + key until the desired time is reached.
3. Press the **TIME** button again to enter the next number
4. Repeat steps 2 and 3 until your desired time is set.

# COOKING FUNCTIONS

- The blinking “0” indicates the digit you can adjust. The maximum time is 99 hours and 60 minutes.
- The display shows hours and minutes, but not seconds.



## Pause/Clear Function

1. Press **Pause/Clear** once to pause the cooking process. This will pause the PIC regardless of cooking stage.
  2. Press **START** to resume cooking.
  3. Press **PAUSE/CLEAR** twice to clear the cooking mode and will display “0”.
- When paused, the temperature will remain and the “F” will be blinking.



## Program Function (Stage Cooking)

1. Press **PROG**.
  2. Pro will be displayed. Set the cooking temperature from **LOW** to **MAX/SEAR**.
  3. Press **TIME**. “00:00” will be displayed then press - or + until the desired time is reached. See Setting Cooking Time (page 10) for entering minutes and hours.
- To add additional stages, repeat steps 2 and 3 then press **START** to begin the program.
  - You may program up to 10 stages (delay is considered a stage).
  - Pressing **PAUSE/CLEAR** will clear all stages.



**Note:** Maximum programmable cook time is 99 hours and 60 minutes.

## Delay Function:

Delay lets you set programs to start at a later time.



1. To delay a program, press **PROG**.
  2. Press **TIME**. A “0” will flash in the display panel.
  3. Press **+** until the desired amount of time to delay the program start is reached. See Setting Cooking Time (page 10) for more.
  4. Press **PROG** again to set the cooking program. The amount of time selected for delay is included in the programmed stages.
- To continue to the next stage enter the cooking temperature. Continue with steps 2 and 3 from the programming Function (Stage Cooking).
  - 5. To begin the countdown press **START**. When delay countdown reaches “0” the PIC Flex will begin the cooking cycle.

**Example:** Boil for 5 minutes before reducing to a simmer for 20 minutes: Press **PROG**. Press **MAX/SEAR**. Press **TIME** once, and then press + until “00:05” is reached. Press **MED/LOW**. Press **TIME** twice, and then press + until “00:20” is reached. Finally, press **START**.

# CARE AND MAINTENANCE

## Cleaning the PIC® Flex™

Before first use, wipe the cooking surface with a cloth damp with warm, soapy water. Dry thoroughly before plugging the PIC Flex into any electrical outlet.



## General Cleaning Instructions

1. Unplug the PIC before cleaning and clean after each use.
2. Make sure the PIC has cooled completely prior to cleaning. Cleaning while the PIC is hot may cause burns and discolor the induction plate's glass finish.
3. The outer surface may be cleaned by wiping carefully with a damp dishcloth or sponge.
4. Remove the power plug prior to cleaning the Nuwave PIC. **DO NOT** use caustic cleaning agents and water should not penetrate the interior of the induction cooktop.
5. **NEVER** immerse the PIC plug in water or other liquids.
6. Wipe the glass surface with a damp cloth or use a mild, non-abrasive soap solution.
7. Wipe casing and operating panel with a damp soft cloth and mild detergent.
8. Remove any debris in the fan and vent using a dry dish brush.
9. **DO NOT** use oil-based cleansing products as their use may damage plastic parts or the casing/operating panel.
10. **DO NOT** use flammable, acidic or alkaline materials or substances near the PIC, as this may reduce the service life of the induction cooktop or pose a fire risk when induction cooktop is in use.
11. Ensure that the bottom of any cookware does not scrape the PIC's glass surface, although a scratched surface will not impair the use of the induction cooktop.
12. Store the PIC in a cool, dry place after properly cleaning.

## **WARNING**

### **Electric Shock Hazard**

**DO NOT** immerse the PIC® Flex™ in water or attempt to cycle it through dishwasher. The outer surface may be cleaned by wiping carefully with a damp dishcloth or sponge. Make sure the PIC has cooled completely prior to cleaning.

# TROUBLESHOOTING GUIDE

**Note:**

- Not all manufacturer cookware will be the same.
- If the PIC is not operating normally, turn off then turn on.
- Cookware is needed for the PIC to begin cooking. (If no cookware is set on the PIC when **START/PAUSE** is pressed , “E1” will display.)

**Error Message:** See table below for troubleshooting displayed error messages after cookware has been removed from the PIC.

Error Message:	Solution(s):
<b>E1</b>	A E1 reading typically means the PIC Flex does not detect cookware on its surface. This can occur for one of two reasons: 1. The induction coils contained within the PIC Flex will only work when they are in direct contact with a piece of cookware. To maintain your appliance’s effectiveness, always ensure that it rests on a flat surface and that contact is consistent with your cookware. 2. A E1 message may also occur if the chosen cookware is not induction-ready.
<b>E2</b>	The PIC is malfunctioning. Contact Customer Service*.
<b>E3</b>	The PIC’s voltage is too low. Minimum = 85 volts
<b>E4</b>	The PIC’s voltage is too high. Maximum = 144 volts
<b>E5</b>	The PIC is malfunctioning. Contact Customer Service.
<b>E6</b>	The PIC is malfunctioning. Contact Customer Service.
<b>E7</b>	Overheating, or air ventilation is obstructed, operation will cease, and the PIC will beep. Press <b>PAUSE/CLEAR</b> twice. Wait for the PIC to cool.
<b>E8</b>	Overheating the appliance will turn off. Contact Customer Service.
<b>E9</b>	The PIC is malfunctioning. Contact Customer Service.

After Removing Cookware:	Beep Sound:	Display:	Reference:
<b>Initial</b>	Single beep	“F” or “C” or “SEAR” or “.” Flashing	After returning the pot, Nuwave PIC Flex will automatically resume cooking.
<b>&lt; 10 seconds</b>	None	“F” or “C” or “SEAR” or “.” Flashing	
<b>11-70 seconds</b>	Yes	E1	Resume cooking by pressing <b>START</b> .
<b>After 70 seconds</b>	None	0	Cooking stops.

# LIMITED WARRANTY

## THE MANUFACTURER WARRANTS

Nuwave, LLC warrants that the Nuwave PIC® Flex (Precision Induction Cooktop) will be free from manufacturer defects for 1 year from the date of purchase, under normal household use, and when operated in accordance with the Manufacturer's written instructions. This Limited Warranty covers for the Original Purchaser only. The Manufacturer will provide the necessary parts and labor to repair the product at the Nuwave LLC Service Department. After the expiration of the warranty, the cost of the parts and labor will be the responsibility of the owner.

## THE WARRANTY DOES NOT COVER

The Limited Warranty is voided if repairs are made by an unauthorized dealer, or the serial number data plate is removed or defaced. Normal deterioration of finish due to use or exposure is not covered by this Warranty. This Limited Warranty does not cover failure, damages or inadequate performance due to accident, acts of God (such as lightning), fluctuations in electric power, alterations, abuse, misuse, misapplications, corrosive-type atmospheres, improper installation, failure to operate in accordance with the Manufacturer's written instructions, abnormal use, commercial or rental uses, or resold units. Nuwave LLC reserves the right to void the Limited Warranty, where allowable by law, for products purchased from an unauthorized dealer.

## TO OBTAIN SERVICE

The owner shall have the obligation and responsibility to pay for all services and parts not covered by the warranty; prepay the freight to and from Service Department for any part or system returned under this warranty; and carefully package the product using adequate padding material to prevent damage in transit. The original container is ideal for this purpose. Include in the package the owner's name, address, daytime telephone number, a detailed description of the problem, and RGA (Return Goods authorization number). Provide the product model & serial number and proof of date of purchase (a copy of the receipt) when making claims under this warranty. To obtain the RGA number, email us at: [support@nuwavenow.com](mailto:support@nuwavenow.com)

Provide the product, model, & serial number and proof of date of purchase (a copy of the receipt) when making claims under this warranty.

## MANUFACTURER'S OBLIGATION

The Manufacturer's obligation under this Limited Warranty is limited, to the extent allowable by law, to repairing or replacing any part covered by this Limited Warranty which upon examination is found to be defective under normal use. The Limited Warranty is applicable only within the continental United States and only to the original purchaser of the manufacturer's authorized channels of distribution.

**THE LIMITED WARRANTY MAY NOT BE ALTERED, VARIED OR EXTENDED EXCEPT BY A WRITTEN INSTRUMENT EXECUTED BY THE MANUFACTURER. THE REMEDY OF REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS LIMITED WARRANTY IS EXCLUSIVE. IN NO EVENT SHALL THE MANUFACTURER BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES TO ANY PERSON, WHETHER OR NOT OCCASIONED BY NEGLIGENCE OF THE MANUFACTURER, INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF USE, COSTS OF SUBSTITUTION, PROPERTY DAMAGE, OR OTHER MONEY LOSS.**

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation exclusions may not apply. This Limited Warranty gives specific legal rights, and there may also be other rights which vary from state to state. **EXCEPT AS OTHERWISE EXPRESSLY PROVIDED ABOVE, THE MANUFACTURER MAKES NO WARRANTIES EXPRESSED OR IMPLIED ARISING BY LAW OR OTHERWISE, INCLUDING WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE TO ANY OTHER PERSON. READ YOUR OWNER'S MANUAL. IF YOU STILL HAVE ANY QUESTIONS ABOUT OPERATION OR WARRANTY OF THE PRODUCT, PLEASE CONTACT NUWAVE LLC.**

## DISPUTE RESOLUTION PROCEDURE

For disputes relating to use of the website or use or purchase of a Nuwave product or service

# LIMITED WARRANTY

(collectively “Disputes”), you agree to first contact Nuwave LLC at [legal@nuwavenow.com](mailto:legal@nuwavenow.com). If we cannot resolve your dispute informally, any and all disputes shall be submitted to final and binding arbitration. You may start the arbitration process by submitting in writing a demand to the American Arbitration Association (“AAA”) and sending a copy to Nuwave. Nuwave will pay all filing costs. A single arbitrator of the AAA will conduct the arbitration in a location convenient to you or by phone. The arbitrator’s award will be binding and may be entered as a judgment in a court of competent jurisdiction. The arbitration will be conducted in accordance with the provisions of AAA’s Commercial Arbitration Rules and Mediation Procedures in effect at the time of submission of your demand for arbitration. See [https://www.adr.org/sites/default/files/CommercialRules\\_Web.pdf](https://www.adr.org/sites/default/files/CommercialRules_Web.pdf). Except as may be required by law as determined by an arbitrator, no party or arbitrator may disclose the existence, content, or results of any arbitration hereunder without prior written consent of both parties.

**A. WAIVER OF RIGHT TO SUE.** By agreeing to arbitration, you understand that, to the maximum extent permitted by law, you are agreeing to waive your right to file suit in any court, to a court hearing, a judge trial, or a jury trial.

**B. CLASS ACTION WAIVER.** To the maximum extent permitted by law, you expressly agree to refrain from bringing or joining any claims in any representative or class-wide capacity, including but not limited to, bringing or joining any claims in any class action or class-wide arbitration.

**C. OPT OUT PROCEDURE.** To request to opt out of arbitration you must contact Nuwave LLC at [legal@nuwavenow.com](mailto:legal@nuwavenow.com), Nuwave LLC, 560 Bunker Ct., Vernon Hills, IL 60061, U.S.A. You will have thirty (30) days from the date of product delivery to opt out of arbitration with respect to any dispute arising out of or relating to use or purchase of any Nuwave product. If more than 30 days have passed, you are not eligible to opt out of arbitration and will have waived your right to sue or participate in a class action with respect to the dispute arising out of your purchase or use of a Nuwave product. For any dispute arising out of your use of Nuwave’s website, you have thirty (30) days from the date you provided information to the website to opt out of arbitration. If more than 30 days have passed, you are not eligible to opt out of arbitration and you will have waived your right to sue and participate in a class action with respect to the dispute arising out of your use of Nuwave’s website.

**D. SOME MATTERS ARE NOT SUBJECT TO ARBITRATION.** Notwithstanding the foregoing, the following shall not be subject to arbitration and may be adjudicated only in the state and federal courts of Illinois: (i) any dispute, controversy, or claim relating to or contesting the validity of our intellectual property rights and proprietary rights, including without limitation, patents, trademarks, service marks, copyrights, or trade secrets; (ii) an action by a party for temporary, preliminary, or permanent injunctive relief, whether prohibitive or mandatory, or other provisional relief; or (iii) interactions with governmental and regulatory authorities. You expressly agree to refrain from bringing or joining any claims in any representative or class-wide capacity, including but not limited to, bringing or joining any claims in any class action or any class-wide arbitration.

## READ YOUR OWNER’S MANUAL

If you still have any questions about operation or warranty of the product, please contact Nuwave LLC. [support@nuwavenow.com](mailto:support@nuwavenow.com)

Para la versión en español de este manual,  
visita [www.nuwavenow.com](http://www.nuwavenow.com).



Scan the code to find recipes,  
how-to videos and more!

## Questions or Concerns?

Customer Service: [support@nuwavenow.com](mailto:support@nuwavenow.com)

1-888-502-7805

Mon-Fri 7:30am-4:30pm CST

### FOR HOUSEHOLD USE ONLY

120VAC / 60 Hz / 1300 Watts

For patent information please go to:

[www.nuwavenow.com/legal/patent](http://www.nuwavenow.com/legal/patent)

### Designed & Developed in USA

Nuwave LLC

560 Bunker Ct.

Vernon Hills, IL 60061, U.S.A.

Made in China

©2024 • All Rights Reserved.

Item No: BM30537

Rev.1-V9-YK

06-24-24