

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support

FORKLIFT MOBILE CRANE USER MANUAL

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.

VEVOR[®]

TOUGH TOOLS, HALF PRICE

Forklift Mobile Crane

Model: LXCCDB-6000BLD



Photo for reference

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

Technical Support and E-Warranty Certificate
www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTION AND PRECAUTIONS

⚠WARNING:

1. Comply with safety operating procedures: Before use, thoroughly understand the usage methods and safety precautions of the tool to prevent accidents.
2. When operating a Forklift Mobile crane, all national safety technical specifications related to the use and operation of the crane should be followed. To ensure safety and avoid damaging the equipment, please follow the following safety operating procedures.
3. It is not allowed to use a Forklift Mobile crane to transport personnel.
4. Do not lift loads above personnel. Do not pull or tow loads diagonally.
5. Overloading is not allowed for use.
6. Prevent the lifting hook from colliding with the limit switch during normal operation.
7. Other important operating tips: The load-lifting device must be hung on the trolley using a flexible connection method. Rigid connection methods can generate uncontrollable forces, ultimately leading to fatigue fracture.
8. When carrying heavy loads, do not pull the manual switch. When manually rotating the arm, only the hook can be pulled, and it is not allowed to pull the manual switch and cable.
9. The fasteners of the Forklift Mobile crane should be checked and tightened once every 6 months of use.

Maintenance

1. For safety and high-altitude operations, users are requested to specify a maintenance plan for the equipment based on their actual situation, and conduct inspections at least every six months or one year according to the following key tips.
2. When damaged components exceeding the specified values are found during inspection, they should be replaced.

Instruction

The forklift jib boom crane is built with sturdy steel material to give you the best service possible, making the whole structure as hard as it can be.

Large Bearing Force:The hoist crane is designed to take the stress off your machinery by supporting a weight capacity of up to 6000LBS.

Extra Hook:The forklift hook is not only made of sturdy material but has a safety latch and can rotate 360°without any limitation, making it is easy to operate.



Adjustable jib Boom:The boom length and lifting angle can be adjusted according to your needs.

Easy Installation:After simple assembly of the boom, attach it to your forklift, and finally secure the loads with the hook.

Widely Used:Suitable for automobile, aviation, machinery, electricity, delivery shipping, railway, and other industries for lifting and transportation.








Porous Design for Adjustment



POSITION LOAD-BEARING CAPACITY

Position	A	B	C	D	E
Capacity (lbs)	6000	4000	2000	1000	500



"WARNING: Read carefully and understand all ASSEMBLY AND OPERATION INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

GENERAL SAFETY RULES

- 1.Never overload.
- 2.This winch is designed for pulling, not for lifting!
3. Never put your hand or anything else near the gear, rim and rolling cable.Always wear gloves when using the winch
4. Never try to repair disassemble the winch when there is a problem.Ask a machinist or specialist for help.
- 5.Do not use the product when you are tired, while under the influence of alcohol, prescription medicines or drugs.
- 6.The safety precautions and instructions given in this manual are unable to cover in detail all the conditions and situations that may arise.
- 7.The operator and/or user must use common sense and caution when operating the product especially for any matters that are not referred in the above.
- 8.The use of any accessories, other than those recommended by the manufacturer or stated in the instructions manual, may result in injury or may cause damages.

Operation:

- 1.Keep the work area clean and free.Cluttered areas invite accidents.
- 2.Observe work area environment conditions
 - Do not expose the product to rain.
 - Do not use in damp or wet Locations.
 - Ensure that work area environment is kept well lit (sunlight or artificial lighting).
- 3.Dress properly
 - Do not wear loose clothing or jewelry that could be caught in moving parts.
 - Rubber gloves and non-skid footwear are recommended as well as a cap to contain long hair.
4. Do not use the product for purposes other than those for which it is intended.The product will do a better and safer job at its rated load if it is used for the purposes it was designed for.

5.The load is maximum when the lifting rod of the product is adjusted to the lowest;The load of the product decreases as the height of the lifting rod increases.

6. Keep a safe distance and keep children away

- Keep yourself and others at a safe distance from the work area,the product and the steel cable when it is pulling under load.
- Keep bystanders (esp. children) and animals away from the work area.
- Keep the product away from children or from their environment.





Never allow children to operate the product.Children should be supervised to ensure that they do not play with the product.

7.Do not damage the steel cable

- Never move the product by dragging it by the cable.
- Keep the cable away from heat and sharp edges.
- Do not step or roll over the product or steel cable.
- During operation, do not step over the product or the steel cable.

8.Safety at work

- Use proper protective equipment according to the work environment.
- Never pull loads greater than the maximal capacity of the product.

	Warning - To reduce the risk of injury, user must read instructions manual carefully.
	Warning- Be sure to wear gloves when using this product.
	Wear safety footwear
	Wear head protection

Manufacturer: Shanghaimuxinmuyeyouxiangongsi

Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.

Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREETEASTWOOD NSW 2122 Australia

Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

EC	REP
-----------	------------

E-CrossStu GmbH
Mainzer Landstr.69, 60329 Frankfurt am Main.

UK	REP
-----------	------------

YH CONSULTING LIMITED.
C/O YH Consulting Limited Office 147, Centurion House,
London Road, Staines-upon-Thames, Surrey, TW18 4AX

VEVOR®

TOUGH TOOLS, HALF PRICE

Technical Support and E-Warranty Certificate

www.vevor.com/support