

MODEL
GGSTF105TB

V 1.1 | 0526



User Manual

Tower Fan

SÖLT

Welcome

Congratulations on purchasing your new Tower Fan!
The Sôlt brand is proudly distributed within Australia by Residentia Group Pty Ltd.

Residentia Group

—
Head Office.
165 Barkly Ave
Burnley
Victoria 3121
Australia
—
ACN.
600 546 656
—
Online.
residentia.group

Please refer to the warranty card at the rear of this manual for information regarding your product's parts and labour warranty, or visit us online at www.residentia.group

At Residentia Group, we are customer obsessed and our Support Team are there to ensure you get the most out of your appliance. Should you want to learn more about your Tower Fan features, and importantly taking care of your appliance when cleaning, our Support Team are here to help.

You can use our online Support Centre at anytime by visiting <http://support.residentiagroup.com.au>, or you can contact us via calling us on 1300 11 HELP (4357).

Sôlt

—
Online.
www.solt.house
—
Instagram.
[/solt.house](https://www.instagram.com/solt.house)
—
Facebook.
[/solt.appliances](https://www.facebook.com/solt.appliances)

It is important that you read through the following use and care manual thoroughly to familiarise yourself with the installation and operation requirements of your appliance to ensure optimum performance.

Again, thank you for choosing an Sôlt appliance and we look forward to being of service to you.

Kind Regards,
The Residentia Team

Contents	2	Welcome
	4	General Instructions
	5	Your Tower Fan
	6	Assembly Instructions
	7	Operating Instructions
	8	Aromatherapy Option
	9	Maintenance and Cleaning
	10	Technical Specifications
	12	Purchase Details
	14	Warranty Information

Customer Care

Sôlt recommends the use of original spare parts. When contacting our customer service team, please ensure that you have the following information at hand (which can be found on your appliances' rating plate).

- Model Number
- Serial Number

General Instructions

CONDITIONS OF USE

- Indoor use only.
- This appliance is intended to be used in household and other residential type of environments only.

SAFETY INSTRUCTIONS

- Before using the appliance, carefully read the instructions in this manual.
- The manufacturer is not responsible if an incorrect installation and use causes injuries and damages.
- Always keep the instructions with your appliance for future reference.

WARNING: To prevent any damages to your and others' life or property, you have to follow the safety notes.

CHILDREN & VULNERABLE PEOPLE SAFETY

WARNING: Risk of suffocation, injury or permanent disability.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children.
- The remote control contains batteries. Keep batteries away from children. Swallowing batteries may result in serious injury or death.

INSTRUCTIONS FOR SAFE OPERATION

- Do not use the appliance unless fully assembled with the base securely attached.
- Do not place the fan on uneven surfaces, carpet edges, bedding or unstable flooring where the appliance may tip over.
- This appliance must be used in accordance with Australian household electrical safety expectations.
- Never insert fingers, pencils, or any other foreign object through the grille when fan is running.
- Disconnect fan when moving from one location to another.
- Be sure fan is on a stable surface when operating to avoid overturning.
- Do not use outdoors, in bathrooms, near open windows during rain, or in damp environments.
- Never insert objects into air outlets.
- Disconnect before cleaning, moving or storage.
- Do not operate with a damaged cord or plug.
- Place on a stable, level surface.
- Do not use with external speed controllers or timers unless supplied with the product.
- Essential oils and fragrances may damage plastic components over time. Only use small amounts on the supplied fragrance pad.
- Do not use heated oils, diffuser oils, or alcohol-based fragrances

INSTALLATION

- Remove all the packaging.
- Do not assemble or use a damaged appliance.
- Keep packaging away from children and dispose of electrical products through local e-waste collection facilities.

ELECTRICAL CONNECTION

WARNING: Caution, risk of fire and electrical shock!

- DO NOT use the fan near a window, rain may create electrical hazard.
- Operate from a 220–240V~, 50–60Hz power supply.
- If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- To ensure your safety, power plug must be inserted into an earthed three-pole socket. Check carefully and make sure that your socket is properly and reliably earthed.
- To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.

MAINTENANCE & CLEANING

WARNING: Risk of injury or damage to the unit.

- Prior cleaning unplug the fan.
- Do not disassemble or open the rotor guard to clean the rotor blades.
- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
- Clean the appliance with a moist soft cloth. Only use mild soaps and thoroughly remove soap film with a dry cloth.
- Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- Do not use gasoline, thinner or similar products as a cleaner.
- Do not allow water or any other liquid into the motor housing or interior parts.

WARNING

Only authorised technicians can carry out repairs.

Note: Your appliance requires little maintenance. If you are experiencing issues, do not try to resolve the issue or fault by yourself. If you appliance requires maintenance:

- Power off the appliance using the Power button.
- Switch off the appliance at the power outlet and remove the plug.
- Contact our customer service team.

PRODUCT DISPOSAL

- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.
- Dispose of used batteries at a safe disposal drop off.


Your Tower Fan

PRODUCT OVERVIEW

1. Control Panel
2. Remote Receiver
3. Tower Fan Body
4. Aromatherapy Compartment (Rear)
5. Base Assembly

Included by not shown:

- Remote Control
- Power Cord



Note: The images in this user manual are for explanatory purposes only.
Your Tower Fan may appear slightly different.


Assembly Instructions

STEP 1

Take out the Tower Fan Body and the Base assembly parts from the box.

STEP 2

Join the base halves and secure with the 2 base clamps and the supplied screws



STEP 3

Fix the Tower Fan Body on the Base and check that the fan is upright and stable before connecting power.

IMPORTANT: During first use, you may notice a slight odour for a short period. This is normal and may occur as manufacturing residues dissipate during initial operation. The odour will reduce and disappear with continued use.

Operating Instructions

CONTROL PANEL

The buttons on the Control Panel body (On/Off, Speed, Mode, Swing, Timer) are the same functions as the corresponding buttons on the Remote Control.



1. **LED Display Screen:** Here is where temperature, timer and mode settings will be displayed.
2. **Speed:** Choose between Low (F1), Medium (F2) and High (F3) fan speeds.
3. **Mode:** Press this button to choose between Normal/Natural (AL) and Sleep (SP) wind modes.
Normal (AL): The wind remains a constant flow.
Natural (AL): Variable wind patterns that simulates the wind outdoors.
Sleep (SP): A low, constant wind speed ideal for a cool, long night's sleep.
4. **On/Off:** This button will power the Tower Fan on and off.
5. **Swing (Oscillation):** After the Tower Fan is powered on, press the Swing button to select oscillation mode.
6. **Timer:** Press the Timer Button to program the Fan to power off automatically between 1–24hrs.

Display Auto-Off: If no buttons are pressed for 5 minutes, the display screen will automatically turn off. Press any button to wake the display back up.

REMOTE CONTROL

Operating the Remote Control

- Point the Remote Control at the receiver on the Tower Fan body and press the desired function button.
- The batteries must be removed from the Remote Control before it is scrapped and that they are disposed of safely.

Note: Only use 2×AAA manganese or alkaline batteries.



- **On/Off:** This button will power the Tower Fan on and off.
- **Speed:** Choose between Low (F1), Medium (F2) and High (F3) fan speeds.
- **Mode:** Press this button to choose between Normal/ Natural (AL) and Sleep (SP) wind modes.
- **Swing (Oscillation):** After the Tower Fan is powered on, press the Swing button to select oscillation mode.
- **Timer:** Press the Timer Button to program the Fan to power off automatically between 1–24hrs.
- **Status:** Change the temperature, timer and mode settings.

BATTERY WARNING

- Do not dispose of batteries in fire. Batteries may explode or leak.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

Note:

The images in this user manual are for explanatory purposes only. Your Tower Fan and Remote Control may appear slightly different.

Aromatherapy Option

Your Sôlt tower fan includes an integrated aromatherapy compartment and with a fragrance pad designed to gently distribute fragrance into the airflow during operation.

Adding fragrance can help create a more comfortable and personalised indoor environment while circulating air throughout the room. Depending on the fragrance selected, you may choose to create a fresher atmosphere for everyday use or a more relaxing environment for reading, winding down in the evening, or general home comfort.

To use the aromatherapy function:

1. Power the fan OFF and disconnect from the power outlet.
2. Open the aromatherapy compartment at the rear.
3. Apply 2–5 drops of your preferred water-based or fan-suitable fragrance onto the supplied fragrance pad.
4. Reinsert the fragrance pad securely into the compartment.
5. Operate the fan normally.

As air passes through the fan, a light fragrance may be dispersed into the surrounding area.


For best performance

- Begin with a small amount of fragrance and increase only if required.
- Stronger airflow settings may increase fragrance distribution.
- Replace or refresh the fragrance pad periodically to maintain performance.
- Store fragrance products separately from the appliance.

IMPORTANT

- Use fragrance on the supplied pad only.
- Do not pour liquids directly into the fan housing or air outlet.
- Do not saturate the pad excessively, as excess liquid may affect surrounding components.
- Do not use oils, liquids or products that are flammable, corrosive or produce residue.
- If fragrance causes discomfort, switch off the appliance and remove the pad before continued use.

Note: Fragrance performance can vary depending on room size, airflow setting and fragrance concentration. This function is intended to provide light ambient scenting and is not designed as a dedicated aroma diffuser.



Maintenance and Cleaning

MAINTENANCE AND SERVICE

- This appliance is designed with no user-serviceable parts and requires minimal upkeep.
- Do not attempt to perform repairs yourself. Contact qualified service professionals for any required maintenance.
- The fan is permanently lubricated and does not need any additional lubrication for its entire lifespan.

CLEANING INSTRUCTIONS

- Always turn the fan off and unplug it from the electrical outlet before cleaning.
- Use a lint-free cloth to remove any excess dust from the surfaces.
- To maintain proper air circulation to the motor, ensure the vents at the back of the motor housing are clear of dust build-up. These vents can be cleaned using a vacuum cleaner hose attachment.
- Do not immerse the fan in water or any other liquid.

STORAGE GUIDELINES

- Before storing the fan, ensure it is completely disassembled and cleaned.
- Save the original packaging to store the fan.
- Always keep the fan in a dry location.
- Never store the fan while it is plugged in.
- Do not wrap the cord tightly around the fan. Avoid putting any stress on the cord where it connects to the fan housing, as this can cause the cord to fray and break.

DISPOSAL

- This product must not be disposed of via normal household waste after its service life, but must be taken to a collection station for the recycling of electrical and electronic devices. The symbol on the product, the operating instructions or the packaging indicate such disposal procedures. The materials are recyclable in accordance with their respective symbols. By means of re-use, material recycling or any other form of recycling old appliances you are making an important contribution to the protection of our environment. Please ask your local council where your nearest disposal station is located.



Technical Specifications

Below outlines the technical specifications for your Tower Fan.

Model	GGSTF105TB
Dimensions (W × D × H mm)	300 × 300 × 1013 mm
Net Weight	3.7kg
Rated Power	45W
Power Supply	220-240V~, 50Hz



**This page
is intentionally
left blank**

Purchase Details

For future reference, please record the following information which can be found on the rating plate and the date of purchase which can be found on your sales invoice.

STORE DETAILS

STORE NAME	
ADDRESS	
TELEPHONE	
PURCHASE DATE	

PRODUCT DETAILS

MODEL NO.	
SERIAL NO.*	



**Attach your receipt
to this page**



Warranty Information

WARRANTY TERMS & CONDITIONS TOWER FAN

This document sets out the terms and conditions of the product warranties for Residentia Group Appliances. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should you require service for your Appliance.

1. **IN THIS WARRANTY**
 - (a) 'acceptable quality' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL;
 - (b) 'ACL' means Trade Practices Amendment (Australian Consumer Law) Act (No.2) 2010;
 - (c) 'Appliance' means any Residentia Group product purchased by you accompanied by this document;
 - (d) 'ASR' means Residentia Group authorised service representative;
 - (e) 'Residentia Group' means Residentia Group Pty Ltd of 165 Barkly Ave, Burnley VIC 3121, ACN 600 546 656 in respect of Appliances purchased in Australia;
 - (f) 'major failure' as referred to in clause 10 of this warranty has the same meaning referred to in the ACL and includes a situation when an Appliance cannot be repaired or it is uneconomic for Residentia Group, at its discretion, to repair an Appliance during the Warranty Period;
 - (g) 'Warranty Period' means:
 - (i) where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual, the Appliance is warranted against manufacturing defects for 24 months, following the date of original purchase of the Appliance;
 - (h) 'you' means the purchaser of the Appliance not having purchased the Appliance for re-sale, and 'your' has a corresponding meaning.
2. This warranty only applies to Appliances purchased and used in Australia and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia.
3. During the Warranty Period Residentia Group or its ASR will, at no extra charge if your Appliance is readily accessible for service, without special equipment and subject to these terms and conditions, repair or replace any parts which it considers to be defective. Residentia Group or its ASR may use remanufactured parts to repair your Appliance. You agree that any replaced Appliances or parts become the property of Residentia Group. This warranty does not apply to light globes, batteries, filters or similar perishable parts.
4. Parts and Appliances not supplied by Residentia Group are not covered by this warranty.

5. You will bear the cost of transportation, travel and delivery of the Appliance to and from Residentia Group or its ASR. If you reside outside of the service area, you will bear the cost of:
 - (a) travel of an authorised representative;
 - (b) transportation and delivery of the Appliance to and from Residentia Group or its ASR, in all instances, unless the Appliance is transported by Residentia Group or its ASR, the Appliance is transported at the owner's cost and risk while in transit to and from Residentia Group or its ASR.
6. Proof of purchase is required before you can make a claim under this warranty.
7. You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. Residentia Group is not liable in the following situations (which are not exhaustive):
 - (a) the Appliance is damaged by:
 - (i) accident
 - (ii) misuse or abuse, including failure to properly maintain or service
 - (iii) normal wear and tear
 - (iv) power surges, electrical storm damage or incorrect power supply
 - (v) incomplete or improper installation
 - (vi) incorrect, improper or inappropriate operation
 - (vii) insect or vermin infestation
 - (viii) failure to comply with any additional instructions supplied with the Appliance;
 - (b) the Appliance is modified without authority from Residentia Group in writing;
 - (c) the Appliance's serial number or warranty seal has been removed or defaced;
 - (d) the Appliance was serviced or repaired by anyone other than Residentia Group, an authorised repairer or ASR.
8. This warranty, the contract to which it relates and the relationship between you and Residentia Group are governed by the law applicable where the Appliance was purchased.
9. To the extent permitted by law, Residentia Group excludes all warranties and liabilities (other than as contained in this document) including liability for any loss or damage whether direct or indirect arising from your purchase, use or non use of the Appliance.
10. For Appliances and services provided by Residentia Group in Australia, the Appliances come with a guarantee by Residentia Group that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. The benefits to you given by this warranty are in addition to your other rights and remedies under a law in relation to the Appliances or services to which the warranty relates.
11. At all times during the Warranty Period, Residentia Group shall, at its discretion, determine whether repair, replacement or refund will apply if an Appliance has a valid warranty claim applicable to it.
12. Missing parts are not covered by warranty. Residentia Group reserves the right to assess each request for missing parts in a case by case basis. Any parts that are not reported missing in the first week after purchase will not provide free of charge.
13. To enquire about claiming under this warranty, please follow these steps:
 - (a) carefully check the operating instructions, user manual and the terms of this warranty;
 - (b) have the model and serial number of the Appliance available;
 - (c) have the proof of purchase (e.g. an invoice) available;
 - (d) telephone the numbers shown below.
14. You accept that if you make a warranty claim, Residentia Group and its ASR may exchange information in relation to you to enable Residentia Group to meet its obligations under this warranty.

IMPORTANT

Before calling for service, please ensure that the steps in point 13 have been followed.

Telephone contacts

- Service: Please call 1300 11 HELP (4357)
- Spare Parts: Please call 1300 11 SPARE (7727)

The Australian Consumer Law requires the inclusion of the following statement with this warranty:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**An initiative by
Residentia Group**



**T. 1300 11 4357
E. support@residentiagroup.com.au**

www.solt.house



E2447

SÔLT