

***acer***

**OHR655**

**True Wireless Earbuds**

**FCC ID:2A2P5-OHR655**

**User Manual**

Please read this user manual carefully when using this product.

## Preface

Thank you for purchasing Acer products. For optimum operation, please read this manual carefully before using.

## Model

OHR655

## Item Name

True Wireless Earbuds

## Package Contents

Headset x2

Charging Chamber x1

USB Charging Cable x1

User Manual x1

## Product Description

This V earphone is a wireless connectivity-enabled audio product, which is compatible with Android and iOS smartphones, tablets, and other portable electronic devices. By eliminating the constraints of wired connections, it offers users enhanced convenience and unrestricted mobility, catering to a wide range of application scenarios.

## Product Specifications

Material:ABS

Product Weight:31.4g

Charging port:Type-C

Earphones Size: 31\*15\*24mm

Charging case size:57.1\*52.2\*28.1mm

## Product structure diagram

---



- 1.Charging case indicator light
- 2.Function Key(Touch)
- 3.Charging compartment inner tray
- 4.Charging port

**Tips:**

Gently insert the earbuds into your ear canal, then adjust them after placement to achieve a comfortable wearing angle.

**Wireless headphone parameters:**

1. Bluetooth Version: V 6.0
2. Connection: Bluetooth
3. Communication distance: Approximately 10 meters (in an open and unobstructed environment).
4. Talk time: About 4 hours.
5. Music playback time: About 5 hours (at medium volume).
6. Frequency response range: 20Hz - 10KHz.
7. Product material: ABS.
8. Wearing style: In-ear.

**Operation Instructions:**

1. Wireless connection: On Android/iOS platforms, search and pair in the Bluetooth settings page of your mobile phone.
2. After placing the earbuds in the charging case, they will automatically power off. The indicator light on the charging case will illuminate. When the earbuds are fully charged, the indicator light will turn off.

**Multifunction key:****1. Power On/Off**

Power on: Open the charging case, or long press either earbud' s touch key for 3 seconds.

Power off: Place in the charging case, or long press either earbud' s touch key for 5 seconds.

**2. Music Control**

Play/Pause: Double tap either earbud' s touch key.

Previous track: Triple tap the left earbud' s touch key.

Next track: Triple tap the right earbud' s touch key.

**3. Volume Adjustment**

Volume down: Single tap the left earbud' s touch key.

Volume up: Single tap the right earbud' s touch key.

**4. Call Functions**

Answer/End call: Double tap either earbud' s touch key.

Reject call: Long press either earbud' s touch key for 2 seconds.

**5. Extra Functions**

Voice Assistant: Long press either earbud' s touch key for 2 seconds and release.

Game/Sleep Mode: Quadruple tap either earbud' s touch key to switch modes.

**Note: This product can be connected and used with any device equipped with Wireless functionality.**

# Safety guidelines

---

1. Before using this product for the first time, please fully charge it before using it.
2. The product is not a toy, and children under the age of 12 must be used under the supervision of an adult.
3. Please use a 5V/0.23A charger that has passed the safety certification of a regular manufacturer to avoid damage to the product caused by a fast charging charger that supports high voltage
4. Please charge in a safe surroundings, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid damage to the battery caused by long-term charging. The charging method of the charging case is the Type-C interface.
5. This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the earbuds will lead to a decrease in battery performance over time, which malformation nonchargeable batteries.
6. This product comes with a healthy battery, if it has not been used for a long time, please charge it at least once a month.
7. If you feel skin discomfort when wearing it due to individual differences, please stop wearing it and consult a doctor.
8. When using this product with Wireless connection, please adjust the sound of the earphones to an appropriate volume to avoid hearing damage caused by long-term loud volume.
9. If you use this product while engaging in activities that require concentration, you should pay attention to your own safety and the safety of others, such as when driving or cycling, on roads, construction sites, railways, or walking. You should remove your headphones or adjust the volume to ensure that you can hear the sounds around you, including alarms and warning signals.
10. please follow the relevant regulations of your region or country and use this product as required when driving.
11. This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using or placing the product.
12. it is recommended to use this product in an surroundings with a temperature of  $-0^{\circ}\text{C}$ – $45^{\circ}\text{C}$  When the ambient temperature is below  $+5^{\circ}\text{C}$ , battery performance is limited.
13. Do not use this product in places where it is expressly prohibited to use wireless equipment otherwise it will interfere with other electronic equipment or cause other dangers.
14. Before approaching medical or industrial equipment or boarding a plane, please ask the local staff if they can use it.
15. Before cleaning and maintaining this product, stop using this product, turn off application, and disconnect all connections or cables to other equipment.
16. Please dispose of waste electronic products properly in accordance with local laws and regulations, and do not dispose of electrical and electronic equipment, parts, batteries and other household waste.
17. The power delivered by the charger must be between min 5 Watts required by the radio equipment, and max 10 Watts in order to achieve the maximum charging speed.
18. Regarding the rechargeable headphones, please use our company's standard USB cable or the designated charging cable to charge the headphones.
19. To ensure the normal operation of the headphones, please make sure the headphones have sufficient power.
20. Please use a charger with the specification of 5V 0.23A.

# Warning

---

- Do not use abrasive cleaners to clean this product.
- Do not allow this product to be heated or close to a fire source, such as a cooking stove.
- Do not expose the product to direct sunlight for a long time.
- Do not discard this product in fire to avoid explosion.
- Do not attempt to disassemble this product to make any modifications, as it does not contain any maintenance components.
- Do not use this product in rain.
- If you do not plan to use this product for a long time, please store it in a dry surroundings and Charge the headset less once to prolong its life and avoid extreme temperature and dust.
- Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of time.
- Batteries may explode if not handled properly.
- Do not disassemble or dispose of batteries in fire.
- Do not short external contacts, crush, puncture or otherwise tamper with batteries.
- Follow local regulations when disposing of used batteries.
- The power delivered by the charger must be between min [5] Watts required by the radio equipment, and max[10] Watts in order to achieve the maximum charging speed.



## FCC Warning

---

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause unintended operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

## CE Declaration of Conformity

Hereby, Acer Gadget Inc. declares in compliance with the essential requirements and the other relevant provisions of the Radio Equipment Directive 2014/53/EU and RoHS Directive 2011/65/EU.

## Disposal of Waste Equipment by Users in Private Households in the European Union

This symbol on the product or its packaging indicates that this product must not be disposed of with other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the store or the shop where you purchased the product.



## **After-sales Customer Service Number :**

- |                        |                       |
|------------------------|-----------------------|
| 1. (978)230-8895(US)   | Mon-Fri: 9am-6pm(EST) |
| 2.+0211 4187 3343(DE)  | Mon-Fri:9am-5pm       |
| 3.+0203868 3233(UK)    | Mon-Fri:9am-6pm(GMT)  |
| 4.+81090-9873-0969(日本) | 月-金:午前9時-午後6時         |
| 5.+61 451 8926 82(AU)  | Mon-Fri:9am-6pm       |

**For any product-related issues or concerns, please reach out to our after-sales service team at the following email address:**

- 1.For Temu and other purchases**  
**shopify@newease.cc**
- 2.For Amazon purchases**  
**NE\_hub.service@acergadget.com**