

BOSE

LIFESTYLE ULTRA SUBWOOFER

Please read and keep all safety and use instructions.

Declarations of conformity can be found at: www.Bose.com/compliance

CE Bose Corporation hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other applicable EU directive requirements.

Important Safety Instructions

Do not use this apparatus near water.

Clean only with a dry cloth.

Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.

Only use attachments/accessories specified by the manufacturer.

Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



This symbol on the product means there is uninsulated, dangerous voltage within the product enclosure that may present a risk of electrical shock.



This symbol on the product means there are important operating and maintenance instructions in this guide.



This product contains a tempered glass surface. Use caution to avoid impact. In the event of breakage, use care in handling broken glass.



This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.

- Safe Installation Instructions: Ensure feet under product are clean and free of debris. Place the product on a clean, dust-free, stable, flat, and level surface. For proper support, all feet must be in full contact with surface. Beware of potential fall hazards as audio vibrations can cause the product to move. Do not position above seating or occupied areas.
- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, dripping, splashing, or moisture and do not place liquid filled objects such as vases, on or near the product.
- Keep the product away from fire and heat sources. Do NOT place naked flame sources, such as lighted candles, on or near the product.
- Do NOT make unauthorized alterations to this product.
- Do NOT use a power inverter with this product.
- Do NOT use in vehicles or boats.
- Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



仅适用于海拔 2000m 以下地区安全使用
Use at altitude less than 2000 meters only.

- Due to ventilation requirements, Bose does not recommend placing the product in a confined space such as in a wall cavity or in an enclosed cabinet.
- Do not place or install near any heat sources, such as fireplaces, radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- The product label is located on the bottom of the product.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Bose Corporation could void the user's authority to operate this equipment.

This device complies with part 15 of the FCC Rules and with ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with FCC and ISED Canada radiation exposure limits set forth for general population. This equipment should be installed and operated with a minimum distance of 20 cm between radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device for operation in the 5150 - 5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Receiver Category = 2

CAN ICES (B) / NMB (B)

Low-power Radio-frequency Devices Technical Regulations: Without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to a approved low power radio-frequency devices. The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user shall cease operating immediately until no interference is achieved. The said legal communications means radio communications is operated in compliance with the Telecommunications Management Act. The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave radiated devices.

FCC regulations restrict the operation of this device to indoor use only.

This device is prohibited from being operated on oil platforms, cars, trains, boats, and aircraft, except it can be operated in large aircraft while flying above 10,000 feet in the 5.925-6.425 GHz band.


Transmitters in the 5.925-7.125 GHz band are prohibited from operating to control or communicate with unmanned aircraft systems.

FCC ID: A94443537


For Europe: Frequency bands of operation 2400 to 2483.5 MHz and 5470 to 5725 MHz. Maximum transmit power less than 20 dBm EIRP. | Frequency band of operation 5725 to 5850 MHz. Maximum transmit power less than 14 dBm (25mW) EIRP. | Frequency bands of operation 5150 to 5250 MHz and 5945 to 6425 MHz. Maximum transmit power less than 23 dBm EIRP.

Maximum transmit power is below regulatory limits such that SAR testing is not necessary and exempt per applicable regulations.

This device is restricted to indoor use when operating in the 5150 to 5350 MHz frequency range in all EU Member States listed in the table.

									
AT	BE	BG	HR	CY	CZ	DK	EE	FI	FR
DE	EL	HU	UK (NI)	IT	LV	LT	LU	MT	NL
PL	PT	RO	SK	SI	ES	SE	CH	IS	LI
NO									


UK

 This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Power State Information: The product, in accordance with the Ecodesign Requirements for Energy Related Products Directive 2009/125/EC and the Ecodesign for Energy-Related Products and Energy Information (Amendment) (EU Exit) Regulations 2020, is in compliance with Commission Regulation (EU) 2023/826. For information about power consumption for different standby modes and the period after which the product automatically reverts to those modes, visit www.Bose.com/compliance and select this regulation.


NOTE: Per Annex III 2(d) of Commission Regulation (EU) 2023/826, the requirement to deactivate a wireless port “does not apply to equipment that relies on a single wireless network connection for intended use and have no wired network connection.”

Names and Contents of Toxic or Hazardous Substances or Elements										
Toxic or Hazardous Substances and Elements										
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (CR(VI))	Polybrominated Biphenyl (PBB)	Polybrominated diphenylether (PBDE)	Dybutyl phthalate (DBP)	Diisobutyl phthalate (DIBP)	Butyl benzyl phthalate (BBP)	Bis(2-ethylhexyl) phthalate (DEHP)
PCBs	X	O	O	O	O	O	O	O	O	O
Metal Parts	X	O	O	O	O	O	O	O	O	O
Plastic Parts	O	O	O	O	O	O	O	O	O	O
Speakers	X	O	O	O	O	O	O	O	O	O
Cables	X	O	O	O	O	O	O	O	O	O

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572.

X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572.





Unit	Restricted substances and its chemical symbols					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr ⁺⁶)	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
PCBs	-	o	o	o	o	o
Metal Parts	-	o	o	o	o	o
Plastic Parts	o	o	o	o	o	o
Speakers	-	o	o	o	o	o
Cables	-	o	o	o	o	o

Note 1: "o" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

Note 2: The "-" indicates that the restricted substance corresponds to the exemption.

Date of Manufacture: The eighth digit in the serial number indicates the year of manufacture; "6" is 2016 or 2026.

Importers: Bose Electronics (Shanghai) Company Limited, Level 6, Tower D, No. 2337 Gudai Rd. Minhang District, Shanghai 201100 | Bose Products B.V., Vijzelstraat 68, 1017HL Amsterdam, The Netherlands | Ingram Micro Mexico SA de CV, Joseillo 3 Int. Piso 5 Col. El Parque, Naucalpan de Juarez, Edo Mex 53398
 Phone Number: +52 55 5263 6500 | Bose Limited (H.K.), 7F., No. 2, Sec. 3, Minsheng E. Road, Zhongshan Dist., Taipei City 104511, Phone Number: +886-2-2514 7676 | Bose Limited, 16 Dufour's Place, London W1F 7SP

Mexico Service Phone Number: 0800-266-0292

Input Rating: 100-240V ~, 50/60 Hz, 180W

Model 443537. The CMIIT ID is located on the bottom of the subwoofer.

The **Bose Terms of Use** apply to this product: worldwide.Bose.com/termsofuse

License Disclosures: To view the license disclosures that apply to the third-party software packages included as components of the Bose Lifestyle Ultra Subwoofer, use the Bose app. You can access this information from the Settings menu.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google and Google Play are trademarks of Google LLC.

Bose, the B logo, CustomTune, and Lifestyle are trademarks of Bose Corporation. | Bose Corporation Headquarters: 1-877-230-5639 | ©2026 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

Serial Number and Regulatory Markings Location: This information is located on the bottom of the subwoofer.

Please complete and retain for your records

Serial number: _____

Model number: 443537

Please keep your receipt. Now is a good time to register your Bose product. You can easily do this by going to worldwide.Bose.com/ProductRegistration



WHAT'S IN THE BOX

Contents 7

SUBWOOFER PLACEMENT

Recommendations 8

POWER

Connect the subwoofer to power 9

CONNECT TO YOUR SOUNDBAR

Connect using the Bose app 10
 New to the Bose app? 10
Connect using an audio cable 11

SUBWOOFER STATUS 12

CARE AND MAINTENANCE

Serial number and regulatory markings location 13
Clean the subwoofer 13
Replacement parts and accessories 13
Limited warranty 13


TROUBLESHOOTING

Reset the subwoofer 14
Restore the subwoofer to factory settings 15




CONTENTS

Confirm that the following parts are included:



Bose Lifestyle Ultra Subwoofer



Power cord*

*May ship with multiple power cords. Use the power cord for your region.

NOTE: If any part of your product appears to be missing or damaged, don't use it. Visit support.bose.com/lu-subwoofer for troubleshooting articles, videos, and product repair or replacement.


RECOMMENDATIONS

For best performance, follow these recommendations when placing the subwoofer:

- Do NOT place any objects on top of the subwoofer.
- To avoid wireless interference, keep other wireless equipment 1 – 3 ft (0.3 – 0.9 m) away from the subwoofer. Place the subwoofer outside of and away from metal cabinets, other audio/video components, and direct heat sources.
- Place the subwoofer on its rubber feet on a stable, flat, and level surface. For proper support, its feet must be resting flat on the surface. Vibration can cause the subwoofer to move, particularly on smooth surfaces like marble, glass, or highly polished wood.
- Place the subwoofer along the same wall as your TV, or along any other wall in the front third of the room.
- Keep the front side of the subwoofer (the side opposite the POWER connector) at least 3 in (7.6 cm) from any other surface. Blocking the port on the bottom of this side may affect acoustic performance.
- For more bass, place the subwoofer closer to walls and corners. For less bass, place the subwoofer further from walls and corners.
- Make sure there is an AC (mains) power outlet nearby.




CAUTION: Do NOT place the subwoofer on its side or top when in use.



CONNECT THE SUBWOOFER TO POWER

1. Connect the power cord to the POWER port on the subwoofer.



2. Plug the other end of the power cord into an AC (mains) power outlet.

The subwoofer powers on. The status light slowly pulses white, red, and amber (repeated).

NOTE: The status light slowly pulses white, red, and amber during initial product setup. If you're reconnecting the subwoofer to power, the status light slowly pulses white, then glows solid white.

CONNECT USING THE BOSE APP

NOTE: If you can't connect to your soundbar using the Bose app, connect using an audio cable (see page 11).

1. In the Bose app, select your soundbar.

NOTE: Look for the name you entered for your soundbar in the Bose app. If you didn't name your soundbar, the default name appears.

2. Go to the Settings menu to add the subwoofer.
3. Once the subwoofer is connected, for best sound quality Bose recommends running the optional CustomTune sound calibration using the Bose app. You can access this option from the Settings menu. For more information, refer to your soundbar owner's guide.

New to the Bose app?

1. On your mobile device, download the Bose app.



setup.Bose.com/lu-subwoofer




2. Follow the app instructions.

CONNECT USING AN AUDIO CABLE


NOTES:

- If you don't have a 3.5 mm audio cable (commonly used for headphones and mobile devices), visit [Bose.com/c/accessories](https://www.bose.com/c/accessories) to purchase the Bose Bass Module Connection Cable. You can also purchase a cable at your local electronics store.
 - When you connect the subwoofer to your soundbar using an audio cable, wireless connectivity is disabled on the subwoofer.
1. Connect one end of a 3.5 mm audio cable to the **BASS IN** port on the back of the subwoofer.




2. Connect the other end of the cable to the **BASS** port on the back of your soundbar.

NOTE: Your soundbar port panel may not appear as shown. Make sure you use the port marked **BASS**.



3. Once the subwoofer is connected, for best sound quality Bose recommends running the optional CustomTune sound calibration using the Bose app. You can access this option from the Settings menu. For more information, refer to your soundbar owner's guide.

The status light is located on the back of the subwoofer and shows the subwoofer status.



STATUS LIGHT ACTIVITY	SYSTEM STATE
Slowly pulses white, red, and amber (repeated)	Powering on and booting up NOTE: Occurs only during initial product setup.
Slowly pulses white	Powering on
Quickly blinks amber	Connecting to soundbar
Solid white	Connected to soundbar
Quickly blinks white	CustomTune sound calibration in progress
Slowly pulses white	Update downloading NOTE: If the subwoofer is connected to the Bose Lifestyle Ultra Soundbar using an audio cable, wireless connectivity is disabled and the subwoofer won't receive software updates.
Dim white	Network standby (wireless connection)
Dim amber	Low power standby (wired connection)
Quickly blinks red	Error - contact Bose customer service

SERIAL NUMBER AND REGULATORY MARKINGS LOCATION

This information is located on the bottom of the subwoofer.

CLEAN THE SUBWOOFER

Wipe the exterior of the subwoofer with a soft, dry cloth.

CAUTIONS:

- Do NOT allow liquids to spill onto the subwoofer or into any openings.
- Do NOT use any sprays near the subwoofer.
- Do NOT use any solvents, chemicals, or cleaning solutions containing alcohol, ammonia, or abrasives.
- Do NOT allow objects to drop into any openings.

REPLACEMENT PARTS AND ACCESSORIES

Replacement parts and accessories can be ordered through Bose customer service.

Visit: support.Bose.com/lu-subwoofer

LIMITED WARRANTY

The subwoofer is covered by a limited warranty. Visit our website at worldwide.Bose.com/Warranty for details of the limited warranty.

To register your product, visit worldwide.Bose.com/ProductRegistration for instructions. Failure to register will not affect your limited warranty rights.

If you experience problems with the subwoofer, make sure:

- The subwoofer is plugged firmly into a live AC (mains) power outlet.
- All cables are secure.
- You're playing audio that has bass frequencies, such as music or movies.

If you could not resolve your issue, you can also access troubleshooting in the Bose app and articles, videos, and other resources at: support.Bose.com/lu-subwoofer-og

If you are unable to resolve your issue, contact Bose customer service.


Visit: worldwide.Bose.com/contact

RESET THE SUBWOOFER

If the subwoofer is unresponsive, you can reset it.

NOTE: Resetting the subwoofer resets the product controls. It doesn't clear any audio, network, or CustomTune sound calibration settings.

Press and release the Reset button.




The subwoofer reboots. The status light displays the current status (see page 12).

RESTORE THE SUBWOOFER TO FACTORY SETTINGS

Restoring the factory settings, clears all audio, network, and CustomTune sound calibration settings from the subwoofer and returns it to its default settings.

NOTE: Restoring the subwoofer disconnects a Bose Lifestyle Ultra Soundbar wirelessly connected to the subwoofer.

1. Press and hold the Reset button for 10 seconds, until the status light blinks white twice.



The subwoofer reboots. The status light slowly pulses white, red, and amber (repeated).

2. Connect the subwoofer using the Bose app (see page 10).



896215-0010