



JLAB
EPIC PARTY
BLUETOOTH
SPEAKER

We love that you are rocking JLab!
We take pride in our products and fully stand behind them.



YOUR WARRANTY

All warranty claims are subject to JLab authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.



CONTACT US


Reach out to us at support@jlab.com or visit jlab.com/contact

REGISTER TODAY
jlab.com/register
 Product updates | How-to tips
 FAQs & more

PAIR UP

1

Press and hold button. Lights will flash blue/red to indicate pairing mode.



2

Select JLab Epic Party in your device settings to connect.



GET CHARGED



PULSES: CHARGING




LIGHTS OFF: CHARGED

USB-C CHARGE OUT (charge other devices)


AUX INPUT

1/4" INPUT




USB-C CHARGE IN (charge Epic Party)

Connect 30w charger to **USB-C IN** and wall outlet to charge.




GO AHEAD, PRESS THE BUTTON




LabSync (CAST TO OTHER JLAB PARTY SPEAKERS)

- 1 Connect **Epic Party** to your device.
Press Hold to enter LabSync.
Epic Party will say "LabSync"




- 2 With your other **JLab Party Speaker(s)** turned off, **Press hold** power button until LEDs flash blue/red.




- 3 Followed by entering LabSync on your other speaker(s).



- 4 **Casting**



Receiving



QUICK TIPS:

- Epic Party is set to Eco-Mode by default. Lights will turn off when battery is less than 25% to conserve power.
- Turning off the lights will significantly improve playtime.
- Epic Party will auto power off if no media is playing for 30 minutes.
- Download the JLab App to adjust the default settings.
- LabSync works with all JLab Pop Party, GO Party, JBuds Party, and Epic Party speakers.

DOWNLOAD THE APP

Customize the Sound, Lights, and Features.



FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada 's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS)d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toutes les interférences, y compris

celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L' équipement est conforme aux limites d'exposition aux rayonnements définies par la IC pour les environnements non contrôlés. La distance minimale entre le dissipateur de chaleur et votre corps doit être de 20 cm lors de l' installation et de l' utilisation du matériel.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



[Shop products](#) | [Product alerts](#) | [Burn-in your headphones](#)

JLab Store + Burn-in Tool

