

Bluetooth® Earbuds User Manual




WHAT'S IN THE BOX

- Bluetooth® Earbuds (2)
- Charging case (1)
- USB-C to USB charging cable (1)
- Carabiner (1)
- User manual (1)
- Extra set of ear gels

www.cat.com www.caterpillar.com
 © 2024 Caterpillar. All Rights Reserved. CAT, CATERPILLAR, LETS DO THE WORK, their respective logos, "Caterpillar Yellow", the "Power Edge" Trade Dress as well as its corporate and product identity used herein, are trademarks of Caterpillar Inc., a Division of Bost Tech Products, Inc., a licensee of Caterpillar Inc. All other marks are the property of their respective owners. ARMS MANUFACTURING A DIVISION OF BOST TECH PRODUCTS INC. WWW.CATVIBBLEACCESSORIES.COM 1-888-868-8688 • GET TRADE STICKERS! C-1748

CHARGING MODE (continued)




*Use the USB cable to connect with computer

*Use the USB cable to connect with USB port or adapter

Earbud charging mode	When the earbuds are placed into the charging case, they will turn off automatically and start charging. When only one earbud is placed in the charging case, the other one won't turn off. The red light will stay on and change to blue when it is fully charged.
Charging case charging	1. LED 1, LED 2, LED 3, LED 4 are successively turned on (blue light). The four blue lights are on after being fully charged. When the charging case is disconnected, the power indicator light will go out after staying on for 3 seconds. 2. The charging indicator lights light up in red when charging and turn off when fully charged.
Earbud low battery	When the battery voltage is lower than 3.3V, there will be a prompt tone of "Low Battery", and the red light flashes slowly. If the battery voltage is lower than 3.0V, it will turn off.

FUNCTION

Left Earbud Right Earbud



Power On	Touch and hold the control key for 3 seconds or take earbuds out of the charging case	Blue lights flash with the prompt tone "Power On"
Power Off	Touch and hold the control key for 5 seconds or put the earbuds into the charging case. If there is no connection for 2 minutes, they will automatically turn off	The red light flashes for 3 seconds and turns off with the prompt tone "Power Off"
Answer Calls	Touch the control key one time	
Hang Up Calls	Touch the control key one time	
Reject Calls	Long touch for 2 seconds, or touch 2 times	
Cancel Dialing	Touch the control key one time	
Play/Pause	Touch the control key one time	Prompt tone "next"
Volume +	Touch the control key 4 times on the left earbud	Prompt tone "next"
Previous Track	Touch the control key 2 times on the right earbud	
Next Track	Touch the control key 2 times on the left earbud	
SHUT/STBY	Touch the control key 3 seconds to hear the prompt tone and release	Prompt tone "Go"
Transparency Mode	Long touch for 20 seconds	Prompt tone "Go"
Reset	Long touch for 20 seconds	The red light flashes for 3 seconds and you will hear the prompt tone "Reset Off"

NOISE CANCELING


The earbuds are equipped with ENC (environmental noise canceling) and ANC (active noise canceling), which are engaged at all times. ENC will reduce unwanted sounds from the surrounding environment so the caller on the other end can hear better. ANC will assist in blocking out external noise so the earbud user can hear better. ANC can be turned off (see: Transparency Mode) while ENC can not be turned off. If ANC is turned off, it will automatically turn back on once the earbuds are powered down and back on.

SPECIFICATIONS

Device Name: CAT-BTEARBUD
Charge Time: Approximately 1 hour
Earbuds Playtime: Approximately 5.5 hours
Bluetooth Version: Bluetooth 5.3
Standby Time: Approximately 200 hours
Charging Case Battery: Built-in 400mAh
Charging Case Voltage: DC 5V
Earbud Battery: Built-in 40mAh
Supported Cell Phone Systems: iOS, Android
Input: USB-C

CHARGING MODE

* Remove red tabs from earbuds prior to use




* Use button to open and close the cover

EARBUD PAIRING AND BLUETOOTH® CONNECTION

Pairing Mode	Touch and hold the power keys of both earbuds for 3 seconds, or take them out of the charging case to turn them on. The red and blue lights of both earbuds will start flashing. The earbuds will enter pairing mode. Within 2 minutes, it will turn off automatically.	The red and blue lights on the main ear flash alternately then you will hear the prompt tone "Pairing". After the pairing is successful, the red and blue lights will not flash.
Connecting Bluetooth Devices	Search the earbuds in Bluetooth settings on the cell phone and connect.	Prompt tone of "Connect". After connecting, the red and blue lights on the earbuds will flash.
Disconnect Bluetooth	Connect the Bluetooth device to the earbud (beyond the distance or disconnect) turn off Bluetooth. After Bluetooth is turned on again, there is automatic connection between Bluetooth and mobile phone.	Prompt tone of "Disconnect". The red and blue lights of the main earbud flash quickly.
Manual Earbud Pairing	Enter the earbud pairing mode and touch and hold for 5 seconds.	Prompt tone "Pairing". Red and blue lights flash alternately.

REMARKS

1. Enter Bluetooth settings and search "CAT-BTEARBUD"
2. If placing earbuds into the charging case while playing music, the earbud will be disconnected from the cell phone and turn off. If you open the charging case and take out the earbuds, they will automatically turn on and reconnect.
3. The earbuds will connect to the cell phone automatically when turning on. If it can't reconnect automatically, press once to reconnect.
4. If the earbuds are unable to connect to the cell phone, clear the pairing history, reboot the earbuds and reconnect.
5. Please use 5V charger



TROUBLESHOOTING

- I can't hear any music.**
Make sure the volume is turned up on both your device and the earbuds. If you still don't hear anything, try pairing the earbuds again.
- I can't answer phone calls.**
Not all phones support hands-free calling. Please refer to your cellular device manual.
- I'm having trouble pairing my Bluetooth® device.**
Make sure your device supports Bluetooth and Bluetooth is enabled. If the earbuds don't show up in your list of nearby Bluetooth devices, try restarting the earbuds.

Note: You cannot pair your device to the earbuds if it is already paired to another Bluetooth device.
The sound is cutting out/distorted.
 Low battery and large obstructions between earbuds and device will affect the Bluetooth distance capabilities and connection. For best results, make sure to keep your earbuds charged and within 10 unobstructed meters of device.

Still having problems? Give us a call.

Toll free: 888-550-2837 | Hours: Monday-Friday, 8am-5pm CST

ATTENTION



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.